

SERVICE MANUAL

SERVICE MANUAL SECTION

BODY CONTROLLER DIAGNOSTIC TROUBLE CODES

Model: 3200

Model: 4100

Model: 4300

Model: 4400

Model: 7300

Model: 7400

Model: 7500

Model: 7600

Model: 7700

Model: 8500

Model: 8600

Model: BE 200

Model: CE Bus

Model: CXT

Model: DuraStar

Model: LoneStar

Model: MXT

Model: ProStar

Model: RXT
Model: TranStar
Model: WorkStar

S08327

08/16/2010

TABLE OF CONTENTS

| | |
|---|----------|
| 1. DISPLAYING DIAGNOSTIC TROUBLE CODES..... | 1 |
| 1.1. VEHICLES EQUIPPED WITH OPTION TO DISPLAY CODES..... | 1 |
| 1.1.1. Displaying Codes on the Gauge Cluster (Non-VID equipped vehicles)..... | 1 |
| 1.1.2. Displaying Codes on the VID (if equipped)..... | 2 |
| 2. CLEARING DIAGNOSTIC TROUBLE CODES..... | 2 |
| 3. DEFINITIONS..... | 2 |
| 3.1. FAILURE MODE INDICATORS (FMI)..... | 3 |
| 3.2. SOURCE ADDRESSES (SA)..... | 4 |
| 4. DIAGNOSTIC TROUBLE CODE (DTC) LIST..... | 4 |

1. DISPLAYING DIAGNOSTIC TROUBLE CODES

The ability to display diagnostic trouble codes (DTC) is an optional feature. Codes may be displayed on either the gauge cluster or an optional vehicle information display (VID). **The vehicle must be equipped with the option to display codes in both cases.** Codes will not be displayed on the gauge cluster if the vehicle is equipped with the VID.

1.1. VEHICLES EQUIPPED WITH OPTION TO DISPLAY CODES

1.1.1. Displaying Codes on the Gauge Cluster (Non-VID equipped vehicles)

To display codes on vehicles not equipped with a VID:

1. Set the parking brake.
2. Turn the key switch to the ACCESSORY position to view only previously active codes. Turn the key switch to the IGNITION position to view both active and previously active codes.
3. Momentarily press the Cruise "ON" switch and the Cruise "Resume" switch at the same time.

A gauge sweep will be performed on the gauges. The gauge cluster will then display the following information for 5 seconds:

- Software Rev: XXX
- Hardware Rev: XXX
- Active Faults: XXX
- Total Faults: XXX

NOTE – The gauge cluster will only display “Software Rev” and “Hardware Rev” for 5 seconds followed by the message “Diagnostic Trouble Codes are not available” if the vehicle is not equipped with the option to display codes.

If faults are present, the gauge cluster display will show each diagnostic trouble code for 10 seconds and then automatically scroll to the next entry and continue to cycle through the faults. Once all faults have been displayed the number of faults will be displayed again, then the cycle will repeat. To manually cycle through the fault list press and release the cluster display selector button. The following information will be displayed for each fault:

SPN: XXXX FMI: XX
Active
OC: XXX SA: XXX

SPN: XXXX FMI: XX
Previously Active
OC: XXX SA: XXX

NOTE – Turning the key switch off, turning the key switch to the CRANK position, or releasing the park brake will take the gauge cluster out of the diagnostic mode.

DEFINITIONS

1.1.2. Displaying Codes on the VID (if equipped)

The VID can be used to display all diagnostic trouble codes (DTC) on the vehicle. Suspect parameter number (SPN), failure mode indicator (FMI) and occurrence count numbers are listed. Source addresses and DTC descriptions are presented in plain text.

NOTE – The VID will display “Not Available” if a DTC description is not available for a particular fault.

Displaying codes will only be allowed if all of the following conditions are true:

- The key switch is in the IGNITION position.
- AND displaying codes is allowed due to vehicle orderable options
- AND the programmable parameter “**Diagnostics**” is enabled using Diamond Logic® Builder (DLB).
- The vehicle is not moving (the Vehicle Speed is equal to zero).
- The feature is not password protected to prevent unauthorized access. Refer to the Vehicle Information Display Owner’s Manual for more information.

Perform the following steps if all of the above conditions are met:

1. Go to the main menu screen

NOTE – The following selections will not be available if the vehicle is not equipped with the option to display codes.

2. Select “DIAGNOSTIC CODES”
3. Select “ACTIVE” or “INACTIVE”. The VID may initiate a password prompt if the VID has been password protected. Refer to the Vehicle Information Display Owner’s Manual for more information.

The VID will indicate "NO FAULT DETECTED" if faults are not found. Scroll through the list of faults if faults are present.

The following information will be displayed for each fault:

SPN : FMI OC
SA
DTC Description

2. CLEARING DIAGNOSTIC TROUBLE CODES

Previously active diagnostic trouble codes can only be cleared by a service tool, such as Diamond Logic® Builder (DLB). Some previously active codes may not be cleared by this method.

3. DEFINITIONS

- “**SPN**” represents the Suspect Parameter Number. This number identifies the item for which diagnostics are being reported.
- “**FMI**” is the Failure Mode Indicator. This number represents the type of failure detected. Refer to Failure Mode Indicators (FMI) below for more information.

- “**Active**” or “**Previously Active**” will be displayed to identify whether a fault is currently active or if the fault was previously active.
- “**OC**” is the Occurrence Count. This number represents the number of times a fault has gone from previously active to active.
- “**SA**” is the Source Address. This number identifies the module reporting the fault. Refer to Source Addresses (SA) for more information.

3.1. FAILURE MODE INDICATORS (FMI)

- FMI=0 - Data Valid But Above Normal Operational Range - Most Severe Level
- FMI=1 - Data Valid But Below Normal Operational Range - Most Severe Level
- FMI=2 - Data Erratic, Intermittent Or Incorrect
- FMI=3 - Voltage Above Normal, Or Shorted To High Source
- FMI=4 - Voltage Below Normal, Or Shorted To Low Source
- FMI=5 - Current Below Normal Or Open Circuit
- FMI=6 - Current Above Normal Or Grounded Circuit
- FMI=7 - Mechanical System Not Responding Or Out Of Adjustment
- FMI=8 - Abnormal Frequency Or Pulse Width Or Period
- FMI=9 - Abnormal Update Rate
- FMI=10 - Abnormal Rate Of Change
- FMI=11 - Root Cause Not Known
- FMI=12 - Bad Intelligent Device Or Component
- FMI=13 - Out Of Calibration
- FMI=14 - Special Instructions
- FMI=15 - Data Valid But Above Normal Operating Range - Least Severe Level
- FMI=16 - Data Valid But Above Normal Operating Range - Moderately Severe Level
- FMI=17 - Data Valid But Below Normal Operating Range - Least Severe Level
- FMI=18 - Data Valid But Below Normal Operating Range - Moderately Severe Level
- FMI=19 - Received Network Data In Error
- FMI=20 - Data Drifted High
- FMI=21 - Data Drifted Low
- FMI=31 - Condition Exists

3.2. SOURCE ADDRESSES (SA)

NOTE – The available source addresses will vary depending on each vehicle configuration.

NOTE – Diagnostic Trouble Codes listed in this document are Body Controller, Auxiliary Gauge Switch Pack, Secondary Instrument Cluster, Instrument Cluster, Rear HVAC Module, and Compass Module.

| Module Name | Source Address |
|---|----------------|
| Engine Control Module (ECM) | 00 |
| Transmission Control Module (TCM) | 03 |
| Shift Selector | 05 |
| Antilock Brake System (ABS) | 11 |
| Electronic Gauge Cluster (EGC) | 23 |
| Compass Module | 28 |
| Body Controller | 33 |
| Vehicle Sensor Module (VSM) | 39 |
| Vehicle Information Display (VID) | 40 |
| Tire Pressure Monitoring System (TPMS) | 51 |
| Rear HVAC | 58 |
| Aftertreatment Module | 61 |
| Telematics Module | 74 |
| Auxiliary Gauge Switch Pack (AGSP) 3 | 132 |
| Secondary Instrument Cluster (SIC) 1 | 167 |
| Hybrid Electric Vehicle (HEV) or Eaton Transmission Control Pad | 239 |
| Power Pack 3 | 247 |
| Service Tool | 249 |
| Global | 255 |

4. DIAGNOSTIC TROUBLE CODE (DTC) LIST

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|----------------------------|-----|--|---|----------|------|----------------|
| 23 | 171 | Ambient Air Temperature | 3 | Fault on Analog Input 3 above normal when used for outside temperature | Voltage above normal, or shorted to high source | | | |
| 23 | 171 | Ambient Air Temperature | 4 | Fault on Analog Input 3 below normal when used for outside temperature | Voltage below normal, or shorted to low source | | | |
| 23 | 623 | Red Stop Lamp | 5 | Red stop light malfunction | Current below normal or open circuit | | | |
| 23 | 624 | Amber Warning Lamp | 5 | Amber Warning light malfunction | Current below normal or open circuit | | | |
| 23 | 928 | Axle Location | 3 | Fault on Analog Input 1 when used for axle load | Voltage above normal, or shorted to high source | | | |
| 23 | 928 | Axle Location | 4 | Fault on Analog Input 1 when used for axle load | Voltage below normal, or shorted to low source | | | |
| 23 | 987 | Protect Lamp | 5 | Protect warning light malfunction | Current below normal or open circuit | | | |
| 23 | 1213 | Malfunction Indicator Lamp | 5 | MIL warning light malfunction | Current below normal or open circuit | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|--------------------------------------|--|------|----------------|
| 23 | 1438 | ABS/EBS Amber Warning Lamp State (Powered Vehicle) | 5 | ABS warning light malfunction | Current below normal or open circuit | | | |
| 23 | 1439 | EBS Red Warning Lamp State | 5 | Brake Pressure warning lamp malfunction | Current below normal or open circuit | | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23), lost communication with ESC. | Loss of drive-train data link. | Loss of communication in excess of 10 seconds. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23), lost communication with engine controller. | Loss of drive-train data link. | Loss of communication in excess of 10 seconds. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23). ABS warning light malfunction. | | | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23). Trailer ABS (Bus Lift Gate) warning light malfunction. | | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|--|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23). Datalink ignition signal does not match the hardwired ignition signal. | | | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 1, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 1, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 1, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 1, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 1, data missing. | | The data for this gauge is not being transmitted. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|--|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 2, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 2, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 2, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 2, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 2, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 3, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 3, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|--|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 3, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 3, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 3, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 4, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 4, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 4, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 4, data unavailable. | | The data for this gauge should be, but is not available. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|--|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 4, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 5, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 5, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 5, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 5, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 5, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 6, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|--|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 6, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 6, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 6, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 6, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 7, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 7, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 7, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|--|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 7, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 7, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 8, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 8, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 8, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 8, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 8, data missing. | | The data for this gauge is not being transmitted. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------|-----|---|-------|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 9, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 9, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 9, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 9, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 9, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 10, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 10, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---------------------------|-----|---|---|---|------|----------------|
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 10, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 10, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 1705 | Gauge Cluster (v 8.7) | 14 | Gauge Cluster (address 23) gauge location 10, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 1725 | Front Axle Above Pressure | 3 | Fault on Analog Input 2 above normal when used for axle load | Voltage above normal, or shorted to high source | | | |
| 23 | 1725 | Front Axle Below Pressure | 4 | Fault on Analog Input 2 below normal when used for axle load | Voltage below normal, or shorted to low source | | | |
| 23 | 1727 | Rear Axle Above Pressure | 3 | Fault on Analog Input 1 above normal when used for axle load | Voltage above normal, or shorted to high source | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|--|--|------|----------------|
| 23 | 1727 | Rear Axle Below Pressure | 4 | Fault on Analog Input 1 below normal when used for axle load | Voltage below normal, or shorted to low source | | | |
| 23 | 1792 | Tractor-Mounted Trailer ABS Warning Signal | 5 | Trailer ABS warning light malfunction | Current below normal or open circuit | | | |
| 23 | 1793 | ATC/ASR Information Signal | 5 | Traction Control warning light malfunction | Current below normal or open circuit | | | |
| 23 | 2000 | Source Address 0 | 9 | Loss of data link from Engine Controller | Abnormal update rate | | | |
| 23 | 2003 | Source Address 3 | 9 | Loss of data link from the Transmission Controller | Abnormal update rate | | | |
| 23 | 2011 | Source Address 11 | 9 | Loss of data link from ABS controller | Abnormal update rate | | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23), lost communication with ESC. | Loss of drive-train data link. | Loss of communication in excess of 10 seconds. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23), lost communication with engine controller. | Loss of drive-train data link. | Loss of communication in excess of 10 seconds. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23). ABS warning light malfunction. | | | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23). Trailer ABS (Bus Lift Gate) warning light malfunction. | | | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23). Datalink ignition signal does not match the hardwired ignition signal. | | | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 1, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 1, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 1, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 1, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 1, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 2, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 2, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 2, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 2, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 2, data missing. | | The data for this gauge is not being transmitted. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 3, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 3, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 3, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 3, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 3, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 4, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 4, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 4, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 4, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 4, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 5, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 5, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 5, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 5, data unavailable. | | The data for this gauge should be, but is not available. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 5, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 6, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 6, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 6, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 6, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 6, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 7, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 7, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 7, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 7, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 7, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 8, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 8, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 8, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|--|-------|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 8, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 8, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 9, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 9, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 9, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 9, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 9, data missing. | | The data for this gauge is not being transmitted. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------|-----|---|---|---|------|----------------|
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 10, data out of range high. | | Data for this gauge is above the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 10, data out of range low. | | Data for this gauge is below the value that can be displayed. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 10, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 10, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 23 | 2023 | Gauge Cluster | 14 | Gauge Cluster (address 23) gauge location 10, data missing. | | The data for this gauge is not being transmitted. | | |
| 23 | 2023 | Gauge Cluster | 3 | Fault on Analog Input 4 above normal when used for ambient light | Voltage above normal, or shorted to high source | | | |
| 23 | 2023 | Gauge Cluster | 4 | Fault on Analog Input 4 below normal when used for ambient light | Voltage below normal, or shorted to low source | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|----------------------------|-----|---|---|----------|------|----------------|
| 23 | 2023 | Gauge Cluster | 11 | Message ignition and switched ignition do not match. | Root cause not known | | | |
| 23 | 2023 | Gauge Cluster | 12 | Failure of non-volatile memory or checksum fault | Bad intelligent device or component | | | |
| 23 | 2023 | Gauge Cluster | 6 | Short detected in the panel dimmer | Current above normal or grounded circuit | | | |
| 23 | 2033 | Source Address 33 | 9 | Loss of data link from ESC | Abnormal update rate | | | |
| 23 | 2062 | Source Address 62 | 9 | Loss of data link from Meritor Wabco Brake Controller to EGC | Meritor Wabco Brake Controller data link failure to EGC | | | |
| 28 | 165 | Compass Bearing | 12 | Sensor Fault/ Compass Bearing | Faulty Compass module sensor | | | |
| 28 | 630 | Calibration Memory | 13 | Compass is out of Calibration | Compass is out of calibration, need to Calibrate | | | |
| 28 | 639 | Drivetrain Message Timeout | 2 | EEPROM data in the Microcontroller is corrupted or Error in Calibration (The Compass module is not calibrated.) | Data erratic, intermittent or incorrect | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|----------------------------|-----|--|---|---|------|---------------------|
| 28 | 639 | Drivetrain Message Timeout | 19 | HMC6352 sensor is not responding or communication link with HMC6352 (I2C communication link) not working reliably. | Faulty Compass module or I2C communication link | | | |
| 28 | 639 | Drivetrain Message Timeout | 9 | J1939 Communication Link Fault | Faulty Compass or Drivetrain Datalink | | | |
| 33 | 69 | Two Speed Axle Switch | 2 | Two Speed Axle Switch Error | Data erratic, intermittent or incorrect | | | Two_Spd_Axle_Switch |
| 33 | 70 | Air Powered Park Brake | 2 | The Auto apply portion with the Air Powered Park Brake is not Operating | Data erratic, intermittent or incorrect | Occurs When the Park Brake Switch is not set within 5 seconds of the receipt of the Park as the requested gear. This failure would indicate a failure in the auto apply relay or in the air lines between the auto apply relay and the Park Brake switch. | | |
| 33 | 70 | Air Powered Park Brake | 7 | Air Powered Park Brake is stuck | Mechanical system not responding or out of adjustment | Occurs when the park brake switch does not match the spring apply-air release (SAAR) chamber travel sensor. This indicates the park brake cannot be applied or cannot be released. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|-------------------------------------|-----|---|--|---|----------|---|
| 33 | 70 | Air Powered Park Brake | 14 | Air Powered Park Brake is stuck | | Occurs when the park brake switch does not match the spring apply-air release (SAAR) chamber travel sensor. This indicates the park brake cannot be applied or cannot be released. | | Park_Brake_SAAR_Travel_Signal, Park_Brake_Switch_Signal |
| 33 | 70 | Air Powered Park Brake | 14 | The Auto Apply portion with the Air Powered Park Brake is not operating | | Occurs When the Park Brake Switch is not set within 5 seconds of the receipt of the Park as the requested gear. This failure would indicate a failure in the auto apply relay or in the air lines between the auto apply relay and the Park Brake switch. | | Park_Brake_Switch_Signal |
| 33 | 77 | Forward Rear Drive Axle Temperature | 0 | Front Rear Axle Temperature Sensor reading above normal range | Front Axle Temperature Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B10 | Frwd_RR_Axle_Oil_Temp_Raw_Signal |
| 33 | 77 | Forward Rear Drive Axle Temperature | 1 | Front Rear Axle Temperature Sensor reading below normal range | Front Axle Temperature Sensor Short to Ground or faulty sensor system | | 1600-B10 | Frwd_RR_Axle_Oil_Temp_Raw_Signal |
| 33 | 78 | Rear Rear Drive Axle Temperature | 0 | Rear Rear Axle Temperature Sensor reading above normal range | Rear Rear Axle Temperature Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B11 | Rear_RR_Axle_Oil_Temp_Raw_Signal |
| 33 | 78 | Rear Rear Drive Axle Temperature | 1 | Rear Rear Axle Temperature Sensor reading below normal range | Rear Rear Axle Temperature Sensor Short to Ground or faulty sensor system | | 1600-B11 | Rear_RR_Axle_Oil_Temp_Raw_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|---------------------------------------|-----|--|---|---|----------|---------------------------------|
| 33 | 84 | Wheel-Based Vehicle Speed | 9 | Missing Wheel Based Vehicle Speed Message | J1939 Drivetrain Data Link Lost | | | Vehicle_Speed |
| 33 | 94 | Fuel Inlet Restriction Lamp | 4 | Fuel Inlet Restriction Lamp | Output shorted to ground | | | |
| 33 | 94 | Fuel Inlet Restriction Lamp | 6 | Fuel Inlet Restriction Lamp | Output overheat | | | |
| 33 | 97 | Water In Fuel Indicator | 4 | Water In Fuel Indicator | Output shorted to ground | | | |
| 33 | 97 | Water In Fuel Indicator | 6 | Water In Fuel Indicator | Output overheat | | | |
| 33 | 115 | Alternator Current | 2 | Phase missing fault/alternator fault. | One or more of the three phase wire from the Dynamic Alternator to the Power Pack E module may be disconnected. | One or more of the three phase wires from the alternator is disconnected. The Power Pack system is shutdown and requires an ignition cycle. | | |
| 33 | 116 | Brake Application Pressure | 0 | Brake Application Pressure Sensor reading above normal range | Brake Application Sensor Shorted High or faulty sensor system | | 1600-B14 | Brake_App_Air_Sensor_Raw_Signal |
| 33 | 116 | Brake Application Pressure | 1 | Brake Application Pressure Sensor reading below normal range | Brake Application Sensor Short To Ground or Open Circuit or faulty sensor system | | 1600-B14 | Brake_App_Air_Sensor_Raw_Signal |
| 33 | 158 | Battery Potential (Voltage), Switched | 2 | Key State Ignition Signal Error | Open in Ignition Signal Input Circuit To BC | | 1600-A16 | |
| 33 | 168 | Electrical Potential (Voltage) | 2 | Comm. fault from ESC/BC to PP3. | Datalink interrupted between ESC and Powerpack. | The Power Pack E Module has stopped receiving heart beat message from the ESC/BC. | | |
| 33 | 168 | Electrical Potential (Voltage) | 3 | DC Module Overvoltage condition on Vehicle DC Bus. | An Over Voltage Condition in the DC regulator (Vehicle Battery Bus). | A High Battery Cutout fault has occurred and the source of the fault is the DC regulator (Vehicle Battery Bus). | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|--------------------------------|-----|--|---|---|------|----------------|
| 33 | 168 | Electrical Potential (Voltage) | 3 | AC Module Overvoltage condition on High Voltage DC Bus. | An Over Voltage Condition in the AC module (Inverter High Voltage Bus). | A high Battery Cutout fault has occurred and the source of the fault is the AC module (inverter high voltage bus). | | |
| 33 | 168 | Electrical Potential (Voltage) | 4 | DC Module Undervoltage condition on Vehicle DC Bus. | An Under Voltage Condition in the DC regulator (Vehicle Battery Bus). | A Low Battery Cutout fault has occurred and the source of the fault is the DC regulator (Vehicle Battery Bus). | | |
| 33 | 168 | Electrical Potential (Voltage) | 4 | AC Module Undervoltage condition on High Voltage DC Bus. | An Under Voltage Condition in the AC module (Inverter High Voltage Bus). | A low Battery Cutout fault has occurred and the source of the fault is the AC module (inverter high voltage bus). | | |
| 33 | 168 | Electrical Potential (Voltage) | 6 | AC Module has shutdown due to overload condition. | A Surge may have occurred for a while in the Vehicle AC bus for a long time (The inverter supplies additional current to the load). | An Overload condition has been detected in the AC module and the Vehicle AC bus is shutdown. | | |
| 33 | 168 | Electrical Potential (Voltage) | 8 | Phase missing fault/alternator fault. | One or more of the three phase wire from the Dynamic Alternator to the Power Pack E module may be disconnected. | One or more of the three phase wires from the alternator is disconnected. The Power Pack system is shutdown and requires an ignition cycle. | | |
| 33 | 168 | Electrical Potential (Voltage) | 16 | DC module over temperature condition. | An overcurrent condition in the Vehicle DC Bus might have caused an over temperature. | An Over Temperature fault has occurred and the source of the fault is the DC regulator (Vehicle Battery Bus). | | |
| 33 | 168 | Electrical Potential (Voltage) | 16 | AC module over temperature condition. | An overcurrent condition in the Vehicle AC Bus might have caused an over temperature. | An Over temperature fault has occurred and the source of the fault is the AC module (inverter high voltage bus). | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|--|-----|--|---|---------------------------|---------------|-----------------------------|
| 33 | 168 | Electrical Potential (Voltage) | 17 | PPE3 Fuse Open. | Load exceeded rating. | PPE3 module Fuse is Open. | | |
| 33 | 175 | Engine Oil Temperature 1 | 0 | Engine Oil Temp Sensor reading above normal range | Engine Oil Temperature Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B6 | Eng_Oil_Temp_Raw_Signal |
| 33 | 175 | Engine Oil Temperature 1 | 1 | Engine Oil Temp Sensor reading below normal range | Engine Oil Temperature Sensor Short to Ground or faulty sensor system | | 1600-B6 | Eng_Oil_Temp_Raw_Signal |
| 33 | 177 | Transmission Oil Temperature | 0 | Transmission Oil Temperature Sensor reading above normal range | Transmission Oil Temperature Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B7 | Trans_Oil_Temp_Raw_Signal |
| 33 | 177 | Transmission Oil Temperature | 1 | Transmission Oil Temperature Sensor reading below normal range | Transmission Oil Temperature Sensor Short to Ground or faulty sensor system | | 1600-B7 | Trans_Oil_Temp_Raw_Signal |
| 33 | 247 | Total Engine Hours | 9 | Engine Total Hours Not Received | The Engine Control Module did not send the Total Engine Hours or possible Data Link failure | | | Engine_Hours_Byte_1 |
| 33 | 564 | Differential Lock State - Central | 5 | Transfer Case Lock Under Current Or Open Circuit | Current below normal or open circuit | Not available | Not available | MATV_Xfer_Case_Lock_Sol_Cmd |
| 33 | 564 | Differential Lock State - Central | 6 | Transfer Case Lock Relay Over Current | Current above normal or grounded circuit | Not available | Not available | MATV_Xfer_Case_Lock_Sol_Cmd |
| 33 | 566 | Differential Lock State - Central Rear | 5 | Power Divider Lock Relay Under Current Or Open Circuit | Open Circuit in Power Divider Lock Circuit | | | PDL_Lock_Solenoid_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|--|-----|---|---|---------------|---------------|---|
| 33 | 566 | Differential Lock State - Central Rear | 6 | Power Divider Lock Relay Over Current | Short To Ground in Power Divider Lock Circuit | | | PDL_Lock_Solenoid_Cmd |
| 33 | 567 | Differential Lock State - Front Axle 1 | 5 | Forward Axle 1 Diff lock air solenoid output undercurrent or open circuit | Current below normal or open circuit | Not available | Not available | Diff_Lock_Fwd_Solenoid_Cmd, MATV_Diff_Lock_Front_Sol_Cmd |
| 33 | 567 | Differential Lock State - Front Axle 1 | 6 | Forward Axle 1 Diff lock air solenoid output overcurrent | Current above normal or grounded circuit | Not available | Not available | Diff_Lock_Fwd_Solenoid_Cmd, MATV_Diff_Lock_Front_Sol_Cmd |
| 33 | 569 | Differential Lock State - Rear Axle 1 | 5 | Forward Rear Diff Lock Relay Under Current Or Open Circuit | Open Circuit in Forward Rear Diff Lock Circuit | | | Diff_Lock_1_Solenoid_Cmd, Diff_Lock_Solenoid_Cmd, Diff_Lock_Rear_Solenoid_Cmd, MATV_Diff_Lock_Rear_Sol_Cmd |
| 33 | 569 | Differential Lock State - Rear Axle 1 | 6 | Forward Rear Diff Lock Relay Over Current | Short To Ground in Forward Rear Diff Lock Circuit | | | Diff_Lock_1_Solenoid_Cmd, Diff_Lock_Solenoid_Cmd, Diff_Lock_Rear_Solenoid_Cmd, MATV_Diff_Lock_Rear_Sol_Cmd |
| 33 | 570 | Differential Lock State - Rear Axle 2 | 5 | Rear Rear Diff Lock Relay Under Current Or Open Circuit | Open Circuit in Rear Rear Diff Lock Circuit | | | Diff_Lock_2_Solenoid_Cmd |
| 33 | 570 | Differential Lock State - Rear Axle 2 | 6 | Rear Rear Diff Lock Relay Over Current | Short To Ground in Rear Rear Diff Lock Circuit | | | Diff_Lock_2_Solenoid_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|---------------------------------------|-----|---|---|---------------|----------------|--|
| 33 | 571 | Retarder Enable - Brake Assist Switch | 2 | Retarder Enable - Brake Assist On/Off switch failure | Data erratic, intermittent or incorrect | | | Comp_Brake_Switch, Eng_Retarder_Switch |
| 33 | 576 | ASR Off-road Switch | 2 | Traction Disable panel mounted switch is in an invalid position | Data erratic, intermittent or incorrect | | | Traction_Disable_SW |
| 33 | 577 | ASR "Hill Holder" Switch | 2 | HSA Disable Switch error | Fault in HSA Disable Switch | Not available | Not available | HSA_Disable_Switch |
| 33 | 596 | Cruise Control Enable Switch | 0 | Cruise Control Switch reading above normal range | Shorted High or Open in Cruise Control Switches Circuit | | 1600-B16 | Cruise_Switch_Raw_Signal |
| 33 | 596 | Cruise Control Enable Switch | 1 | Cruise Control Switch reading below normal range | Short To Ground in Cruise Control Switches Circuit | | 1600-B16 | Cruise_Switch_Raw_Signal |
| 33 | 596 | Cruise Control Enable Switch | 2 | Cruise Control Enable Switch error | Data erratic, intermittent or incorrect | | | BUS_Cruise_On_Switch, Cruise_Switch_Raw_Signal |
| 33 | 597 | Brake Switch | 0 | Brake Switch reading above normal range | Brake Switch Shorted High or Open Circuit or faulty sensor system | | 1602-E14 & E15 | Brake_Analog_Switch_Raw_Signal |
| 33 | 597 | Brake Switch | 1 | Brake Switch reading below normal range | Brake Switch Short To Ground or faulty sensor system | | 1602-E14 & E15 | Brake_Analog_Switch_Raw_Signal |
| 33 | 597 | Brake Switch | 2 | Brake Switch Inputs Do Not Match | High resistance in the wire harness, defective brake switch, or a defective Body Controller or defective ABS controller or Datalink | | 1602-E14 & E15 | Brake_Switch_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|---------------------------|-----|--|--|---|----------------|--------------------------|
| 33 | 597 | Brake Switch | 7 | Brake Switch Stuck Open Or Closed | Defective Brake Switch | | 1602-E14 & E15 | Brake_Switch_Signal |
| 33 | 597 | Brake Switch | 14 | Brake switch is stuck in the open or closed position | Defective brake switch | Occurs if the wheel based vehicle speed increases from 0kph to 72kph two times without the brake switch opening or decreases from 72kph to 0kph two times without the brake switch closing. | | Brake_Switch_Signal |
| 33 | 597 | Brake Switch | 14 | Brake switch inputs do not match | Occurs if there is a high resistance in the wire harness, defective brake switch or a defective Electronic Systems Controller (ESC). | Occurs if the comparison of the inputs indicates a mismatch in the analog and digital signals. | | Brake_Switch_Signal |
| 33 | 598 | Clutch Switch | 0 | Clutch Switch reading above normal range | Upper Clutch Switch Shorted High or Open Circuit or faulty sensor system | | 1600-B4 | Clutch_Switch_Raw_Signal |
| 33 | 598 | Clutch Switch | 1 | Clutch Switch reading below normal range | Upper Clutch Switch Short To Ground or faulty sensor system | | 1600-B4 | Clutch_Switch_Raw_Signal |
| 33 | 598 | Clutch Switch | 7 | Clutch Switch Stuck | Defective Upper Clutch Switch | | 1600-B4 | Clutch_Switch_Raw_Signal |
| 33 | 598 | Clutch Switch | 14 | Upper Clutch Switch stuck in the open or closed position | Defective upper clutch switch | Occurs if the vehicle speed increases from 0kph to 72kph without a change in state of the clutch switch. | | Clutch_Switch_Raw_Signal |
| 33 | 599 | Cruise Control Set Switch | 2 | Cruise SET /Resume Panel mounted switch error | Data erratic, intermittent or incorrect | | | BUS_Cruise_Set_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|------------------------------|-----|---|---|----------|---------------------|---------------------|
| 33 | 604 | Transmission Neutral Switch | 2 | Transmission Auto Neutral Enable Switch Error | Data erratic, intermittent or incorrect | | | Auto_Neutral_Switch |
| 33 | 608 | J1587/1708 Datalink | 9 | J1708 (J1587) Switch Data Link Lost | Faulty BC or Switch Data Link | | | |
| 33 | 611 | Virtual Fuse | 3 | Unexpected Connection | A connection has been made to an output that has no functionality assigned. | | | |
| 33 | 614 | Gauge Cluster Checksum | 14 | Global Broadcast Messages, J1939, proprietary, public bus (drivetrain) (address 255) has an unknown checksum fault. | | | | |
| 33 | 623 | Red Stop Lamp | 4 | Red Stop Lamp | Output shorted to ground | | | |
| 33 | 623 | Red Stop Lamp | 5 | Red Stop Lamp | Output open circuit | | | |
| 33 | 623 | Red Stop Lamp | 6 | Red Stop Lamp | Output overheat | | | |
| 33 | 624 | Amber Warning Lamp | 4 | Amber Warning Lamp | Output shorted to ground | | | |
| 33 | 624 | Amber Warning Lamp | 5 | Amber Warning Lamp | Output open circuit | | | |
| 33 | 624 | Amber Warning Lamp | 6 | Amber Warning Lamp | Output overheat | | | |
| 33 | 625 | Switch and Door Pod | 14 | Global Broadcast Messages, J1708, proprietary messages (escape PID) (address 255) has an unknown fault. | | | 1600-29, 1600-30 | |
| 33 | 626 | Engine Start Enable Device 1 | 5 | Fuel Heater Relay Under Current Or Open Circuit | Open Circuit in Fuel Heater Circuit | | | Fuel_Heater_Req |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|--|-----|---|---|--|---------------|--------------------------------------|
| 33 | 626 | Engine Start Enable Device 1 | 6 | Fuel Heater Relay Over Current | Short To Ground in Fuel Heater Circuit | | | Fuel_Heater_Req |
| 33 | 639 | Drivetrain Message Timeout | 9 | J1939 Drivetrain Data Link Lost | Faulty BC or Drivetrain Data Link | | | J1939DT_Root_Comm_Fail |
| 33 | 639 | Drivetrain Message Timeout | 14 | Failed to receive PGN 65535. | | | | |
| 33 | 639 | Drivetrain Message Timeout | 14 | Communication fault (from PP3 to ESC) | Datalink interrupted between ESC and Powerpack. | Check for open circuit or short in J1939 datalink. | | |
| 33 | 685 | Disengage Differential Lock Request - Front Axle 1 | 2 | Forward axle 1 diff lock switch error | Data erratic, intermittent or incorrect | Not available | Not available | Diff_Lock_1_Switch |
| 33 | 687 | Disengage Differential Lock Request - Rear Axle 1 | 2 | Forward Rear Diff Lock Switch Error | Faulty Switch Actuator or Microswitch for Forward Rear Diff Lock Switch | | | Diff_Lock_Switch, Diff_Lock_1_Switch |
| 33 | 688 | Disengage Differential Lock Request - Rear Axle 2 | 2 | Rear Rear Diff Lock Switch Error | Faulty Switch Actuator or Microswitch for Rear Rear Diff Lock Switch | | | Diff_Lock_2_Switch |
| 33 | 691 | Disengage Differential Lock Request - Central Rear | 2 | Power Divider Lock Switch Error | Faulty Switch Actuator or Microswitch for Power Divider Lock Switch | | | PDL_Lock_Switch |
| 33 | 829 | Left Fuel Level Sensor | 0 | Fuel Tank 1 Sensor reading above normal range | Fuel Tank 1 Sensor Shorted High or Open Circuit or faulty sensor system | Not available | 1600-B8 | Fuel_Sensor1_Raw_Signal |
| 33 | 829 | Left Fuel Level Sensor | 1 | Fuel Tank 1 Sensor reading below normal range | Fuel Tank 1 Sensor Short To Ground or faulty sensor system | Not available | 1600-B8 | Fuel_Sensor1_Raw_Signal |
| 33 | 830 | Right Fuel Level Sensor | 0 | Fuel Tank 2 Sensor reading above normal range | Fuel Tank 2 Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B9 | Fuel_Sensor2_Raw_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|---|-----|--|---|----------|----------|--|
| 33 | 830 | Right Fuel Level Sensor | 1 | Fuel Tank 2 Sensor reading below normal range | Fuel Tank 2 Sensor Short To Ground or faulty sensor system | | 1600-B9 | Fuel_Sensor2_Raw_Signal |
| 33 | 871 | Refrigerant Charge | 1 | AC - Service now Very low charge | Data valid but below normal operational range - most severe level | | | BC_RCD_Temp_In_Raw_Signal, BC_RCD_Temp_Out_Raw_Signal |
| 33 | 871 | Refrigerant Charge | 18 | AC - Service now low charge | Data valid but below normal operating range - moderately severe level | | | BC_RCD_Temp_In_Raw_Signal, BC_RCD_Temp_Out_Raw_Signal |
| 33 | 876 | Compressor Clutch Circuit | 5 | HVAC Compressor Clutch Engagement Undercurrent | Open in HVAC AC Compressor Clutch Circuit | | 1603-C | BC_RCD_AC_Comp_Clutch_Cmd |
| 33 | 876 | Compressor Clutch Circuit | 6 | HVAC Compressor Clutch Engagement Overcurrent | Short to Ground or Overload in HVAC AC Compressor Clutch Circuit | | 1603-C | BC_RCD_AC_Comp_Clutch_Cmd |
| 33 | 878 | Clearance, Side Marker, Identification Lamp Circuit (Black) | 5 | Trailer Marker Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Marker Lamp Circuit | | 1601-F14 | Trailer_Marker_Light |
| 33 | 878 | Clearance, Side Marker, Identification Lamp Circuit (Black) | 6 | Trailer Marker Lamp Relay Over Current | Short To Ground in Trailer Marker Lamp Circuit | | 1601-F14 | Trailer_Marker_Light |
| 33 | 879 | Left Turn Lamp Circuit (Yellow) | 5 | Trailer Left Turn Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Left Turn Lamp Circuit | | 1601-F13 | Trailer_Left_Light |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|-----|--|-----|--|--|--|---------------|---------------------------------|
| 33 | 879 | Left Turn Lamp Circuit (Yellow) | 6 | Trailer Left Turn Lamp Relay Over Current | Short To Ground in Trailer Left Turn Lamp Circuit | | 1601-F13 | Trailer_Left_Light |
| 33 | 880 | Stop Lamp Circuit (Red) | 5 | Stop Lights Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E5 | Stop_Relay_Cmd |
| 33 | 880 | Stop Lamp Circuit (Red) | 6 | Stop Lights Relay Overcurrent | Current above normal or grounded circuit | | 1601-E5 | Stop_Relay_Cmd |
| 33 | 881 | Right Turn Lamp Circuit (Green) | 5 | Trailer Right Turn Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Right Turn Lamp Circuit | | 1601-E15 | Trailer_Right_Light |
| 33 | 881 | Right Turn Lamp Circuit (Green) | 6 | Trailer Right Turn Lamp Relay Over Current | Short To Ground in Trailer Right Turn Lamp Circuit | | 1601-E15 | Trailer_Right_Light |
| 33 | 882 | Tail Lamp/License Plate Lamp Circuit (Brown) | 5 | Trailer License Plate Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer License Plate Lamp Circuit | | 1601-E10 | Trailer_Plate_Light |
| 33 | 882 | Tail Lamp/License Plate Lamp Circuit (Brown) | 6 | Trailer License Plate Lamp Relay Over Current | Short To Ground in Trailer License Plate Lamp Circuit | | 1601-E10 | Trailer_Plate_Light |
| 33 | 972 | Accelerator Interlock Switch | 2 | Accelerator Interlock Switch Error | Faulty Switch Actuator or Microswitch for Accelerator Interlock | Not available | Not available | Accelerator_Interlock_On_Switch |
| 33 | 972 | Accelerator Interlock Switch | 6 | Over current for Accelerator Interlock Switch Indicator | Over current or Short to Battery for the Accelerator Interlock Switch Indicator. | MSM Switch Indicator overcurrent fault | | |
| 33 | 973 | Engine Retarder Selection | 2 | Engine Retarder Level Selection Switch Error | Faulty Switch Actuator or Microswitch for Engine Retarder Level Select Switch | | | Comp_Brake_3_Switch |
| 33 | 980 | PTO Enable Switch | 2 | Engine PTO Switch Error | Data erratic, intermittent or incorrect | | | PTO_Enable_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---------------------------------------|-----|--|---|----------|---------|-------------------------------|
| 33 | 986 | Requested Percent Fan Speed | 2 | Engine Fan Switch Error | Faulty Switch Actuator or Microswitch for Engine Fan Switch | | | Fan_Ovrdr_Switch |
| 33 | 1043 | Internal Sensor Voltage Supply | 0 | Bias Voltage reading above normal range | Bias Voltage Circuit Shorted High | | | Bias_Voltage_Raw_Signal |
| 33 | 1043 | Internal Sensor Voltage Supply | 1 | Bias Voltage reading below normal range | Short To Ground in Bias Voltage Circuit | | | Bias_Voltage_Raw_Signal |
| 33 | 1044 | Hydraulic Pump Motor | 5 | Current below Normal or Open Circuited | Current below Normal or Open Circuited | | | Motor_Input_Raw_Signal |
| 33 | 1044 | Hydraulic Pump Motor | 4 | Voltage below Normal or Shorted to Low Source | Voltage below Normal or Shorted to Low Source | | | Motor_Input_Raw_Signal |
| 33 | 1044 | Hydraulic Pump Motor | 3 | Voltage above Normal or Shorted to High Source | Voltage above Normal or Shorted to High Source | | | Motor_Input_Raw_Signal |
| 33 | 1079 | Vref Sensor Supply Voltage | 0 | 5V Sensor Supply Above Normal Range | Data valid but above normal operational range - most severe level | | | Switched_5V_Sense_Raw_Signal |
| 33 | 1079 | Vref Sensor Supply Voltage | 1 | 5V Sensor Supply Below Normal Range | Data valid but below normal operational range - most severe level | | | Switched_5V_Sense_Raw_Signal |
| 33 | 1081 | Wait to Start Lamp | 4 | Wait to Start Lamp | Output shorted to ground | | | |
| 33 | 1081 | Wait to Start Lamp | 6 | Wait to Start Lamp | Output overheat | | | |
| 33 | 1087 | Service Brake Air Pressure Circuit #1 | 0 | Primary Air Tank Sensor reading above normal range | Primary Air Tank Sensor Shorted High or faulty sensor system | | 1600-B2 | Primary_Air_Sensor_Raw_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---------------------------------------|-----|---|---|---------------|---------------|---------------------------------|
| 33 | 1087 | Service Brake Air Pressure Circuit #1 | 1 | Primary Air Tank Sensor reading below normal range | Primary Air Tank Sensor Short To Ground or Open Circuit or faulty sensor system | | 1600-B2 | Primary_Air_Sensor_Raw_Signal |
| 33 | 1088 | Service Brake Air Pressure Circuit #2 | 0 | Secondary Air Tank Sensor reading above normal range | Secondary Air Tank Sensor Shorted High or faulty sensor system | | 1600-B3 | Secondary_Air_Sensor_Raw_Signal |
| 33 | 1088 | Service Brake Air Pressure Circuit #2 | 1 | Secondary Air Tank Sensor reading below normal range | Secondary Air Tank Sensor Short To Ground or Open Circuit or faulty sensor system | | 1600-B3 | Secondary_Air_Sensor_Raw_Signal |
| 33 | 1089 | Auxiliary Equipment Supply Pressure | 0 | Auxiliary Air Tank Sensor Reading Above Normal | Short to High in Air Pressure Auxiliary Sensor Circuit | | 1600-B2 | Auxiliary_Air_Sensor_Raw_Signal |
| 33 | 1089 | Auxiliary Equipment Supply Pressure | 1 | Auxiliary Air Tank Sensor Reading Below Normal | Short to Ground or Open in Air Pressure Auxiliary Sensor Circuit | | 1600-B2 | Auxiliary_Air_Sensor_Raw_Signal |
| 33 | 1231 | Body Address Claim/Message Timeout | 9 | J1939 Body Builder Data Link Lost | Faulty BC or Bodybuilder Data Link | | | J1939DT_Rcv_61441_xxx_011_Timer |
| 33 | 1231 | Body Address Claim/Message Timeout | 14 | Global Broadcast Messages, J1939, proprietary, private bus (body builder) (address 255) has an unknown fault. | | | | |
| 33 | 1238 | Traction Control Override Switch | 2 | ATC OFF-ROAD Switch Error | Faulty Switch Actuator or Micro switch for ATC OFF-ROAD Switch | Not available | Not available | ATC_Off_Road_Enable |
| 33 | 1378 | Change Oil Lamp | 4 | Change Oil Lamp | Output shorted to ground | | | |
| 33 | 1378 | Change Oil Lamp | 6 | Change Oil Lamp | Output overheat | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|---|---|----------|--------------------------------|
| 33 | 1382 | Fuel Filter (suction side) Differential Pressure | 14 | The filter between the fuel pump and the fuel tank is plugged. | Heavy build up of particulate matter in the fuel filter preventing fuel flow. | The detection has indicated a value of 51 on the fuel filter signal which indicates a severely restricted or plugged condition. | | Fuel_Filter_Plugged_In d_Cmd |
| 33 | 1547 | A/C Evaporator Temperature | 0 | HVAC Inlet Temp Sensor reading above normal range | HVAC Refrigerant Inlet Temperature Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B5 | BC_RCD_Temp_In_Raw_Signal |
| 33 | 1547 | A/C Evaporator Temperature | 1 | HVAC Inlet Temp Sensor reading below normal range | HVAC Refrigerant Inlet Temperature Sensor Short To Ground or faulty sensor system | | 1600-B5 | BC_RCD_Temp_In_Raw_Signal |
| 33 | 1548 | HVAC Duct Temperature | 0 | HVAC Outlet Temp Sensor reading above normal range | HVAC Refrigerant Outlet Temperature Sensor Shorted High or Open Circuit or faulty sensor system | | 1600-B13 | BC_RCD_Temp_Out_Raw_Signal |
| 33 | 1548 | HVAC Duct Temperature | 1 | HVAC Outlet Temp Sensor reading below normal range | HVAC Refrigerant Outlet Temperature Sensor Short To Ground or faulty sensor system | | 1600-B13 | BC_RCD_Temp_Out_Raw_Signal |
| 33 | 1552 | Operator Input device for Cab Climate Control | 2 | HVAC Control Head Temperature Mix DM1 | HVAC Motor in Wrong Position or Jammed | | | RCD_HVAC_Ctrl_Head_Diag_Signal |
| 33 | 1553 | HVAC Blower Motor Speed Adjustment | 0 | HVAC Blower Speed Analog Input reading above normal range | HVAC Blower Speed Control Shorted High or Open Circuit or faulty sensor system | | 1600-B15 | Front_AC_Blower_Speeded_Raw |
| 33 | 1553 | HVAC Blower Motor Speed Adjustment | 1 | HVAC Blower Speed Analog Input reading below normal range | HVAC Blower Speed Control Short To Ground or faulty sensor system | | 1600-B15 | Front_AC_Blower_Speeded_Raw |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|--|---|--|---------------|---------------------------------|
| 33 | 1653 | Vehicle Limiting Speed Governor Enable Switch | 2 | Vehicle Limiting Speed Governor Enable Switch Error | Faulty Switch Actuator or Microswitch for AVSL Switch | Not available | Not available | AVSL_On_Switch |
| 33 | 1653 | Vehicle Limiting Speed Governor Enable Switch | 6 | Over current for Vehicle Limiting Speed Governor Enable Switch Indicator | Over current or Short to Battery for the Vehicle Limiting Speed Governor Enable Switch Indicator. | MSM Switch Indicator overcurrent fault | | |
| 33 | 1660 | Engine Automatic Start Alarm | 5 | Remote Start Alarm Buzzer Relay Under Current Or Open Circuit | Open Circuit in Remote Start Alarm Buzzer Circuit | | | Remote_Start_Alarm_Buzzer_Relay |
| 33 | 1660 | Engine Automatic Start Alarm | 6 | Remote Start Alarm Buzzer Relay Over Current | Short To Ground in Remote Start Alarm Buzzer Circuit | | | Remote_Start_Alarm_Buzzer_Relay |
| 33 | 1709 | Transmission Controller Power Relay | 5 | PRNDL Pseudo ignition relay driver output Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E3 | PRNDL_Trans_Pseudo_Ignition_Cmd |
| 33 | 1709 | Transmission Controller Power Relay | 6 | PRNDL Pseudo ignition relay driver output overcurrent | Current above normal or grounded circuit | | 1601-E3 | PRNDL_Trans_Pseudo_Ignition_Cmd |
| 33 | 1716 | Retarder Selection, non-engine | 2 | Transmission Retarder Level Selection Switch Failure | Data erratic, intermittent or incorrect | | | Retarder_High_Switch |
| 33 | 1741 | Level Control Mode | 0 | Mode Selection Switch Damaged or Not Connected | Data Valid but Above Normal Range, Most Severe | Not available | Not available | SHCS_Switch_High_Position |
| 33 | 1741 | Level Control Mode | 1 | Possible ECU Malfunction | Data Valid, but Below Normal Range, Most Severe | Not available | Not available | SHCS_Switch_High_Position |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|----------------------------------|-----|--|--|---------------|---------|----------------------------------|
| 33 | 1747 | Kneeling Control Mode Request | 2 | Suspension Dump Switch Error | Faulty Switch Actuator or Microswitch for Suspension Dump Switch | | | Susp_Dump_Dump_Switch |
| 33 | 1755 | Lowering Control Mode Rear Axle | 5 | Suspension Dump Solenoid B Relay Under Current Or Open Circuit | Open Circuit in Suspension Dump Solenoid B Circuit | | | Susp_Dump_Solenoid_B_Cmd |
| 33 | 1755 | Lowering Control Mode Rear Axle | 6 | Suspension Dump Solenoid B Relay Over Current | Short To Ground in Suspension Dump Solenoid B Circuit | | | Susp_Dump_Solenoid_B_Cmd |
| 33 | 1756 | Lifting Control Mode Rear Axle | 5 | Suspension Dump Solenoid A Relay Under Current Or Open Circuit | Open Circuit in Suspension Dump Solenoid A Circuit | | | Susp_Dump_Solenoid_A_Cmd |
| 33 | 1756 | Lifting Control Mode Rear Axle | 6 | Suspension Dump Solenoid A Relay Over Current | Short To Ground in Suspension Dump Solenoid A Circuit | | | Susp_Dump_Solenoid_A_Cmd |
| 33 | 1820 | Ramp / Wheel Chair Lift Position | 5 | Wheelchair Lift Solenoid Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E1 | BUS_WheelChair_Lift_Solenoid_Cmd |
| 33 | 1820 | Ramp / Wheel Chair Lift Position | 6 | Wheelchair Lift Solenoid Relay Short To Ground | Current above normal or grounded circuit | | 1601-E1 | BUS_WheelChair_Lift_Solenoid_Cmd |
| 33 | 1837 | Convoy Driving Lamp Select | 6 | BO Drive Overcurrent | Current above normal or grounded circuit | Not available | 1603-K | BO_Drive_Cmd |
| 33 | 1840 | Rear Black Out Marker Select | 6 | BO Marker Overcurrent | Current above normal or grounded circuit | Not available | 1603-F | BO_Marker_Cmd |
| 33 | 1841 | Black Out Brake/Stop Lamp Select | 6 | BO Stop Overcurrent | Current above normal or grounded circuit | Not available | 1603-J | BO_Stop_Cmd |
| 33 | 2000 | Source Address 0 | 9 | ECM Data Link Comm. Failure | Faulty ECM or Drivetrain Data Link | | | J1939DT_Rcv_65265_xxx_000_Timer |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------------|-----|--|--|---------------|---------------|---------------------------------|
| 33 | 2000 | Source Address 0 | 19 | PTC1 (PGN 64892) not Received from Engine | ECM not Programmed for Aftertreatment, Faulty ECM, or Faulty Drivetrain Data Link | | | |
| 33 | 2003 | Source Address 3 | 9 | TCM Data Link Comm. Failure | Faulty TCM or Drivetrain Data Link | | | J1939DT_Rcv_61442_xxx_003_Timer |
| 33 | 2011 | Source Address 11 | 9 | ABS Data Link Comm. Failure | Faulty ABS Module or Drivetrain Data Link | | | J1939DT_Rcv_61441_xxx_011_Timer |
| 33 | 2023 | Gauge Cluster | 9 | EGC Data Link Comm. Failure | Faulty EGC or Drivetrain Data Link | | | J1939DT_Rcv_61184_033_023_Timer |
| 33 | 2040 | Auxiliary Switch Pack #1 | 9 | AGSP #1 Data Link Comm. Failure | Abnormal update rate | | | J1939DT_Rcv_61184_033_040_Timer |
| 33 | 2058 | Source Address 58 | 9 | Rear HVAC Data Link Communication Failure | Faulty Rear HVAC or Body Builder Data Link | | | J1939BB_Rcv_61217_058_033_Timer |
| 33 | 2058 | Source Address 58 | 14 | Rear HVAC Data Link Communication Failure | Faulty Rear HVAC or Body Builder Data Link | | | J1939BB_Rcv_61217_058_033_Timer |
| 33 | 2062 | Source Address 62 | 9 | Meritor Wabco Brake Controller Data Link Comm. Failure to BC | Faulty Meritor Wabco Brake Controller Module Data Link | Not available | Not available | J1939DT_Rcv_65103_xxx_062_Timer |
| 33 | 2225 | Remote Power Module #1 Fuse | 9 | RPM #1 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_225_Timer |
| 33 | 2225 | Remote Power Module #1 Fuse | 14 | Remote Power Module #1 (address 225) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_225_Timer |
| 33 | 2226 | Remote Power Module #2 Fuse | 9 | RPM #2 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_226_Timer |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-----------------------------|-----|--|--|----------|------|---------------------------------|
| 33 | 2226 | Remote Power Module #2 Fuse | 14 | Remote Power Module #2 (address 226) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_226_Timer |
| 33 | 2227 | Source Address 227 | 9 | RPM #3 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_227_Timer |
| 33 | 2227 | Source Address 227 | 14 | Remote Power Module #3 (address 227) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_227_Timer |
| 33 | 2228 | Remote Power Module #4 Fuse | 9 | RPM #4 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_228_Timer |
| 33 | 2228 | Remote Power Module #4 Fuse | 14 | Remote Power Module #4 (address 228) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_228_Timer |
| 33 | 2229 | Source Address 229 | 9 | RPM #5 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_229_Timer |
| 33 | 2229 | Source Address 229 | 14 | Remote Power Module #5 (address 229) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_229_Timer |
| 33 | 2230 | Source Address 230 | 9 | RPM #6 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_230_Timer |
| 33 | 2230 | Source Address 230 | 14 | Remote Power Module #6 (address 230) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_230_Timer |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|--|--|---|--------|-----------------------------------|
| 33 | 2231 | Remote Power Module #7 Fuse | 9 | RPM #7 Data Link Comm. Failure | Abnormal update rate | | | J1939BB_Rcv_65313_xxx_231_Timer |
| 33 | 2231 | Remote Power Module #7 Fuse | 14 | Remote Power Module #7 (address 231) has an address problem. | Drivetrain J1939 data link, an improperly addressed RPM module, or a missing RPM module that the BC is expecting | | | J1939BB_Rcv_65313_xxx_231_Timer |
| 33 | 2233 | Source Address 233 | 9 | Rear Driver Door Pod Data Link Comm. Failure | Faulty Rear Driver Door Pod Module or Switch Data Link | | | Door_Pod_Rear1_Stat us_Msg_Timer |
| 33 | 2234 | Remote Air Solenoid #2 Fuse | 9 | Rear Passenger Door Pod Data Link Comm. Failure | Faulty Rear Passenger Door Pod Module or Switch Data Link | | | Door_Pod_Rear2_Stat us_Msg_Timer |
| 33 | 2236 | Source Address 236 | 9 | Driver Door Pod Data Link Comm. Failure | Faulty Driver Door Pod Module or Switch Data Link | | | Door_Pod_Master_Stat us_Msg_Timer |
| 33 | 2237 | Source Address 237 | 9 | Passenger Door Pod Data Link Comm. Failure | Faulty Passenger Door Pod Module or Switch Data Link | | | Door_Pod_Front_Stat us_Msg_Timer |
| 33 | 2239 | Source Address 239 | 9 | HCM Data Link Comm. Failure | Faulty HCM or Drivetrain Data Link | | | J1939DT_Rcv_65241_xxx_003_Timer |
| 33 | 2239 | Source Address 239 | 14 | HCM Address Conflict | Drivetrain J1939 data link, an improperly addressed HCM, or a missing HCM that the BC is expecting | | | J1939DT_Rcv_65241_xxx_003_Timer |
| 33 | 2247 | Source Address 247 | 9 | Communication fault from PP3 to BC. | Private J1939 datalink problem (exceeded bandwidth). | BC has failed to receive heartbeat message from PowerPack E module. | | |
| 33 | 2361 | Tractor Rear High Mounted Work Lights Command | 2 | Work Light Switch Error | Faulty Switch Actuator or Microswitch for Work Light Switch | | | Work_Light_On_Switch |
| 33 | 2362 | Tractor Rear High Mounted Work Lights | 5 | Work Light Undercurrent | Open in Work Light Circuit | | 1603-G | Work_Light_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---------------------------------------|-----|------------------------------------|--|---------------|--------|--|
| 33 | 2362 | Tractor Rear High Mounted Work Lights | 6 | Work Light Overcurrent | Short To Ground or Overload in Work Light Circuit | | 1603-G | Work_Light_Cmd |
| 33 | 2368 | Left Turn Signal Lights | 5 | Left Front Turn Lamp Undercurrent | Open in Left Front Turn Signal Circuit | | 1603-B | LT_FT_Turn_Cmd |
| 33 | 2368 | Left Turn Signal Lights | 6 | Left Front Turn Lamp Overcurrent | Short To Ground or Overload in Left Front Turn Signal Circuit | | 1603-B | LT_FT_Turn_Cmd |
| 33 | 2370 | Right Turn Signal Lights | 5 | Right Front Turn Lamp Undercurrent | Open in Right Front Turn Signal Circuit | | 1603-A | RT_FT_Turn_Cmd |
| 33 | 2370 | Right Turn Signal Lights | 6 | Right Front Turn Lamp Overcurrent | Short To Ground or Overload in Right Front Turn Signal Circuit | | 1603-A | RT_FT_Turn_Cmd |
| 33 | 2372 | Left Stop Light | 5 | Left Rear Turn Lamp Undercurrent | Open in Left Rear Turn Signal Circuit | Not available | 1603-D | LT_RR_Turn_Cmd, Stop_Lights_Cmd |
| 33 | 2372 | Left Stop Light | 6 | Left Rear Turn Lamp Overcurrent | Short To Ground or Overload in Left Rear Turn Signal Circuit | Not available | 1603-D | LT_RR_Turn_Cmd, Stop_Lights_Cmd |
| 33 | 2374 | Right Stop Light | 5 | Right Rear Turn Lamp Undercurrent | Open in Right Rear Turn Signal Circuit | | 1603-M | RT_RR_Turn_Cmd |
| 33 | 2374 | Right Stop Light | 6 | Right Rear Turn Lamp Overcurrent | Short To Ground or Overload in Right Rear Turn Signal Circuit | | 1603-M | RT_RR_Turn_Cmd |
| 33 | 2378 | Tractor Marker Light | 5 | Park Lights Undercurrent | Open in Park Lights Circuit | | 1604-G | Park_Light_Cmd |
| 33 | 2378 | Tractor Marker Light | 6 | Park Lights Overcurrent | Short To Ground or Overload in Park Lights Circuit | | 1604-G | Park_Light_Cmd |
| 33 | 2387 | Tractor Front Fog Lights Command | 2 | Fog Light Switch Error | Faulty Switch Actuator or Microswitch for Fog Lights Switch | | | Fog_Light_Switch, Front_Fog_Light_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|---|--|---------------|---------------|--------------------------------|
| 33 | 2388 | Fog Light 1 command | 5 | Fog Lights Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1603-F | Fog_Light_Cmd |
| 33 | 2388 | Fog Light 1 command | 6 | Fog Lights Relay Overcurrent | Current above normal or grounded circuit | | 1603-F | Fog_Light_Cmd |
| 33 | 2389 | Rear Fog Light Command | 2 | Rear Fog Light Switch error | Faulty Switch Actuator or Microswitch for Rear Fog Lights Switch | Not available | Not available | Rear_Fog_Light_Switch_On |
| 33 | 2390 | Rear Fog Lights | 5 | Rear Fog Light Relay Under Current Or Open Circuit | Under Current Or Open Circuit in Rear Fog Light Relay Driver | Not available | Not available | Rear_Fog_Light_Cmd |
| 33 | 2390 | Rear Fog Lights | 6 | Rear Fog Lights Relay Overcurrent | Short circuit in Rear Fog Light Relay Driver | Not available | Not available | Rear_Fog_Light_Cmd |
| 33 | 2392 | Back Up Light and Alarm Horn | 5 | Reverse Lights Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E4 | Ext_Lamp_Test_Reverse_Lamp |
| 33 | 2392 | Back Up Light and Alarm Horn | 6 | Reverse Lights Relay Overcurrent | Current above normal or grounded circuit | | 1601-E4 | Ext_Lamp_Test_Reverse_Lamp |
| 33 | 2404 | Running Light | 5 | Running Light Control relay Under Current Or Open Circuit | Open Circuit in Running Lights Circuit | | 1601-F16 | Skirt_Light_Req |
| 33 | 2404 | Running Light | 6 | Running Light Control relay Over Current | Short To Ground in Running Lights Circuit | | 1601-F16 | Skirt_Light_Req |
| 33 | 2584 | Hydraulic Brake Pressure Warning State Circuit 1 | 5 | Current Below Normal or Open Circuited | Current Below Normal or Open Circuited | | | Pressure_Flow_Switch_Raw_Input |
| 33 | 2584 | Hydraulic Brake Pressure Warning State Circuit 1 | 4 | Voltage Below Normal or Shorted to Low Source | Voltage Below Normal or Shorted to Low Source | | | Pressure_Flow_Switch_Raw_Input |
| 33 | 2584 | Hydraulic Brake Pressure Warning State Circuit 1 | 3 | Voltage Above Normal or Shorted to High Source | Voltage Above Normal or Shorted to High Source | | | Pressure_Flow_Switch_Raw_Input |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|--|----------|----------|----------------------------|
| 33 | 2609 | Cab A/C Refrigerant Compressor Outlet Pressure | 0 | HVAC Pressure Sensor reading above normal range | HVAC Pressure Sensor Shorted High or faulty sensor system | | 1600-B12 | BC_RCD_Pressure_Raw_Signal |
| 33 | 2609 | Cab A/C Refrigerant Compressor Outlet Pressure | 1 | HVAC Pressure Sensor reading below normal range | HVAC Pressure Short To Ground or Open Circuit or faulty sensor system | | 1600-B12 | BC_RCD_Pressure_Raw_Signal |
| 33 | 2609 | Cab A/C Refrigerant Compressor Outlet Pressure | 7 | AC - Service Now. Fan Problem/Clogged Pipe | At the current operating ambient temperature the engine fan isn't working, one of the AC lines has become plugged or the system is over-charged. The compressor is shut off to prevent damage. | | | BC_RCD_Pressure_Raw_Signal |
| 33 | 2609 | Cab A/C Refrigerant Compressor Outlet Pressure | 16 | HVAC High Pressure Protection | HVAC Head Pressure exceeded 480 psi. Compressor shut off until next key cycle for system protection | | | |
| 33 | 2636 | Windshield Wiper Motor ON/OFF | 5 | Wiper On/Off Relay Under Current Or Open Circuit | Open Circuit in Wiper On/Off Circuit | | 1601-E7 | Wiper_Low_Speed_Relay_Cmd |
| 33 | 2636 | Windshield Wiper Motor ON/OFF | 6 | Wiper On/Off Relay Over Current | Short To Ground in Wiper On/Off Circuit | | 1601-E7 | Wiper_Low_Speed_Relay_Cmd |
| 33 | 2637 | Windshield Wiper Motor Speed | 5 | Wiper High/Low Relay Under Current Or Open Circuit | Open Circuit in Wiper High/Low Circuit | | 1601-E6 | Wiper_High_Speed_Relay_Cmd |
| 33 | 2637 | Windshield Wiper Motor Speed | 6 | Wiper High/Low Relay Over Current | Short To Ground in Wiper High/Low Circuit | | 1601-E6 | Wiper_High_Speed_Relay_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|---|---|----------|---------|-------------------------------------|
| 33 | 2641 | Horn | 5 | Electric Horn Undercurrent | Open in Electric Horn Circuit | | 1603-E | Elec_City_Horn_Cmd |
| 33 | 2641 | Horn | 6 | Electric Horn Overcurrent | Short To Ground or Overload in City Horn Circuit | | 1603-E | Elec_City_Horn_Cmd |
| 33 | 2642 | Mirror Heat 1 | 5 | Left Mirror Heat Undercurrent | Open in Left Mirror Heat Circuit | | 1603-H | Left_Mirror_Heat_Cmd |
| 33 | 2642 | Mirror Heat 1 | 6 | Left Mirror Heat Overcurrent | Short to Ground or Overload in Left Mirror Heat Circuit | | 1603-H | Left_Mirror_Heat_Cmd |
| 33 | 2653 | Headlamp Low Beam Left #1 | 5 | Left Low Beam Under Current | Open in Left Low Beam Circuit | | 1604-B | Left_Lowbeam_Cmd |
| 33 | 2653 | Headlamp Low Beam Left #1 | 6 | Left Low Beam Short To Ground | Short To Ground or Overload in Left Low Beam Circuit | | 1604-B | Left_Lowbeam_Cmd |
| 33 | 2655 | Headlamp Low Beam Right #1 | 5 | Right Low Beam Open Circuit | Open in Right Low Beam Circuit | | 1604-H | Right_Lowbeam_Cmd |
| 33 | 2655 | Headlamp Low Beam Right #1 | 6 | Right Low Beam Short To Ground | Short to Ground or Overload in Right Low Beam Circuit | | 1604-H | Right_Lowbeam_Cmd |
| 33 | 2796 | Transfer Case Selector Switch | 2 | Front Axle Switch Error | Data erratic, intermittent or incorrect | | | Xfer_Case_Fwd_Axle_Eng_Switch |
| 33 | 2819 | Park Interlock Error | 5 | Park Position Interlock Solenoid Output is Under Current Or Open Circuit. | Current below normal or open circuit | | 1601-E8 | Park_Pos_Unlock_Solenoid_Cmd |
| 33 | 2819 | Park Interlock Error | 6 | Park Position Interlock Solenoid Output is overcurrent. | Current above normal or grounded circuit | | 1601-E8 | Park_Pos_Unlock_Solenoid_Cmd |
| 33 | 3313 | Fifth Wheel Lock Couple Status Indicator | 5 | Fifth Wheel Jaw Unlock Solenoid 1 output is Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Fifth_Wheel_Jaw_Unlock_Solenoid_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|---|--|----------|------|-------------------------------------|
| 33 | 3313 | Fifth Wheel Lock Couple Status Indicator | 6 | Fifth Wheel Jaw Unlock Solenoid 1 output is Overcurrent | Short To Ground or Defective Solenoid | | | Fifth_Wheel_Jaw_Unlock_Solenoid_Cmd |
| 33 | 3314 | Fifth Wheel Release Control | 2 | Fifth Wheel Jaw Unlock Switch state is invalid | Data erratic, intermittent or incorrect | | | Fifth_Wheel_Jaw_Unlock_Switch |
| 33 | 3316 | Fifth Wheel Slider Lock Indicator | 5 | Fifth Wheel Slide Under Current Or Open Circuit | Open Circuit in Fifth Wheel Slide Circuit | | | Fifth_Wheel_Slide_Cmd |
| 33 | 3316 | Fifth Wheel Slider Lock Indicator | 6 | Fifth Wheel Slide Over Current | Short To Ground in Fifth Wheel Slide Circuit | | | Fifth_Wheel_Slide_Cmd |
| 33 | 3412 | Lock Status of Door 1 | 7 | Driver Door Lock Motor Failure | Driver Door Pod Module Has Shorted, Opened, or Jammed Solenoid | | | |
| 33 | 3415 | Lock Status of Door 2 | 7 | Passenger Door Lock Motor Failure | Passenger Door Pod Module Has Shorted, Opened, or Jammed Solenoid | | | |
| 33 | 3418 | Lock Status of Door 3 | 7 | Rear Driver Door Lock Motor failure | Rear Driver Door Pod Module Has Shorted, Opened, or Jammed Solenoid | | | |
| 33 | 3421 | Lock Status of Door 4 | 7 | Rear Passenger Door Lock Motor failure | Rear Passenger Door Pod Module Has Shorted, Opened, or Jammed Solenoid | | | |
| 33 | 3452 | Enable Switch - Transmission input shaft PTO 1 | 2 | Transmission PTO A Switch Error | Faulty Switch Actuator or Microswitch for Transmission PTO A Switch | | | PTOa_On_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|---|---|----------|------|---|
| 33 | 3452 | Enable Switch - Transmission input shaft PTO 1 | 2 | PTO Engagement Switch Error | Faulty Switch Actuator or Microswitch for Transmission PTO A Switch | | | TEM_PTO_Engagement_Switch_On |
| 33 | 3453 | Enable Switch - Transmission input shaft PTO 2 | 2 | Transmission PTO B Switch Error | Faulty Switch Actuator or Microswitch for Transmission PTO B Switch | | | PTOb_On_Switch |
| 33 | 3455 | Enable Switch - Transfer case output shaft PTO | 2 | Transfer Case Switch Error | Data erratic, intermittent or incorrect | | | Transfer_Case_Blower_Switch |
| 33 | 3455 | Enable Switch - Transfer case output shaft PTO | 2 | Transfer Case PTO Switch Error | Data erratic, intermittent or incorrect | | | Xfer_Case_PTO_Eng_Switch |
| 33 | 3456 | Engagement Consent - Transmission input shaft PTO 1 | 5 | Transmission PTO A Solenoid Relay Under Current Or Open Circuit | Open Circuit in Transmission PTO A Solenoid Circuit | | | PTO1_Air_Solenoid_Cmd,PTOa_Air_Solenoid_Cmd |
| 33 | 3456 | Engagement Consent - Transmission input shaft PTO 1 | 6 | Transmission PTO A Solenoid Relay Over Current | Short To Ground in Transmission PTO A Solenoid Circuit | | | PTO1_Air_Solenoid_Cmd,PTOa_Air_Solenoid_Cmd |
| 33 | 3457 | Engagement Consent - Transmission input shaft PTO 2 | 5 | Transmission PTO B Solenoid Relay Under Current Or Open Circuit | Open Circuit in Transmission PTO B Solenoid Circuit | | | PTOb_Air_Solenoid_Cmd |
| 33 | 3457 | Engagement Consent - Transmission input shaft PTO 2 | 6 | Transmission PTO B Solenoid Relay Over Current | Short To Ground in Transmission PTO B Solenoid Circuit | | | PTOb_Air_Solenoid_Cmd |
| 33 | 3461 | Engagement Status - Transmission input shaft PTO 2 | 5 | PTO Air Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_PTO_Air_Solenoid_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|--|---|----------|----------|---------------------------|
| 33 | 3461 | Engagement Status - Transmission input shaft PTO 2 | 6 | PTO Air Solenoid Overcurrent | Current above normal or grounded circuit | | | TEM_PTO_Air_Solenoid_Cmd |
| 33 | 3695 | Diesel Particulate Filter Regeneration Inhibit Switch | 2 | Regen Inhibit Switch Error | Faulty Switch Actuator or Microswitch for Regen Inhibit Switch | | | |
| 33 | 3696 | Diesel Particulate Filter Regeneration Switch | 5 | Open Circuit in Regen Switch Indicator Circuit | Open Circuit in the Regen Switch Indicator Circuit. | | | Regen_Switch_Ind_Cmd |
| 33 | 3696 | Diesel Particulate Filter Regeneration Switch | 6 | Over current for Parked Regen Switch Indicator | Over current or Short to Battery for the Parked Regen Switch Indicator. | | | Regen_Switch_Ind_Cmd |
| 33 | 3696 | Diesel Particulate Filter Regeneration Switch | 2 | Parked Regen Switch Error | Faulty Switch Actuator or Microswitch for Parked Regen Switch | | | Regen_Switch_On |
| 33 | 3697 | Diesel Particulate Filter Lamp | 5 | Particulate Trap Lamp Relay Under Current Or Open Circuit | Open Circuit in Particulate Trap Lamp Circuit | | | Particulate_Trap_Ind_Cmd |
| 33 | 3697 | Diesel Particulate Filter Lamp | 6 | Particulate Trap Lamp Relay Over Current | Short to Ground in Particulate Trap Lamp Circuit | | | Particulate_Trap_Ind_Cmd |
| 33 | 3698 | Exhaust System High Temperature Lamp Command | 5 | Exhaust System High Temperature Lamp Command Under Current Or Open Circuit | Open Circuit in Exhaust System High Temperature Circuit | | | Exhaust_High_Temp_Ind_Cmd |
| 33 | 3698 | Exhaust System High Temperature Lamp Command | 6 | Exhaust System High Temperature Lamp Command Over Current | Short to Ground in Exhaust System High Temperature Circuit | | | Exhaust_High_Temp_Ind_Cmd |
| 33 | 3950 | Air Horn | 5 | Air Horn Undercurrent | Open in Air Horn Circuit | | 1602-E12 | Air_Horn_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|--|---|----------|----------|-------------------------|
| 33 | 3950 | Air Horn | 6 | Air Horn Overcurrent | Short To Ground or Overload in Air Horn Circuit | | 1602-E12 | Air_Horn_Cmd |
| 33 | 3952 | Air Shield Light | 6 | Air Shield Lighting Overcurrent | Short To Ground or Overload in Air Shield Light Circuit | | 1604-F | Air_Shield_Lights_Cmd |
| 33 | 3957 | Auxiliary Transmission Constant Supply Actuator | 5 | Auxiliary Transmission Solenoid B (Constant Supply) output is Under Current Or Open Circuit. | Current below normal or open circuit | | | Aux_Xmsn_Solenoid_B_Cmd |
| 33 | 3957 | Auxiliary Transmission Constant Supply Actuator | 6 | Auxiliary Transmission Solenoid B (Constant Supply) output is overcurrent. | Current above normal or grounded circuit | | | Aux_Xmsn_Solenoid_B_Cmd |
| 33 | 3958 | Auxiliary Transmission High Range Actuator | 5 | Auxiliary Transmission Solenoid C (High) Output is Under Current Or Open Circuit. | Current below normal or open circuit | | | Aux_Xmsn_Solenoid_C_Cmd |
| 33 | 3958 | Auxiliary Transmission High Range Actuator | 6 | Auxiliary Transmission Solenoid C (High) output is overcurrent. | Current above normal or grounded circuit | | | Aux_Xmsn_Solenoid_C_Cmd |
| 33 | 3959 | Auxiliary Transmission Neutral Actuator | 5 | Auxiliary Transmission Solenoid A (Neutral) output is Under Current Or Open Circuit. | Current below normal or open circuit | | | Aux_Xmsn_Solenoid_A_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|--|--|----------|---------|-------------------------|
| 33 | 3959 | Auxiliary Transmission Neutral Actuator | 6 | Auxiliary Transmission Solenoid A (Neutral) output is overcurrent. | Current above normal or grounded circuit | | | Aux_Xmsn_Solenoid_A_Cmd |
| 33 | 3960 | Auxiliary Transmission Range Switch | 2 | Auxiliary Transmission High/Low Switch state is invalid. | Data erratic, intermittent or incorrect | | | Aux_Xmsn_Hi_Switch |
| 33 | 3961 | Body Equipment Hydraulic Power Auxiliary Pump Inhibit Command | 5 | TEM Epump Inhibit Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E1 | TEM_EPump_Inhibit_Relay |
| 33 | 3961 | Body Equipment Hydraulic Power Auxiliary Pump Inhibit Command | 6 | TEM Epump Inhibit Relay Over Current | Current above normal or grounded circuit | | 1601-E1 | TEM_EPump_Inhibit_Relay |
| 33 | 3962 | Bus Amber Signal Light 1 | 5 | Left Front Amber PWL Undercurrent | Current below normal or open circuit | | 1603-C | BUS_LF_Amber_PWL_Cmd |
| 33 | 3962 | Bus Amber Signal Light 1 | 6 | Left Front Amber PWL Overcurrent | Current above normal or grounded circuit | | 1603-C | BUS_LF_Amber_PWL_Cmd |
| 33 | 3963 | Bus Amber Signal Light 2 | 5 | Right Front Amber PWL Undercurrent | Current below normal or open circuit | | 1604-J | BUS_RF_Amber_PWL_Cmd |
| 33 | 3963 | Bus Amber Signal Light 2 | 6 | Right Front Amber PWL Overcurrent | Current above normal or grounded circuit | | 1604-J | BUS_RF_Amber_PWL_Cmd |
| 33 | 3964 | Bus Amber Signal Light 3 | 5 | Left Rear Amber PWL Undercurrent | Current below normal or open circuit | | 1603-G | BUS_LR_Amber_PWL_Cmd |
| 33 | 3964 | Bus Amber Signal Light 3 | 6 | Left Rear Amber PWL Overcurrent | Current above normal or grounded circuit | | 1603-G | BUS_LR_Amber_PWL_Cmd |
| 33 | 3965 | Bus Amber Signal Light 4 | 5 | Right Rear Amber PWL Undercurrent | Current below normal or open circuit | | 1603-K | BUS_RR_Amber_PWL_Cmd |
| 33 | 3965 | Bus Amber Signal Light 4 | 6 | Right Rear Amber PWL Overcurrent | Current above normal or grounded circuit | | 1603-K | BUS_RR_Amber_PWL_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|-------------------------------------|-----|--|--|----------|----------|------------------------------------|
| 33 | 3966 | Bus Crossing Gate | 5 | Crossing Gate output is undercurrent. | Current below normal or open circuit | | 1602-E12 | BUS_Crossing_Gate_Cmd |
| 33 | 3966 | Bus Crossing Gate | 6 | Crossing Gate output is overcurrent. | Current above normal or grounded circuit | | 1602-E12 | BUS_Crossing_Gate_Cmd |
| 33 | 3967 | Bus Passenger Door Close Relay | 5 | Bus Entrance Door Close Relay Driver Output is Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E9 | BUS_Door_Close_Cmd |
| 33 | 3967 | Bus Passenger Door Close Relay | 6 | Bus Entrance Door Close Relay Driver Output is overcurrent | Current above normal or grounded circuit | | 1601-E9 | BUS_Door_Close_Cmd |
| 33 | 3969 | Bus Passenger Door Control Switch 2 | 0 | Bus Entrance Door Steering Wheel Switch Input Above Normal Range | Bus Door Control Switches Circuit Open or Shorted High | | 1600-B16 | BUS_PWL_And_Door_Switch_Raw_Signal |
| 33 | 3969 | Bus Passenger Door Control Switch 2 | 1 | Bus Entrance Door Steering Wheel Switch Input Below Normal Range | Short To Ground in Bus Door Control Switches Circuit | | 1600-B16 | BUS_PWL_And_Door_Switch_Raw_Signal |
| 33 | 3970 | Bus Passenger Door Open Relay | 5 | Bus Entrance Door Open Relay Driver Output is Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E13 | BUS_Door_Open_Cmd |
| 33 | 3970 | Bus Passenger Door Open Relay | 6 | Bus Entrance Door Open Relay Driver Output is overcurrent | Current above normal or grounded circuit | | 1601-E13 | BUS_Door_Open_Cmd |
| 33 | 3971 | Bus Red Signal Light 1 | 5 | Left Front Red PWL Undercurrent | Current below normal or open circuit | | 1603-H | BUS_LF_Red_PWL_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|------------------------|-----|--|---|----------|---------|----------------------------|
| 33 | 3971 | Bus Red Signal Light 1 | 6 | Left Front Red PWL Overcurrent | Current above normal or grounded circuit | | 1603-H | BUS_LF_Red_PWL_Cmd |
| 33 | 3972 | Bus Red Signal Light 2 | 5 | Right Front Red PWL Undercurrent | Current below normal or open circuit | | 1603-F | BUS_RF_Red_PWL_Cmd |
| 33 | 3972 | Bus Red Signal Light 2 | 6 | Right Front Red PWL Overcurrent | Current above normal or grounded circuit | | 1603-F | BUS_RF_Red_PWL_Cmd |
| 33 | 3973 | Bus Red Signal Light 3 | 5 | Left Rear Red PWL Undercurrent | Current below normal or open circuit | | 1603-J | BUS_LR_Red_PWL_Cmd |
| 33 | 3973 | Bus Red Signal Light 3 | 6 | Left Rear Red PWL Overcurrent | Current above normal or grounded circuit | | 1603-J | BUS_LR_Red_PWL_Cmd |
| 33 | 3974 | Bus Red Signal Light 4 | 5 | Right Rear Red PWL Undercurrent | Current below normal or open circuit | | 1603-L | BUS_RR_Red_PWL_Cmd |
| 33 | 3974 | Bus Red Signal Light 4 | 6 | Right Rear Red PWL Overcurrent | Current above normal or grounded circuit | | 1603-L | BUS_RR_Red_PWL_Cmd |
| 33 | 3975 | Bus Stop Arm | 5 | Bus Stop Arm Output is Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E2 | BUS_Stop_Arm_Cmd |
| 33 | 3975 | Bus Stop Arm | 6 | Bus Stop Arm Output is over current | Current above normal or grounded circuit | | 1601-E2 | BUS_Stop_Arm_Cmd |
| 33 | 3976 | Cab Dome Light 1 | 5 | Cab Dome Light Open Circuit | Open in Cab Dome Light Circuit | | 1604-J | Dome_Light_Cmd |
| 33 | 3976 | Cab Dome Light 1 | 6 | Cab Dome Light Short To Ground | Short To Ground or Overload in Cab Dome Light Circuit | | 1604-J | Dome_Light_Cmd |
| 33 | 3977 | Cab Dome Light 2 | 5 | Sleeper Dome Light Relay Under Current Or Open Circuit | Open Circuit in Sleeper Dome Light Circuit | | 1601-F2 | Sleeper_Cab_Dome_Light_Req |
| 33 | 3977 | Cab Dome Light 2 | 6 | Sleeper Dome Light Over Current | Short To Ground in Sleeper Dome Light Circuit | | 1601-F2 | Sleeper_Cab_Dome_Light_Req |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|--|----------|---------|--------------------------------|
| 33 | 3978 | Cab Dome Light 2 Switch | 2 | Sleeper Dome / Floor Search Light Switch Error | Faulty Switch Actuator or Microswitch for Sleeper Dome / Floor Search Light Switch | | | Floor_Lights_Cab_Switch |
| 33 | 3979 | Cab Floor Light | 5 | Floor Lights Relay Under Current Or Open Circuit | Open Circuit in Floor Light Circuit | | 1601-E5 | Floor_Search_Lights_Req |
| 33 | 3979 | Cab Floor Light | 6 | Floor Lights Relay Over Current | Short To Ground in Floor Light Circuit | | 1601-E5 | Floor_Search_Lights_Req |
| 33 | 3981 | Cab HVAC Mode Control Actuator | 2 | HVAC Control Head Mode Fault DM1 | HVAC Motor in Wrong Position or Jammed | | | |
| 33 | 3982 | Cab HVAC Rear Blower Speed Control Switch | 2 | HVAC Rear Blower Speed Control Switch Error | Faulty Switch Actuator or Microswitch for HVAC Rear Blower Speed Control Switch | | | Rear_HVAC_Blower_UP |
| 33 | 3983 | Cab HVAC Rear Temperature Control Switch | 2 | Rear HVAC Temperature Control Switch Error | Faulty Switch Actuator or Microswitch for Rear HVAC Temperature Control Switch | | | Rear_HVAC_Temp_UP |
| 33 | 3984 | Cab HVAC Recirculation Door Control Actuator | 2 | HVAC Control Head Air Inlet DM1 | HVAC Motor in Wrong Position or Jammed | | | |
| 33 | 3985 | Cab HVAC System Controller | 9 | HVAC Control Head Circuit Failed To Communicate With the Body Controller | Abnormal update rate | | | RCD_HVAC_Ctrl_Head_Diag_Signal |
| 33 | 3987 | Compression Brake Enable Switch Indicator Lamp | 5 | Compression Brake Indicator output is Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E4 | Comp_Brake_LED_Ind_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|---|----------|----------|------------------------------|
| 33 | 3987 | Compression Brake Enable Switch Indicator Lamp | 6 | Compression Brake Indicator is over current | Current above normal or grounded circuit | | 1601-E4 | Comp_Brake_LED_Ind_Cmd |
| 33 | 3988 | Door 1 Control Module | 7 | Driver Door Pod Module Failure | Defective Driver Door Pod Module | | | Door_Pod_Master_MF_Signal |
| 33 | 3989 | Door 1 Window Motor | 7 | Driver Window Motor Failure | Driver Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Master_WM_Signal |
| 33 | 3990 | Door 2 Control Module | 7 | Passenger Door Pod Module Failure | Defective Passenger Door Pod Module | | | Door_Pod_Front_MF_Signal |
| 33 | 3991 | Door 2 Window Motor | 7 | Passenger Window Motor Failure | Passenger Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Front_WM_Signal |
| 33 | 3992 | Door 3 Control module | 7 | Rear Driver Door Pod Module Failure | Defective Rear Driver Door Pod Module | | | Door_Pod_Rear_1_MF_Signal |
| 33 | 3993 | Door 3 Window Motor | 7 | Rear Driver Window Motor Failure | Rear Driver Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Rear_1_WM_Signal |
| 33 | 3994 | Door 4 Control Module | 7 | Rear Passenger Door Pod Module Failure | Defective Rear Passenger Door Pod Module | | | Door_Pod_Rear_2_MF_Signal |
| 33 | 3995 | Door 4 Window Motor | 7 | Rear Passenger Window Motor Failure | Rear Passenger Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Rear_2_WM_Signal |
| 33 | 3997 | Electrical Accessory Power Relay | 5 | Electrical Accessory Request Relay Under Current Or Open Circuit | Open Circuit in Electrical Accessory Request Circuit | | 1601-E11 | Electrical_Accessory_Request |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|------------------------------------|-----|--|---|----------|----------|------------------------------|
| 33 | 3997 | Electrical Accessory Power Relay | 6 | Electrical Accessory Request Relay Over Current | Short To Ground in Electrical Accessory Request Circuit | | 1601-E11 | Electrical_Accessory_Request |
| 33 | 3998 | Electrical Load Shed OFF | 5 | Load Shed OFF Relay Under Current Or Open Circuit | Open Circuit in Load Shed OFF Circuit | | 1601-F7 | Load_Shed_Power_Off_RD_Cmd |
| 33 | 3998 | Electrical Load Shed OFF | 6 | Load Shed OFF Relay Over Current | Short To Ground in Load Shed OFF Circuit | | 1601-F7 | Load_Shed_Power_Off_RD_Cmd |
| 33 | 3999 | Electrical Load Shed ON | 5 | Load Shed ON Relay Under Current Or Open Circuit | Open Circuit in Load Shed ON Circuit | | 1601-F6 | Load_Shed_Power_On_RD_Cmd |
| 33 | 3999 | Electrical Load Shed ON | 6 | Load Shed ON Relay Over Current | Short To Ground in Load Shed ON Circuit | | 1601-F6 | Load_Shed_Power_On_RD_Cmd |
| 33 | 4000 | Engine Exhaust Brake Enable Switch | 2 | Retarder Enable - Brake Assist On/Off switch failure | Data erratic, intermittent or incorrect | | | Exhaust_Brake_Switch |
| 33 | 4002 | Engine Remote Start | 6 | TEM Engine Crank Relay Over Current | Current above normal or grounded circuit | | | TEM_Engine_Crank_Cmd |
| 33 | 4003 | Engine Remote Stop | 5 | TEM Engine Stop Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E2 | TEM_Engine_Stop_Relay_Cmd |
| 33 | 4003 | Engine Remote Stop | 6 | TEM Engine Stop Relay Over Current | Current above normal or grounded circuit | | 1601-E2 | TEM_Engine_Stop_Relay_Cmd |
| 33 | 4004 | Exterior Lamp Check Switch | 2 | Exterior Lamp Check Switch Error | Data erratic, intermittent or incorrect | | | BUS_ELC_On_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--------------------------------------|-----|--|--|----------|----------|------------------------------|
| 33 | 4007 | Fifth Wheel Slide Lock Switch | 2 | Fifth Wheel Slide Switch Error | Faulty Switch Actuator or Microswitch for Fifth Wheel Slide Switch | | | Fifth_Wheel_Slide_Switch |
| 33 | 4008 | Fog Light 2 | 5 | Right Fog Light Undercurrent | Open in Right Fog Light Circuit | | 1603-K | Right_Gen2_Fog_Light_Cmd |
| 33 | 4008 | Fog Light 2 | 6 | Right Fog Light Overcurrent | Short To Ground or Overload in Right Fog Light Output Circuit | | 1603-K | Right_Gen2_Fog_Light_Cmd |
| 33 | 4009 | Fuel Filter Fuel Heater Relay | 5 | Fuel Heater Relay Under Current Or Open Circuit | Open Circuit in Fuel Heater Circuit | | 1601-F12 | Fuel_Heater_Req |
| 33 | 4009 | Fuel Filter Fuel Heater Relay | 6 | Fuel Heater Relay Over Current | Short To Ground in Fuel Heater Circuit | | 1601-F12 | Fuel_Heater_Req |
| 33 | 4010 | Fuel Tank Transfer Pump | 5 | Fuel Transfer Pump Relay Under Current Or Open Circuit | Open Circuit in Fuel Transfer Pump Circuit | | 1601-F11 | Fuel_Transfer_Pump_Relay_Cmd |
| 33 | 4010 | Fuel Tank Transfer Pump | 6 | Fuel Transfer Pump Relay Short To Ground | Short To Ground in Fuel Transfer Pump Circuit | | 1601-F11 | Fuel_Transfer_Pump_Relay_Cmd |
| 33 | 4011 | Headlamp 1 High Beam | 5 | Left High Beam Open Circuit | Open in Left High Beam Circuit | | 1604-C | Left_Highbeam_Cmd |
| 33 | 4011 | Headlamp 1 High Beam | 6 | Left High Beam Short To Ground | Short To Ground or Overload in Left High Beam Circuit | | 1604-C | Left_Highbeam_Cmd |
| 33 | 4012 | Headlamp 2 High Beam | 5 | Right High Beam Open Circuit | Open in Right High Beam Circuit | | 1604-K | Right_Highbeam_Cmd |
| 33 | 4012 | Headlamp 2 High Beam | 6 | Right High Beam Short To Ground | Short To Ground or Overload in Right High Beam Circuit | | 1604-K | Right_Highbeam_Cmd |
| 33 | 4014 | High Current Auxiliary Load Switch 1 | 2 | High Current Load Switch Error | Data erratic, intermittent or incorrect | | | High_Current_Load_Switch |
| 33 | 4016 | High Current Auxiliary Power Relay 1 | 5 | High Current Load Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E16 | High_Current_Load_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|---|--|----------|----------|-----------------------------|
| 33 | 4016 | High Current Auxiliary Power Relay 1 | 6 | High Current Load Overcurrent | Current above normal or grounded circuit | | 1601-E16 | High_Current_Load_Cmd |
| 33 | 4022 | Lift Gate Power Control Enable | 5 | Lift Gate Enable Undercurrent | Current below normal or open circuit | | 1603-J | Lift_Gate_Enable_Cmd |
| 33 | 4022 | Lift Gate Power Control Enable | 6 | Lift Gate Enable Overcurrent | Current above normal or grounded circuit | | 1603-J | Lift_Gate_Enable_Cmd |
| 33 | 4023 | Lift Gate Power Control Switch | 2 | Lift Gate Switch Error | Data erratic, intermittent or incorrect | | | Lift_Gate_Enable_Switch |
| 33 | 4024 | Marker Light Interrupt Switch | 2 | Marker Light Interrupt Switch Failure | Data erratic, intermittent or incorrect | | | Marker_Interrupt_Switch |
| 33 | 4026 | Mirror Heat 2 | 5 | Right Mirror Heat Undercurrent | Open in Right Mirror Heat Circuit | | 1603-L | Right_Mirror_Heat_Cmd |
| 33 | 4026 | Mirror Heat 2 | 6 | Right Mirror Heat Overcurrent | Short To Ground or Overload in Right Mirror Heat Circuit | | 1603-L | Right_Mirror_Heat_Cmd |
| 33 | 4028 | Service Brake Circuit 1 Air Tank Drain Valve | 5 | Service Brake Circuit 1 Air Tank Drain Valve Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Hmphry_Vlve_Prim_Tk_Sol_Cmd |
| 33 | 4028 | Service Brake Circuit 1 Air Tank Drain Valve | 6 | Service Brake Circuit 1 Air Tank Drain Valve Solenoid Short To Ground | Current above normal or grounded circuit | | | Hmphry_Vlve_Prim_Tk_Sol_Cmd |
| 33 | 4029 | Service Brake Circuit 1 Air Tank Drain Valve Switch | 2 | Service Brake Circuit 1 Air Tank Drain Switch Error | Data erratic, intermittent or incorrect | | | Hmphry_Vlve_Prim_Tk_Open |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|---|----------|----------|---------------------------------|
| 33 | 4030 | Service Brake Circuit 2 Air Tank Drain Valve | 5 | Service Brake Circuit 2 Air Tank Drain Valve Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Hmphry_Vlve_Sec_Tk _Sol_Cmd |
| 33 | 4030 | Service Brake Circuit 2 Air Tank Drain Valve | 6 | Service Brake Circuit 2 Air Tank Drain Valve Solenoid Short To Ground | Current above normal or grounded circuit | | | Hmphry_Vlve_Sec_Tk _Sol_Cmd |
| 33 | 4031 | Service Brake Supply Air Tank Drain Valve | 5 | Service Brake Supply Air Tank Drain Valve Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Hmphry_Vlve_Wet_Tk _Sol_Cmd |
| 33 | 4031 | Service Brake Supply Air Tank Drain Valve | 6 | Service Brake Supply Air Tank Drain Valve Solenoid Short To Ground | Current above normal or grounded circuit | | | Hmphry_Vlve_Wet_Tk _Sol_Cmd |
| 33 | 4032 | Service Brake Supply Air Tank Drain Valve Switch | 2 | Service Brake Supply Air Tank Drain Valve Switch Error | Data erratic, intermittent or incorrect | | | Hmphry_Vlve_Wet_Tk _Open |
| 33 | 4033 | Sleeper Remote - Start/Stop Enable Command | 5 | Sleeper Control Enable Relay Under Current or Open Circuit | Current below normal or open circuit | | | |
| 33 | 4033 | Sleeper Remote - Start/Stop Enable Command | 6 | Sleeper Control Enable Relay Over Current | Short To Ground in Sleeper Control Enable Circuit | | | |
| 33 | 4038 | Snow Plow Forward Lighting Relay 2 | 5 | Right Plow Light Relay Under Current Or Open Circuit | Current below normal or open circuit | | 1601-F16 | Right_Plow_Lights_Rel ay_Req |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|--|-----|--|--|----------|----------|---|
| 33 | 4038 | Snow Plow Forward Lighting Relay 2 | 6 | Right Plow Light Relay Circuit Short To Ground | Current above normal or grounded circuit | | 1601-F16 | Right_Plow_Lights_Relay_Req |
| 33 | 4039 | Snow Plow Forward Lighting Relay 1 | 5 | Left Plow Light Relay Circuit Under Current Or Open Circuit | Current below normal or open circuit | | 1601-F12 | Left_Plow_Lights_Relay_Req |
| 33 | 4039 | Snow Plow Forward Lighting Relay 1 | 6 | Left Plow Light Relay Circuit Short To Ground | Current above normal or grounded circuit | | 1601-F12 | Left_Plow_Lights_Relay_Req |
| 33 | 4040 | Snow Plow Lighting Mode Switch | 2 | Snow Plow Switch Error | Data erratic, intermittent or incorrect | | | Plow_Lights_Switch |
| 33 | 4041 | Software Loop Time Exceeded | 14 | Software Loop Time Exceeded in the Body Controller, Internal Fault | Software Configuration Too Big | | | LoopTime_OK |
| 33 | 4042 | Trailer Auxiliary Power Switch | 2 | Trailer Auxiliary Power Switch Error | Faulty Switch Actuator or Microswitch for Auxiliary Trailer Switch | | | EGC_Digital_Input_1 |
| 33 | 4043 | Transfer Case Front Driveline Actuator | 5 | Transfer Case Front Driveline Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_D_Cmd |
| 33 | 4043 | Transfer Case Front Driveline Actuator | 6 | Transfer Case Front Driveline Solenoid Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_D_Cmd |
| 33 | 4044 | Transfer Case High Range Actuator | 5 | Transfer Case High Range Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_C_Cmd, MATV_Xfer_Case_High_Sol_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|------|---|-----|---|--|----------|------|---|
| 33 | 4044 | Transfer Case High Range Actuator | 6 | Transfer Case High Range Solenoid Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_C_Cmd, MATV_Xfer_Case_High_Sol_Cmd |
| 33 | 4045 | Transfer Case Low Range Actuator | 5 | Transfer Case Low Range Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_A_Cmd, MATV_Xfer_Case_Low_Sol_Cmd |
| 33 | 4045 | Transfer Case Low Range Actuator | 6 | Transfer Case Low Range Solenoid Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_A_Cmd, MATV_Xfer_Case_Low_Sol_Cmd |
| 33 | 4046 | Transfer Case Neutral Actuator | 5 | Transfer Case Neutral Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_B_Cmd, MATV_Xfer_Case_Neutral_Sol_Cmd |
| 33 | 4046 | Transfer Case Neutral Actuator | 6 | Transfer Case Neutral Solenoid Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_B_Cmd, MATV_Xfer_Case_Neutral_Sol_Cmd |
| 33 | 4047 | Transfer Case Output Shaft PTO Actuator | 5 | Transfer Case Output Shaft PTO Actuator Under Current Or Open Circuit | Current below normal or open circuit | | | SSpd_Xfer_Case_NC_Sol_Cmd |
| 33 | 4047 | Transfer Case Output Shaft PTO Actuator | 6 | Transfer Case Output Shaft PTO Actuator Over Current | Current above normal or grounded circuit | | | SSpd_Xfer_Case_NC_Sol_Cmd |
| 33 | 4048 | Transfer Case Range Switch | 2 | Transfer Case Range Switch Error | Data erratic, intermittent or incorrect | | | Xfer_Case_High_Switch |
| 33 | 4049 | Transfer Case Rear Driveline Actuator | 5 | Transfer Case Rear Driveline Relay Under Current Or Open Circuit | Current below normal or open circuit | | | SSpd_Xfer_Case_NO_Sol_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|---|---------------|---------------|--|
| 33 | 4049 | Transfer Case Rear Driveline Actuator | 6 | Transfer Case Rear Driveline Relay Over Current | Current above normal or grounded circuit | | | SSpd_Xfer_Case_NO_Sol_Cmd |
| 33 | 4053 | Transmission Input Shaft PTO 2 Actuator | 5 | Transmission Input Shaft PTO Engagement Actuator Circuit Under Current Or Open Circuit | Current below normal or open circuit | Not available | Not available | TEM_PTO_Engagement_Relay_Cmd, TEM_PTO_Relay_Driver_Cmd |
| 33 | 4053 | Transmission Input Shaft PTO 2 Actuator | 6 | Transmission Input Shaft PTO Engagement Actuator Circuit Overcurrent | Current above normal or grounded circuit | Not available | Not available | TEM_PTO_Engagement_Relay_Cmd, TEM_PTO_Relay_Driver_Cmd |
| 33 | 4055 | Transmission Retarder Enable Switch | 2 | Transmission Retarder On/Off switch Failure | Data erratic, intermittent or incorrect | | | Retarder_Switch |
| 33 | 4056 | Two Speed Axle Actuator | 5 | Two Speed Axle Solenoid Relay Under Current Or Open Circuit | Current below normal or open circuit | | | Two_Spd_Axle_Solenoid_Cmd |
| 33 | 4056 | Two Speed Axle Actuator | 6 | Two Speed Axle Solenoid Relay Short To Ground | Current above normal or grounded circuit | | | Two_Spd_Axle_Solenoid_Cmd |
| 33 | 4057 | Wiper Motor | 5 | Wiper Motor Undercurrent | Open in Wiper Motor Circuit | | 1604-A | Wipers_Cmd |
| 33 | 4057 | Wiper Motor | 6 | Wiper Motor Overcurrent | Short To Ground or Overload in Wiper Motor Circuit | | 1604-A | Wipers_Cmd |
| 33 | 4058 | Cab Dome Light 1 Switch | 2 | Cab Dome Light Switch is reporting an error. | Faulty Switch Actuator or Microswitch for Cab Dome Light Switch | | | Dome_Light_ON_Switch |
| 33 | 520461 | Switch 6-Pack #1 Data Link | 9 | Switch 6-Pack #1 Data Link Comm. Failure | Faulty Switch Pack #1 or Switch Data Link | | | SwitchPack_1_IN_Timer |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|---|---|------|--------------------------------|
| 33 | 520462 | Switch 6-Pack #2 Data Link | 9 | Switch 6-Pack #2 Data Link Comm. Failure | Faulty Switch Pack #2 or Switch Data Link | | | SwitchPack_2_IN_Timer |
| 33 | 520463 | Switch 6-Pack #3 Data Link | 9 | Switch 6-Pack #3 Data Link Comm. Failure | Faulty Switch Pack #3 or Switch Data Link | | | SwitchPack_5_IN_Timer |
| 33 | 520464 | Electrical Accessory Request | 5 | Electrical Accessory Request Relay Under Current Or Open Circuit | Open Circuit in Electrical Accessory Request Circuit | | | Electrical_Accessory_Request |
| 33 | 520464 | Electrical Accessory Request | 6 | Electrical Accessory Request Relay Over Current | Short To Ground in Electrical Accessory Request Circuit | | | Electrical_Accessory_Request |
| 33 | 520465 | HVAC Control Head Multiple Motor Faults | 2 | HVAC control Head Multiple Motor Faults DM1 | HVAC Motor in Wrong Position or Jammed | | | RCD_HVAC_Ctrl_Head_Diag_Signal |
| 33 | 520467 | Comm. Loss from BC to Power Pack | 9 | Comm. fault from BC to PP3. | Private J1939 datalink problem (exceeded bandwidth). | The Power Pack E Module has stopped receiving heart beat message from the BC. | | |
| 33 | 520468 | RPM 1 Channel 1 Cab Switch | 2 | RPM 1 Channel 1 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod1_Swch1_ON_Switch |
| 33 | 520469 | RPM 1 Channel 1 Overcurrent | 6 | RPM 1 Channel 1 Overcurrent | Current above normal or grounded circuit | | | PwrMod1_Output1_Current_Signal |
| 33 | 520469 | RPM 1 Channel 1 Overcurrent | 14 | RPM 1 Channel 1 Analog Input Data Unavailable | RPM 1 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value of FFh | | | PwrMod1_Output1_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520469 | RPM 1 Channel 1 Overcurrent | 19 | RPM 1 Channel 1 Analog Input Invalid Data | RPM 1 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value in the range of FCh to FEh | | | PwrMod1_Output1_Current_Signal |
| 33 | 520470 | RPM 1 Channel 2 Cab Switch | 2 | RPM 1 Channel 2 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod1_Swch2_ON_Switch |
| 33 | 520471 | RPM 1 Channel 2 Overcurrent | 6 | RPM 1 Channel 2 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod1_Output2_Current_Signal |
| 33 | 520471 | RPM 1 Channel 2 Overcurrent | 14 | RPM 1 Channel 2 Analog Input Data Unavailable | RPM 1 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value of FFh | | | N/A - Handled by translator. PwrMod1_Output2_Current_Signal |
| 33 | 520471 | RPM 1 Channel 2 Overcurrent | 19 | RPM 1 Channel 2 Analog Input Invalid Data | RPM 1 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod1_Output2_Current_Signal |
| 33 | 520472 | RPM 1 Channel 3 Cab Switch | 2 | RPM 1 Channel 3 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod1_Swch3_ON_Switch |
| 33 | 520473 | RPM 1 Channel 3 Overcurrent | 6 | RPM 1 Channel 3 Overcurrent | Current above normal or grounded circuit | | | PwrMod1_Output3_Current_Signal |
| 33 | 520473 | RPM 1 Channel 3 Overcurrent | 14 | RPM 1 Channel 3 Analog Input Data Unavailable | RPM 1 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value of FFh | | | PwrMod1_Output3_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--------------------------------|
| 33 | 520473 | RPM 1 Channel 3 Overcurrent | 19 | RPM 1 Channel 3 Analog Input Invalid Data | RPM 1 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value in the range of FCh to FEh | | | PwrMod1_Output3_Current_Signal |
| 33 | 520474 | RPM 1 Channel 4 Cab Switch | 2 | RPM 1 Channel 4 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod1_Swch4_ON_Switch |
| 33 | 520475 | RPM 1 Channel 4 Overcurrent | 6 | RPM 1 Channel 4 Overcurrent | Current above normal or grounded circuit | | | PwrMod1_Output4_Current_Signal |
| 33 | 520475 | RPM 1 Channel 4 Overcurrent | 14 | RPM 1 Channel 4 Analog Input Data Unavailable | RPM 1 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value of FFh | | | PwrMod1_Output4_Current_Signal |
| 33 | 520475 | RPM 1 Channel 4 Overcurrent | 19 | RPM 1 Channel 4 Analog Input Invalid Data | RPM 1 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value in the range of FCh to FEh | | | PwrMod1_Output4_Current_Signal |
| 33 | 520476 | RPM 1 Channel 5 Cab Switch | 2 | RPM 1 Channel 5 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod1_Swch5_ON_Switch |
| 33 | 520477 | RPM 1 Channel 5 Overcurrent | 6 | RPM 1 Channel 5 Overcurrent | Current above normal or grounded circuit | | | PwrMod1_Output5_Current_Signal |
| 33 | 520477 | RPM 1 Channel 5 Overcurrent | 14 | RPM 1 Channel 5 Analog Input Data Unavailable | RPM 1 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value of FFh | | | PwrMod1_Output5_Current_Signal |
| 33 | 520477 | RPM 1 Channel 5 Overcurrent | 19 | RPM 1 Channel 5 Analog Input Invalid Data | RPM 1 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value in the range of FCh to FEh | | | PwrMod1_Output5_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520478 | RPM 1 Channel 6 Cab Switch | 2 | RPM 1 Channel 6 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod1_Swch6_ON_Switch |
| 33 | 520479 | RPM 1 Channel 6 Overcurrent | 6 | RPM 1 Channel 6 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod1_Output6_Current_Signal |
| 33 | 520479 | RPM 1 Channel 6 Overcurrent | 14 | RPM 1 Channel 6 Analog Input Data Unavailable | RPM 1 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value of FFh | | | N/A - Handled by translator. PwrMod1_Output6_Current_Signal |
| 33 | 520479 | RPM 1 Channel 6 Overcurrent | 19 | RPM 1 Channel 6 Analog Input Invalid Data | RPM 1 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod1_Output6_Current_Signal |
| 33 | 520480 | RPM 2 Channel 1 Cab Switch | 2 | RPM 2 Channel 1 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod2_Swch1_ON_Switch |
| 33 | 520481 | RPM 2 Channel 1 Overcurrent | 6 | RPM 2 Channel 1 Overcurrent | Current above normal or grounded circuit | | | PwrMod2_Output1_Current_Signal |
| 33 | 520481 | RPM 2 Channel 1 Overcurrent | 14 | RPM 2 Channel 1 Analog Input Data Unavailable | RPM 2 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value of FFh | | | PwrMod2_Output1_Current_Signal |
| 33 | 520481 | RPM 2 Channel 1 Overcurrent | 19 | RPM 2 Channel 1 Analog Input Invalid Data | RPM 2 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value in the range of FCh to FEh | | | PwrMod2_Output1_Current_Signal |
| 33 | 520482 | RPM 2 Channel 2 Cab Switch | 2 | RPM 2 Channel 2 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod2_Swch2_ON_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520483 | RPM 2 Channel 2 Overcurrent | 6 | RPM 2 Channel 2 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod2_Output2_Current_Signal |
| 33 | 520483 | RPM 2 Channel 2 Overcurrent | 14 | RPM 2 Channel 2 Analog Input Data Unavailable | RPM 2 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value of FFh | | | N/A - Handled by translator. PwrMod2_Output2_Current_Signal |
| 33 | 520483 | RPM 2 Channel 2 Overcurrent | 19 | RPM 2 Channel 2 Analog Input Invalid Data | RPM 2 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod2_Output2_Current_Signal |
| 33 | 520484 | RPM 2 Channel 3 Cab Switch | 2 | RPM 2 Channel 3 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod2_Swch3_ON_Switch |
| 33 | 520485 | RPM 2 Channel 3 Overcurrent | 6 | RPM 2 Channel 3 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod2_Output3_Current_Signal |
| 33 | 520485 | RPM 2 Channel 3 Overcurrent | 14 | RPM 2 Channel 3 Analog Input Data Unavailable | RPM 2 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value of FFh | | | N/A - Handled by translator. PwrMod2_Output3_Current_Signal |
| 33 | 520485 | RPM 2 Channel 3 Overcurrent | 19 | RPM 2 Channel 3 Analog Input Invalid Data | RPM 2 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod2_Output3_Current_Signal |
| 33 | 520486 | RPM 2 Channel 4 Cab Switch | 2 | RPM 2 Channel 4 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod2_Swch4_ON_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520487 | RPM 2 Channel 4 Overcurrent | 6 | RPM 2 Channel 4 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod2_Output4_Current_Signal |
| 33 | 520487 | RPM 2 Channel 4 Overcurrent | 14 | RPM 2 Channel 4 Analog Input Data Unavailable | RPM 2 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value of FFh | | | N/A - Handled by translator. PwrMod2_Output4_Current_Signal |
| 33 | 520487 | RPM 2 Channel 4 Overcurrent | 19 | RPM 2 Channel 4 Analog Input Invalid Data | RPM 2 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod2_Output4_Current_Signal |
| 33 | 520488 | RPM 2 Channel 5 Cab Switch | 2 | RPM 2 Channel 5 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod2_Swch5_ON_Switch |
| 33 | 520489 | RPM 2 Channel 5 Overcurrent | 6 | RPM 2 Channel 5 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod2_Output5_Current_Signal |
| 33 | 520489 | RPM 2 Channel 5 Overcurrent | 14 | RPM 2 Channel 5 Analog Input Data Unavailable | RPM 2 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value of FFh | | | N/A - Handled by translator. PwrMod2_Output5_Current_Signal |
| 33 | 520489 | RPM 2 Channel 5 Overcurrent | 19 | RPM 2 Channel 5 Analog Input Invalid Data | RPM 2 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod2_Output5_Current_Signal |
| 33 | 520490 | RPM 2 Channel 6 Cab Switch | 2 | RPM 2 Channel 6 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod2_Swch6_ON_Switch |
| 33 | 520491 | RPM 2 Channel 6 Overcurrent | 6 | RPM 2 Channel 6 Overcurrent | Current above normal or grounded circuit | | | PwrMod2_Output6_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--------------------------------|
| 33 | 520491 | RPM 2 Channel 6 Overcurrent | 14 | RPM 2 Channel 6 Analog Input Data Unavailable | RPM 2 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value of FFh | | | PwrMod2_Output6_Current_Signal |
| 33 | 520491 | RPM 2 Channel 6 Overcurrent | 19 | RPM 2 Channel 6 Analog Input Invalid Data | RPM 2 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value in the range of FCh to FEh | | | PwrMod2_Output6_Current_Signal |
| 33 | 520504 | RPM 4 Channel 1 Cab Switch | 2 | RPM 4 Channel 1 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod4_Swch1_ON_Switch |
| 33 | 520505 | RPM 4 Channel 1 Overcurrent | 6 | RPM 4 Channel 1 Overcurrent | Current above normal or grounded circuit | | | PwrMod4_Output1_Current_Signal |
| 33 | 520505 | RPM 4 Channel 1 Overcurrent | 14 | RPM 4 Channel 1 Analog Input Data Unavailable | RPM 4 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value of FFh | | | PwrMod4_Output1_Current_Signal |
| 33 | 520505 | RPM 4 Channel 1 Overcurrent | 19 | RPM 4 Channel 1 Analog Input Invalid Data | RPM 4 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value in the range of FCh to FEh | | | PwrMod4_Output1_Current_Signal |
| 33 | 520506 | RPM 4 Channel 2 Cab Switch | 2 | RPM 4 Channel 2 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod4_Swch2_ON_Switch |
| 33 | 520507 | RPM 4 Channel 2 Overcurrent | 6 | RPM 4 Channel 2 Overcurrent | Current above normal or grounded circuit | | | PwrMod4_Output2_Current_Signal |
| 33 | 520507 | RPM 4 Channel 2 Overcurrent | 14 | RPM 4 Channel 2 Analog Input Data Unavailable | RPM 4 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value of FFh | | | PwrMod4_Output2_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--------------------------------|
| 33 | 520507 | RPM 4 Channel 2 Overcurrent | 19 | RPM 4 Channel 2 Analog Input Invalid Data | RPM 4 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value in the range of FCh to FEh | | | PwrMod4_Output2_Current_Signal |
| 33 | 520508 | RPM 4 Channel 3 Cab Switch | 2 | RPM 4 Channel 3 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod4_Swch3_ON_Switch |
| 33 | 520509 | RPM 4 Channel 3 Overcurrent | 6 | RPM 4 Channel 3 Overcurrent | Current above normal or grounded circuit | | | PwrMod4_Output3_Current_Signal |
| 33 | 520509 | RPM 4 Channel 3 Overcurrent | 14 | RPM 4 Channel 3 Analog Input Data Unavailable | RPM 4 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value of FFh | | | PwrMod4_Output3_Current_Signal |
| 33 | 520509 | RPM 4 Channel 3 Overcurrent | 19 | RPM 4 Channel 3 Analog Input Invalid Data | RPM1 Channel1 Analog Input Data (PGN 65313 , Byte 5) indicates a value in the range of FCh to FEh | | | PwrMod4_Output3_Current_Signal |
| 33 | 520510 | RPM 4 Channel 4 Cab Switch | 2 | RPM 4 Channel 4 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod4_Swch4_ON_Switch |
| 33 | 520511 | RPM 4 Channel 4 Overcurrent | 6 | RPM 4 Channel 4 Overcurrent | Current above normal or grounded circuit | | | PwrMod4_Output4_Current_Signal |
| 33 | 520511 | RPM 4 Channel 4 Overcurrent | 14 | RPM 4 Channel 4 Analog Input Data Unavailable | RPM 4 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value of FFh | | | PwrMod4_Output4_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520511 | RPM 4 Channel 4 Overcurrent | 19 | RPM 4 Channel 4 Analog Input Invalid Data | RPM 4 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value in the range of FCh to FEh | | | PwrMod4_Output4_Current_Signal |
| 33 | 520512 | RPM 4 Channel 5 Cab Switch | 2 | RPM 4 Channel 5 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod4_Swch5_ON_Switch |
| 33 | 520513 | RPM 4 Channel 5 Overcurrent | 6 | RPM 4 Channel 5 Overcurrent | Current above normal or grounded circuit | | | PwrMod4_Output5_Current_Signal |
| 33 | 520513 | RPM 4 Channel 5 Overcurrent | 14 | RPM 4 Channel 5 Analog Input Data Unavailable | RPM 4 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value of FFh | | | PwrMod4_Output5_Current_Signal |
| 33 | 520513 | RPM 4 Channel 5 Overcurrent | 19 | RPM 4 Channel 5 Analog Input Invalid Data | RPM 4 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value in the range of FCh to FEh | | | PwrMod4_Output5_Current_Signal |
| 33 | 520514 | RPM 4 Channel 6 Cab Switch | 2 | RPM 4 Channel 6 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod4_Swch6_ON_Switch |
| 33 | 520515 | RPM 4 Channel 6 Overcurrent | 6 | RPM 4 Channel 6 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod4_Output6_Current_Signal |
| 33 | 520515 | RPM 4 Channel 6 Overcurrent | 14 | RPM 4 Channel 6 Analog Input Data Unavailable | RPM 4 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value of FFh | | | N/A - Handled by translator. PwrMod4_Output6_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520515 | RPM 4 Channel 6 Overcurrent | 19 | RPM 4 Channel 6 Analog Input Invalid Data | RPM 4 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod4_Output6_Current_Signal |
| 33 | 520540 | RPM 7 Channel 1 Cab Switch | 2 | RPM 7 Channel 1 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod7_Swch1_ON_Switch |
| 33 | 520541 | RPM 7 Channel 1 Overcurrent | 6 | RPM 7 Channel 1 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod7_Output1_Current_Signal |
| 33 | 520541 | RPM 7 Channel 1 Overcurrent | 14 | RPM 7 Channel 1 Analog Input Data Unavailable | RPM 7 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value of FFh | | | N/A - Handled by translator. PwrMod7_Output1_Current_Signal |
| 33 | 520541 | RPM 7 Channel 1 Overcurrent | 19 | RPM 7 Channel 1 Analog Input Invalid Data | RPM 7 Channel 1 Analog Input Data (PGN 65313 , Byte 3) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod7_Output1_Current_Signal |
| 33 | 520542 | RPM 7 Channel 2 Cab Switch | 2 | RPM 7 Channel 2 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod7_Swch2_ON_Switch |
| 33 | 520543 | RPM 7 Channel 2 Overcurrent | 6 | RPM 7 Channel 2 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod7_Output2_Current_Signal |
| 33 | 520543 | RPM 7 Channel 2 Overcurrent | 14 | RPM 7 Channel 2 Analog Input Data Unavailable | RPM 7 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value of FFh | | | N/A - Handled by translator. PwrMod7_Output2_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--|
| 33 | 520543 | RPM 7 Channel 2 Overcurrent | 19 | RPM 7 Channel 2 Analog Input Invalid Data | RPM 7 Channel 2 Analog Input Data (PGN 65313 , Byte 4) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod7_Output2_Current_Signal |
| 33 | 520544 | RPM 7 Channel 3 Cab Switch | 2 | RPM 7 Channel 3 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod7_Swch3_ON_Switch |
| 33 | 520545 | RPM 7 Channel 3 Overcurrent | 6 | RPM 7 Channel 3 Overcurrent | Current above normal or grounded circuit | | | N/A - Handled by translator. PwrMod7_Output3_Current_Signal |
| 33 | 520545 | RPM 7 Channel 3 Overcurrent | 14 | RPM 7 Channel 3 Analog Input Data Unavailable | RPM 7 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value of FFh | | | N/A - Handled by translator. PwrMod7_Output3_Current_Signal |
| 33 | 520545 | RPM 7 Channel 3 Overcurrent | 19 | RPM 7 Channel 3 Analog Input Invalid Data | RPM 7 Channel 3 Analog Input Data (PGN 65313 , Byte 5) indicates a value in the range of FCh to FEh | | | N/A - Handled by translator. PwrMod7_Output3_Current_Signal |
| 33 | 520546 | RPM 7 Channel 4 Cab Switch | 2 | RPM 7 Channel 4 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod7_Swch4_ON_Switch |
| 33 | 520547 | RPM 7 Channel 4 Overcurrent | 6 | RPM 7 Channel 4 Overcurrent | Current above normal or grounded circuit | | | PwrMod7_Output4_Current_Signal |
| 33 | 520547 | RPM 7 Channel 4 Overcurrent | 14 | RPM 7 Channel 4 Analog Input Data Unavailable | RPM 7 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value of FFh | | | PwrMod7_Output4_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|---|---|----------|------|--------------------------------|
| 33 | 520547 | RPM 7 Channel 4 Overcurrent | 19 | RPM 7 Channel 4 Analog Input Invalid Data | RPM 7 Channel 4 Analog Input Data (PGN 65313 , Byte 6) indicates a value in the range of FCh to FEh | | | PwrMod7_Output4_Current_Signal |
| 33 | 520548 | RPM 7 Channel 5 Cab Switch | 2 | RPM 7 Channel 5 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod7_Swch5_ON_Switch |
| 33 | 520549 | RPM 7 Channel 5 Overcurrent | 6 | RPM 7 Channel 5 Overcurrent | Current above normal or grounded circuit | | | PwrMod7_Output5_Current_Signal |
| 33 | 520549 | RPM 7 Channel 5 Overcurrent | 14 | RPM 7 Channel 5 Analog Input Data Unavailable | RPM 7 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value of FFh | | | PwrMod7_Output5_Current_Signal |
| 33 | 520549 | RPM 7 Channel 5 Overcurrent | 19 | RPM 7 Channel 5 Analog Input Invalid Data | RPM 7 Channel 5 Analog Input Data (PGN 65313 , Byte 7) indicates a value in the range of FCh to FEh | | | PwrMod7_Output5_Current_Signal |
| 33 | 520550 | RPM 7 Channel 6 Cab Switch | 2 | RPM 7 Channel 6 Switch Error | Data erratic, intermittent or incorrect | | | PwrMod7_Swch6_ON_Switch |
| 33 | 520551 | RPM 7 Channel 6 Overcurrent | 6 | RPM 7 Channel 6 Overcurrent | Current above normal or grounded circuit | | | PwrMod7_Output6_Current_Signal |
| 33 | 520551 | RPM 7 Channel 6 Overcurrent | 14 | RPM 7 Channel 6 Analog Input Data Unavailable | RPM 7 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value of FFh | | | PwrMod7_Output6_Current_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|----------------------------------|-----|---|---|----------|------|--------------------------------|
| 33 | 520551 | RPM 7 Channel 6 Overcurrent | 19 | RPM 7 Channel 6 Analog Input Invalid Data | RPM 7 Channel 6 Analog Input Data (PGN 65313 , Byte 8) indicates a value in the range of FCh to FEh | | | PwrMod7_Output6_Current_Signal |
| 33 | 520552 | TEM Aux 1 Int Switch | 2 | TEM Aux 1 Int Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux1_Int_Switch_On |
| 33 | 520553 | TEM Aux 1 Switch | 2 | TEM Aux 1 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux1_Switch |
| 33 | 520554 | TEM Aux 1 With Interlocks Switch | 2 | TEM Aux 1 With Interlocks Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux1_w_Interlocks_Switch |
| 33 | 520555 | TEM Aux 10 Switch | 2 | TEM Aux 10 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux10_Switch |
| 33 | 520556 | TEM Aux 11 Switch | 2 | TEM Aux 11 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux11_Switch |
| 33 | 520557 | TEM Aux 12 Switch | 2 | TEM Aux 12 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux12_Switch |
| 33 | 520558 | TEM Aux 13 Switch | 2 | TEM Aux 13 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux13_Switch |
| 33 | 520559 | TEM Aux 14 Switch | 2 | TEM Aux 14 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux14_Switch |
| 33 | 520560 | TEM Aux 15 Switch | 2 | TEM Aux 16 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux15_Switch |
| 33 | 520561 | TEM Aux 16 Switch | 2 | TEM Aux 16 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux16_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|----------------------------------|-----|--|---|----------|------|------------------------------|
| 33 | 520562 | TEM Aux 17 Switch | 2 | TEM Aux 17 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux17_Switch |
| 33 | 520563 | TEM Aux 18 Switch | 2 | TEM Aux 18 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux18_Switch |
| 33 | 520564 | TEM Aux 2 Int Switch | 2 | TEM Aux 2 Int Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux2_Int_Switch_On |
| 33 | 520565 | TEM Aux 2 Switch | 2 | TEM Aux 2 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux2_Switch |
| 33 | 520566 | TEM Aux 2 With Interlocks Switch | 2 | TEM Aux 2 With Interlocks Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux2_w_Interlocks_Switch |
| 33 | 520567 | TEM Aux 3 Int Switch | 2 | TEM Aux 3 Int Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux3_Int_Switch_On |
| 33 | 520568 | TEM Aux 3 Switch | 2 | TEM Aux 3 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux3_Switch |
| 33 | 520569 | TEM Aux 3 With Interlocks Switch | 2 | TEM Aux 3 With Interlocks Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux3_w_Interlocks_Switch |
| 33 | 520570 | TEM Aux 4 Switch | 2 | TEM Aux 4 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux4_Switch |
| 33 | 520571 | TEM Aux 4 With Interlocks Switch | 2 | TEM Aux 4 With Interlocks Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux4_w_Interlocks_Switch |
| 33 | 520572 | TEM Aux 5 Switch | 2 | TEM Aux 5 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux5_Switch |
| 33 | 520573 | TEM Aux 6 Switch | 2 | TEM Aux 6 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux6_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------|-----|--|--|----------|------|--|
| 33 | 520574 | TEM Aux 7 Switch | 2 | TEM Aux 7 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux7_Switch |
| 33 | 520575 | TEM Aux 8 Switch | 2 | TEM Aux 8 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux8_Switch |
| 33 | 520576 | TEM Aux 9 Switch | 2 | TEM Aux 9 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux9_Switch |
| 33 | 520577 | TEM Aux Solenoid 1 | 5 | TEM Aux Solenoid 1 Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_Aux_Open_Solenoid_1_Cmd, TEM_Aux_Solenoid_1_Cmd |
| 33 | 520577 | TEM Aux Solenoid 1 | 6 | TEM Aux Solenoid 1 Overcurrent | Current above normal or grounded circuit | | | TEM_Aux_Open_Solenoid_1_Cmd, TEM_Aux_Solenoid_1_Cmd |
| 33 | 520578 | TEM Aux Solenoid 1 Switch | 2 | TEM Aux Solenoid 1 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux_Solenoid_1_Switch_On |
| 33 | 520579 | TEM Aux Solenoid 2 | 5 | TEM Aux Solenoid 2 Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_Aux_Open_Solenoid_2_Cmd, TEM_Aux_Solenoid_2_Cmd |
| 33 | 520579 | TEM Aux Solenoid 2 | 6 | TEM Aux Solenoid 2 Overcurrent | Current above normal or grounded circuit | | | TEM_Aux_Open_Solenoid_2_Cmd, TEM_Aux_Solenoid_2_Cmd |
| 33 | 520580 | TEM Aux Solenoid 2 Switch | 2 | TEM Aux Solenoid 2 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux_Solenoid_2_Switch_On |
| 33 | 520581 | TEM Aux Solenoid 3 | 5 | TEM Aux Solenoid 3 Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_Aux_Open_Solenoid_3_Cmd, TEM_Aux_Solenoid_3_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------|-----|--|--|----------|------|--|
| 33 | 520581 | TEM Aux Solenoid 3 | 6 | TEM Aux Solenoid 3 Overcurrent | Current above normal or grounded circuit | | | TEM_Aux_Open_Solenoid_3_Cmd, TEM_Aux_Solenoid_3_Cmd |
| 33 | 520582 | TEM Aux Solenoid 3 Switch | 2 | TEM Aux Solenoid 3 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux_Solenoid_3_Switch_On |
| 33 | 520583 | TEM Aux Solenoid 4 | 5 | TEM Aux Solenoid 4 Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_Aux_Open_Solenoid_4_Cmd, TEM_Aux_Solenoid_4_Cmd |
| 33 | 520583 | TEM Aux Solenoid 4 | 6 | TEM Aux Solenoid 4 Overcurrent | Current above normal or grounded circuit | | | TEM_Aux_Open_Solenoid_4_Cmd, TEM_Aux_Solenoid_4_Cmd |
| 33 | 520584 | TEM Aux Solenoid 4 Switch | 2 | TEM Aux Solenoid 4 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux_Solenoid_4_Switch_On |
| 33 | 520585 | TEM Aux Solenoid 5 | 5 | TEM Aux Solenoid 5 Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_Aux_Open_Solenoid_5_Cmd |
| 33 | 520585 | TEM Aux Solenoid 5 | 6 | TEM Aux Solenoid 5 Overcurrent | Current above normal or grounded circuit | | | TEM_Aux_Open_Solenoid_5_Cmd |
| 33 | 520586 | TEM Aux Solenoid 5 Switch | 2 | TEM Aux Solenoid 5 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux_Solenoid_5_Switch_On |
| 33 | 520587 | TEM Aux Solenoid 6 | 5 | TEM Aux Solenoid 6 Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_Aux_Open_Solenoid_6_Cmd |
| 33 | 520587 | TEM Aux Solenoid 6 | 6 | TEM Aux Solenoid 6 Overcurrent | Current above normal or grounded circuit | | | TEM_Aux_Open_Solenoid_6_Cmd |
| 33 | 520588 | TEM Aux Solenoid 6 Switch | 2 | TEM Aux Solenoid 6 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Aux_Solenoid_6_Switch_On |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------------|-----|--|--|--|------|------------------------------|
| 33 | 520589 | TEM Dual 1 Switch | 2 | TEM Dual 1 Switch Error | Data erratic, intermittent or incorrect | | | TEM_Dual1_Switch |
| 33 | 520590 | Data Link - Switch 12 Pack top | 9 | Switch 12-Pack Top Data Link Comm. Failure | Abnormal update rate | | | SwitchPack_3_IN_Timer |
| 33 | 520591 | Data Link - Switch 12 Pack bottom | 9 | Switch 12-Pack Bottom Data Link Comm. Failure | Abnormal update rate | | | SwitchPack_4_IN_Timer |
| 33 | 520604 | 5V Sensor Supply | 0 | 5V Sensor Supply Above Normal Range | Data valid but above normal operational range - most severe level | | | Switched_5V_Sense_Raw_Signal |
| 33 | 520604 | 5V Sensor Supply | 1 | 5V Sensor Supply Below Normal Range | Data valid but below normal operational range - most severe level | | | Switched_5V_Sense_Raw_Signal |
| 33 | 520605 | EGC Gauge Calibration | 13 | Electronic Gauge Cluster checksum error. | Defective EGC | | | Cluster_cal_status |
| 33 | 520606 | AGSP Gauge Calibration | 13 | AGSP checksum error. | Defective AGSP | | | AGSP_cal_status |
| 33 | 520607 | SIC Gauge Calibration | 13 | SIC checksum error. | Defective SIC | | | SIC1_Calibration_Status |
| 33 | 520644 | PPE3 AC Module Input Voltage | 3 | AC Module Overvoltage condition on High Voltage DC Bus. | An Over Voltage Condition in the AC module (Inverter High Voltage Bus). | A high Battery Cutout fault has occurred and the source of the fault is the AC module (inverter high voltage bus). | | |
| 33 | 520644 | PPE3 AC Module Input Voltage | 4 | AC Module Undervoltage condition on High Voltage DC Bus. | An Under Voltage Condition in the AC module (Inverter High Voltage Bus). | A low Battery Cutout fault has occurred and the source of the fault is the AC module (inverter high voltage bus). | | |
| 33 | 520649 | Air Horn Solenoid Command | 5 | Air Horn Undercurrent | Open in Air Horn Circuit | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|---|----------|---------|------------------------------------|
| 33 | 520649 | Air Horn Solenoid Command | 6 | Air Horn Overcurrent | Short To Ground or Overload in Air Horn Circuit | | | |
| 33 | 520650 | Air Horn Switch / Headlight Interrupt Switch | 0 | Headlight Interrupt, Marker Interrupt and Air Horn Switch reading above normal range | AMH Request Circuit Open or Shorted High | | 1600-B1 | Steering_Wheel_Switches_Raw_Signal |
| 33 | 520650 | Air Horn Switch / Headlight Interrupt Switch | 1 | Headlight Interrupt, Marker Interrupt and Air Horn Switch reading below normal range | Short To Ground in AMH Request Circuit | | 1600-B1 | Steering_Wheel_Switches_Raw_Signal |
| 33 | 520651 | Air Shield Lights Command | 6 | Air Shield Lighting Overcurrent | Short To Ground or Overload in Air Shield Light Circuit | | | Air_Shield_Lights_Cmd |
| 33 | 520652 | Auxiliary High Current Load Relay Command | 5 | High Current Load Under Current Or Open Circuit | Current below normal or open circuit | | | High_Current_Load_Command |
| 33 | 520652 | Auxiliary High Current Load Relay Command | 6 | High Current Load Overcurrent | Current above normal or grounded circuit | | | High_Current_Load_Command |
| 33 | 520653 | Auxiliary High Current Load Switch | 2 | High Current Load Switch Error | Data erratic, intermittent or incorrect | | | High_Current_Load_Switch |
| 33 | 520654 | Auxiliary Transmission Constant Supply Air Solenoid Command | 5 | Auxiliary Transmission Solenoid B (Constant Supply) output is Under Current Or Open Circuit. | Current below normal or open circuit | | | Aux_Xmsn_Solenoid_B_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|--|----------|------|-------------------------|
| 33 | 520654 | Auxiliary Transmission Constant Supply Air Solenoid Command | 6 | Auxiliary Transmission Solenoid B (Constant Supply) output is overcurrent. | Current above normal or grounded circuit | | | Aux_Xmsn_Solenoid_B_Cmd |
| 33 | 520655 | Auxiliary Transmission High Range Air Solenoid Command | 5 | Auxiliary Transmission Solenoid C (High) output is Under Current Or Open Circuit. | Current below normal or open circuit | | | Aux_Xmsn_Solenoid_C_Cmd |
| 33 | 520655 | Auxiliary Transmission High Range Air Solenoid Command | 6 | Auxiliary Transmission Solenoid C (High) output is overcurrent. | Current above normal or grounded circuit | | | Aux_Xmsn_Solenoid_C_Cmd |
| 33 | 520656 | Auxiliary Transmission Neutral Air Solenoid Command | 5 | Auxiliary Transmission Solenoid A (Neutral) output is Under Current Or Open Circuit. | Current below normal or open circuit | | | Aux_Xmsn_Solenoid_A_Cmd |
| 33 | 520656 | Auxiliary Transmission Neutral Air Solenoid Command | 6 | Auxiliary Transmission Solenoid A (Neutral) output is overcurrent. | Current above normal or grounded circuit | | | Aux_Xmsn_Solenoid_A_Cmd |
| 33 | 520657 | Auxiliary Transmission Range Switch | 2 | Auxiliary Transmission High/Low Switch state is invalid. | Data erratic, intermittent or incorrect | | | Aux_Xmsn_Hi_Switch |
| 33 | 520658 | Body Equipment Hydraulic Power Auxiliary Pump Inhibit Command | 5 | TEM Epump Inhibit Relay Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_EPump_Inhibit_Relay |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|---------------------------------------|--|----------|------|-------------------------|
| 33 | 520658 | Body Equipment Hydraulic Power Auxiliary Pump Inhibit Command | 6 | TEM Epump Inhibit Relay Over Current | Current above normal or grounded circuit | | | TEM_EPump_Inhibit_Relay |
| 33 | 520659 | Bus Amber Signal Light 1 Command | 5 | Left Front Amber PWL Undercurrent | Current below normal or open circuit | | | BUS_LF_Amber_PWL_Cmd |
| 33 | 520659 | Bus Amber Signal Light 1 Command | 6 | Left Front Amber PWL Overcurrent | Current above normal or grounded circuit | | | BUS_LF_Amber_PWL_Cmd |
| 33 | 520660 | Bus Amber Signal Light 2 Command | 5 | Right Front Amber PWL Undercurrent | Current below normal or open circuit | | | BUS_RF_Amber_PWL_Cmd |
| 33 | 520660 | Bus Amber Signal Light 2 Command | 6 | Right Front Amber PWL Overcurrent | Current above normal or grounded circuit | | | BUS_RF_Amber_PWL_Cmd |
| 33 | 520661 | Bus Amber Signal Light 3 Command | 5 | Left Rear Amber PWL Undercurrent | Current below normal or open circuit | | | BUS_LR_Amber_PWL_Cmd |
| 33 | 520661 | Bus Amber Signal Light 3 Command | 6 | Left Rear Amber PWL Overcurrent | Current above normal or grounded circuit | | | BUS_LR_Amber_PWL_Cmd |
| 33 | 520662 | Bus Amber Signal Light 4 Command | 5 | Right Rear Amber PWL Undercurrent | Current below normal or open circuit | | | BUS_RR_Amber_PWL_Cmd |
| 33 | 520662 | Bus Amber Signal Light 4 Command | 6 | Right Rear Amber PWL Overcurrent | Current above normal or grounded circuit | | | BUS_RR_Amber_PWL_Cmd |
| 33 | 520663 | Bus Red Signal Light 4 Command | 5 | Right Rear Red PWL Undercurrent | Current below normal or open circuit | | | BUS_RR_Red_PWL_Cmd |
| 33 | 520663 | Bus Red Signal Light 4 Command | 6 | Right Rear Red PWL Overcurrent | Current above normal or grounded circuit | | | BUS_RR_Red_PWL_Cmd |
| 33 | 520664 | Bus Crossing Gate Command | 5 | Crossing Gate output is undercurrent. | Current below normal or open circuit | | | BUS_Crossing_Gate_Cmd |
| 33 | 520664 | Bus Crossing Gate Command | 6 | Crossing Gate output is overcurrent. | Current above normal or grounded circuit | | | BUS_Crossing_Gate_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|--|----------|------|------------------------------------|
| 33 | 520665 | Bus Passenger Door Close Relay Command | 5 | Bus Entrance Door Close Relay Driver Output is Under Current Or Open Circuit | Current below normal or open circuit | | | BUS_Door_Close_Cm d |
| 33 | 520665 | Bus Passenger Door Close Relay Command | 6 | Bus Entrance Door Close Relay Driver Output is overcurrent | Current above normal or grounded circuit | | | BUS_Door_Close_Cm d |
| 33 | 520667 | Bus Passenger Door Control Switch 2 | 0 | Bus Entrance Door Steering Wheel Switch Input Above Normal Range | Bus Door Control Switches Circuit Open or Shorted High | | | BUS_PWL_And_Door_Switch_Raw_Signal |
| 33 | 520667 | Bus Passenger Door Control Switch 2 | 1 | Bus Entrance Door Steering Wheel Switch Input Below Normal Range | Short To Ground in Bus Door Control Switches Circuit | | | BUS_PWL_And_Door_Switch_Raw_Signal |
| 33 | 520668 | Bus Passenger Door Open Relay Command | 5 | Bus Entrance Door Open Relay Driver Output is Under Current Or Open Circuit | Current below normal or open circuit | | | BUS_Door_Open_Cmd |
| 33 | 520668 | Bus Passenger Door Open Relay Command | 6 | Bus Entrance Door Open Relay Driver Output is overcurrent | Current above normal or grounded circuit | | | BUS_Door_Open_Cmd |
| 33 | 520669 | Bus Red Signal Light 1 Command | 5 | Left Front Red PWL Undercurrent | Current below normal or open circuit | | | BUS_LF_Red_PWL_C md |
| 33 | 520669 | Bus Red Signal Light 1 Command | 6 | Left Front Red PWL Overcurrent | Current above normal or grounded circuit | | | BUS_LF_Red_PWL_C md |
| 33 | 520670 | Bus Red Signal Light 2 Command | 5 | Right Front Red PWL Undercurrent | Current below normal or open circuit | | | BUS_RF_Red_PWL_C md |
| 33 | 520670 | Bus Red Signal Light 2 Command | 6 | Right Front Red PWL Overcurrent | Current above normal or grounded circuit | | | BUS_RF_Red_PWL_C md |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------|-----|--|--|----------|------|----------------------------|
| 33 | 520671 | Bus Red Signal Light 3 Command | 5 | Left Rear Red PWL Undercurrent | Current below normal or open circuit | | | BUS_LR_Red_PWL_Cmd |
| 33 | 520671 | Bus Red Signal Light 3 Command | 6 | Left Rear Red PWL Overcurrent | Current above normal or grounded circuit | | | BUS_LR_Red_PWL_Cmd |
| 33 | 520672 | Bus Stop Arm Command | 5 | Bus Stop Arm Output is Under Current Or Open Circuit | Current below normal or open circuit | | | BUS_Stop_Arm_Cmd |
| 33 | 520672 | Bus Stop Arm Command | 6 | Bus Stop Arm Output is over current | Current above normal or grounded circuit | | | BUS_Stop_Arm_Cmd |
| 33 | 520673 | Cab Dome Light 1 Command | 5 | Cab Dome Light Open Circuit | Open in Cab Dome Light Circuit | | | Dome_Light_Cmd |
| 33 | 520673 | Cab Dome Light 1 Command | 6 | Cab Dome Light Short To Ground | Short To Ground or Overload in Cab Dome Light Circuit | | | Dome_Light_Cmd |
| 33 | 520674 | Cab Dome Light 1 Switch | 2 | Cab Dome Light Switch is reporting an error. | Faulty Switch Actuator or Microswitch for Cab Dome Light Switch | | | Dome_Light_ON_Switch |
| 33 | 520675 | Cab Dome Light 2 Command | 5 | Sleeper Dome Light Relay Under Current Or Open Circuit | Open Circuit in Sleeper Dome Light Circuit | | | Sleeper_Cab_Dome_Light_Req |
| 33 | 520675 | Cab Dome Light 2 Command | 6 | Sleeper Dome Light Over Current | Short To Ground in Sleeper Dome Light Circuit | | | Sleeper_Cab_Dome_Light_Req |
| 33 | 520676 | Cab Dome Light 2 Switch | 2 | Sleeper Dome / Floor Search Light Switch Error | Faulty Switch Actuator or Microswitch for Sleeper Dome / Floor Search Light Switch | | | Floor_Lights_Cab_Switch |
| 33 | 520677 | Cab Floor Light Command | 5 | Floor Lights Relay Under Current Or Open Circuit | Open Circuit in Floor Light Circuit | | | Floor_Search_Lights_Req |
| 33 | 520677 | Cab Floor Light Command | 6 | Floor Lights Relay Over Current | Short To Ground in Floor Light Circuit | | | Floor_Search_Lights_Req |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|---|---|----------|------|-----------------------------|
| 33 | 520678 | Cab Window Motor 1 Status | 7 | Driver Window Motor Failure | Driver Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Master_WM_F_Signal |
| 33 | 520679 | Cab Window Motor 2 Status | 7 | Passenger Window Motor Failure | Passenger Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Front_LMF_Signal |
| 33 | 520680 | Cab Window Motor 3 Status | 7 | Rear Driver Window Motor Failure | Rear Driver Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Rear_1_WM_F_Signal |
| 33 | 520681 | Cab Window Motor 4 Status | 7 | Rear Passenger Window Motor Failure | Rear Passenger Door Pod Module Window Motor Has Short or Open or Window is Jammed | | | Door_Pod_Rear_2_WM_F_Signal |
| 33 | 520682 | Compression Brake Switch Indicator Lamp Command | 5 | Compression Brake Indicator output is Under Current Or Open Circuit | Current below normal or open circuit | | | Comp_Brake_LED_Ind_Cmd |
| 33 | 520682 | Compression Brake Switch Indicator Lamp Command | 6 | Compression Brake Indicator is over current | Current above normal or grounded circuit | | | Comp_Brake_LED_Ind_Cmd |
| 33 | 520683 | Door Control Module 1 Status | 7 | Driver Door Pod Module Failure | Defective Driver Door Pod Module | | | Door_Pod_Front_MF_Signal |
| 33 | 520684 | Door Control Module 2 Status | 7 | Passenger Door Pod Module Failure | Defective Passenger Door Pod Module | | | Door_Pod_Front_MF_Signal |
| 33 | 520685 | Door Control Module 3 Status | 7 | Rear Driver Door Pod Module Failure | Defective Rear Driver Door Pod Module | | | Door_Pod_Rear_1_MF_Signal |
| 33 | 520686 | Door Control Module 4 Status | 7 | Rear Passenger Door Pod Module Failure | Defective Rear Passenger Door Pod Module | | | Door_Pod_Rear_2_MF_Signal |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|--|----------|------|--------------------|
| 33 | 520687 | Engine Remote Start Command | 5 | Remote Start Relay Under Current Or Open Circuit | Open Circuit in Remote Bunk Start Circuit | | | Remote_Start_Relay |
| 33 | 520687 | Engine Remote Start Command | 6 | Remote Start Relay Over Current | Short To Ground in Remote Bunk Start Circuit | | | Remote_Start_Relay |
| 33 | 520688 | Engine Remote Stop Command | 5 | Remote Stop Relay Under Current Or Open Circuit | Open Circuit in Remote Bunk Stop Circuit | | | Remote_Stop_Relay |
| 33 | 520688 | Engine Remote Stop Command | 6 | Remote Stop Relay Over Current | Short To Ground in Remote Bunk Stop Circuit | | | Remote_Stop_Relay |
| 33 | 520689 | Exterior Lamp Check Switch | 2 | Exterior Lamp Check Switch Error | Data erratic, intermittent or incorrect | | | BUS_ELC_On_Switch |
| 33 | 520690 | Fifth Wheel Slide Latch Solenoid Command | 2 | Fifth Wheel Slide Switch Error | Faulty Switch Actuator or Microswitch for Fifth Wheel Slide Switch | | | |
| 33 | 520691 | Fog Light 2 Command | 5 | Right Fog Light Undercurrent | Open in Right Fog Light Circuit | | | |
| 33 | 520691 | Fog Light 2 Command | 6 | Right Fog Light Overcurrent | Short To Ground or Overload in Right Fog Light Output Circuit | | | |
| 33 | 520692 | Fuel Transfer Pump Command | 5 | Fuel Transfer Pump Relay Under Current Or Open Circuit | Open Circuit in Fuel Transfer Pump Circuit | | | |
| 33 | 520692 | Fuel Transfer Pump Command | 6 | Fuel Transfer Pump Relay Short To Ground | Short To Ground or Overload in Fuel Transfer Pump Circuit | | | |
| 33 | 520693 | Headlamp High Beam Command 1 | 5 | Left High Beam Open Circuit | Open in Left High Beam Circuit | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|---|--|----------|------|----------------|
| 33 | 520693 | Headlamp High Beam Command 1 | 6 | Left High Beam Short To Ground | Short To Ground or Overload in Left High Beam Circuit | | | |
| 33 | 520694 | Headlamp High Beam Command 2 | 5 | Right High Beam Open Circuit | Open in Right High Beam Circuit | | | |
| 33 | 520694 | Headlamp High Beam Command 2 | 6 | Right High Beam Short To Ground | Short To Ground or Overload in Right High Beam Circuit | | | |
| 33 | 520695 | HVAC Mode Control Actuator | 2 | HVAC Control Head Mode Fault DM1 | HVAC Motor in Wrong Position or Jammed | | | |
| 33 | 520696 | HVAC Recirculation Door Control Actuator | 2 | HVAC Control Head Air Inlet DM1 | HVAC Motor in Wrong Position or Jammed | | | |
| 33 | 520697 | HVAC System Controller | 9 | HVAC Control Head Circuit Failed To Communicate With The BC | Abnormal update rate | | | |
| 33 | 520698 | Ignition Signal | 2 | Key State Ignition Signal Error | Open in Ignition Signal Input Circuit To BC | | | |
| 33 | 520703 | Lift Gate Power Control Enable Command | 5 | Lift Gate Enable Undercurrent | Current below normal or open circuit | | | |
| 33 | 520703 | Lift Gate Power Control Enable Command | 6 | Lift Gate Enable Overcurrent | Current above normal or grounded circuit | | | |
| 33 | 520704 | Lift Gate Power Control Switch | 2 | Lift Gate Switch Error | Data erratic, intermittent or incorrect | | | |
| 33 | 520705 | Load Shed OFF Command | 5 | Load Shed OFF Relay Under Current Or Open Circuit | Open Circuit in Load Shed OFF Circuit | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|---|----------|------|--------------------------|
| 33 | 520705 | Load Shed OFF Command | 6 | Load Shed OFF Relay Over Current | Short To Ground in Load Shed OFF Circuit | | | |
| 33 | 520706 | Load Shed ON Command | 5 | Load Shed ON Relay Under Current Or Open Circuit | Open Circuit in Load Shed ON Circuit | | | |
| 33 | 520706 | Load Shed ON Command | 6 | Load Shed ON Relay Over Current | Short To Ground in Load Shed ON Circuit | | | |
| 33 | 520707 | Loop Time Exceeded | 14 | BC Internal Fault, Main Loop Time Exceeded | Software Configuration Too Big | | | |
| 33 | 520708 | Marker Interrupt Switch | 2 | Marker Interrupt Switch Failure | Data erratic, intermittent or incorrect | | | Marker_Interrupt_Switch |
| 33 | 520709 | Mirror Heat 2 Command | 5 | Right Mirror Heat Undercurrent | Open in Right Mirror Heat Circuit | | | |
| 33 | 520709 | Mirror Heat 2 Command | 6 | Right Mirror Heat Overcurrent | Short To Ground or Overload in Right Mirror Heat Circuit | | | |
| 33 | 520711 | Primary Air Tank Drain Valve Actuator Command | 5 | Humphrey Valve Primary Tank Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | |
| 33 | 520711 | Primary Air Tank Drain Valve Actuator Command | 6 | Humphrey Valve Primary Tank Solenoid Short To Ground | Current above normal or grounded circuit | | | |
| 33 | 520712 | Primary Tank Drain Valve Switch | 2 | Humphrey Valve Primary Tank Switch Error | Data erratic, intermittent or incorrect | | | Hmphry_Vlve_Prim_Tk_Open |
| 33 | 520713 | Rear HVAC Blower Speed Control Switch | 2 | Rear HVAC Blower Speed Control Switch Error | Faulty Switch Actuator or Microswitch for Rear HVAC Blower Speed Control Switch | | | Rear_HVAC_Blower_UP |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|--|----------|------|-----------------------------|
| 33 | 520714 | Rear HVAC Temperature Control Switch | 2 | Rear HVAC Temperature Control Switch Error | Faulty Switch Actuator or Microswitch for Rear HVAC Temperature Control Switch | | | Rear_HVAC_Temp_UP |
| 33 | 520715 | Secondary Tank Drain Valve Actuator Command | 5 | Humphrey Valve Secondary Tank Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | |
| 33 | 520715 | Secondary Tank Drain Valve Actuator Command | 6 | Humphrey Valve Secondary Tank Solenoid Short To Ground | Current above normal or grounded circuit | | | |
| 33 | 520716 | Secondary Tank Drain Valve Switch | 2 | Humphrey Valve Secondary Tank Switch Error | Data erratic, intermittent or incorrect | | | Hmphry_Vlve_Sec_Tk_Open |
| 33 | 520720 | Snow Plow Light Left Forward Lighting Relay Command | 5 | Left Plow Light Relay Under Current Or Open Circuit | Current below normal or open circuit | | | Left_Plow_Lights_Relay_Req |
| 33 | 520720 | Snow Plow Light Left Forward Lighting Relay Command | 6 | Left Plow Light Relay Circuit Short To Ground | Current above normal or grounded circuit | | | Left_Plow_Lights_Relay_Req |
| 33 | 520721 | Snow Plow Light Right Forward Lighting Relay Command | 5 | Right Plow Light Relay Under Current Or Open Circuit | Current below normal or open circuit | | | Right_Plow_Lights_Relay_Req |
| 33 | 520721 | Snow Plow Light Right Forward Lighting Relay Command | 6 | Right Plow Light Relay Circuit Short To Ground | Current above normal or grounded circuit | | | Right_Plow_Lights_Relay_Req |
| 33 | 520722 | Snow Plow Lighting Mode Switch | 2 | Snow Plow Switch Error | Data erratic, intermittent or incorrect | | | Plow_Lights_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|---|----------|------|----------------------------|
| 33 | 520725 | Supply Air Tank Drain Valve Actuator Command | 5 | Humphrey Valve Wet Tank Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Hmphry_Vlve_Wet_Tk_Sol_Cmd |
| 33 | 520725 | Supply Air Tank Drain Valve Actuator Command | 6 | Humphrey Valve Wet Tank Solenoid Short To Ground | Current above normal or grounded circuit | | | Hmphry_Vlve_Wet_Tk_Sol_Cmd |
| 33 | 520726 | Supply Air Tank Drain Valve Switch | 2 | Humphrey Valve Wet Tank Switch Error | Data erratic, intermittent or incorrect | | | Hmphry_Vlve_Wet_Tk_Open |
| 33 | 520727 | Trailer Auxiliary Power Switch | 2 | Auxiliary Switch Error | Faulty Switch Actuator or Micro switch for Auxiliary Trailer Switch | | | EGC_Digital_Input_1 |
| 33 | 520728 | Trailer Left Turn Light Relay Command | 5 | Trailer Left Turn Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Left Turn Lamp Circuit | | | Trailer_Left_Light |
| 33 | 520728 | Trailer Left Turn Light Relay Command | 6 | Trailer Left Turn Lamp Relay Over Current | Short To Ground in Trailer Left Turn Lamp Circuit | | | Trailer_Left_Light |
| 33 | 520729 | Trailer License Plate Light Relay Command | 5 | Trailer License Plate Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer License Plate Lamp Circuit | | | Trailer_Plate_Light |
| 33 | 520729 | Trailer License Plate Light Relay Command | 6 | Trailer License Plate Lamp Relay Over Current | Short To Ground in Trailer License Plate Lamp Circuit | | | Trailer_Plate_Light |
| 33 | 520730 | Trailer Marker Light Relay Command | 5 | Trailer Marker Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Marker Lamp Circuit | | | Trailer_Marker_Light |
| 33 | 520730 | Trailer Marker Light Relay Command | 6 | Trailer Marker Lamp Relay Over Current | Short To Ground in Trailer Marker Lamp Circuit | | | Trailer_Marker_Light |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|---|--|----------|------|-----------------------------|
| 33 | 520731 | Trailer Right Turn Light Relay Command | 5 | Trailer Right Turn Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Right Turn Lamp Circuit | | | Trailer_Right_Light |
| 33 | 520731 | Trailer Right Turn Light Relay Command | 6 | Trailer Right Turn Lamp Relay Over Current | Short To Ground in Trailer Right Turn Lamp Circuit | | | Trailer_Right_Light |
| 33 | 520732 | Trailer Stop Light Relay Command | 5 | Trailer Stop Lamp Relay Under Current Or Open Circuit | Open Circuit in Trailer Stop Lamp Circuit | | | Trailer_Stop_Light |
| 33 | 520732 | Trailer Stop Light Relay Command | 6 | Trailer Stop Lamp Relay Over Current | Short To Ground in Trailer Stop Lamp Circuit | | | Trailer_Stop_Light |
| 33 | 520733 | Transfer Case Blower Switch | 2 | Transfer Case Switch Error | Data erratic, intermittent or incorrect | | | Transfer_Case_Blower_Switch |
| 33 | 520734 | Transfer Case Front Driveline Solenoid Command | 5 | Transfer Case Solenoid D Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_D_Command |
| 33 | 520734 | Transfer Case Front Driveline Solenoid Command | 6 | Transfer Case Solenoid D Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_D_Command |
| 33 | 520735 | Transfer Case High Range Solenoid Command | 5 | Transfer Case Solenoid C Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_C_Command |
| 33 | 520735 | Transfer Case High Range Solenoid Command | 6 | Transfer Case Solenoid C Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_C_Command |
| 33 | 520736 | Transfer Case Low Range Solenoid Command | 5 | Transfer Case Solenoid A Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_A_Command |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|--|----------|------|----------------------------|
| 33 | 520736 | Transfer Case Low Range Solenoid Command | 6 | Transfer Case Solenoid A Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_A_Cmd |
| 33 | 520737 | Transfer Case Neutral Solenoid Command | 5 | Transfer Case Solenoid B Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_Sol_B_Cmd |
| 33 | 520737 | Transfer Case Neutral Solenoid Command | 6 | Transfer Case Solenoid B Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_Sol_B_Cmd |
| 33 | 520738 | Transfer Case PTO Solenoid Command | 5 | Air Solenoid B Packs Relay Under Current Or Open Circuit | Current below normal or open circuit | | | SSpd_Xfer_Case_NO_Sol_Cmd |
| 33 | 520738 | Transfer Case PTO Solenoid Command | 6 | Air Solenoid B Packs Relay Over Current | Current above normal or grounded circuit | | | SSpd_Xfer_Case_NO_Sol_Cmd |
| 33 | 520739 | Transfer Case PTO Solenoid Relay Command | 5 | Transfer Case PTO Solenoid Under Current Or Open Circuit | Current below normal or open circuit | | | Xfer_Case_PTO_Solenoid_Cmd |
| 33 | 520739 | Transfer Case PTO Solenoid Relay Command | 6 | Transfer Case PTO Solenoid Short To Ground | Current above normal or grounded circuit | | | Xfer_Case_PTO_Solenoid_Cmd |
| 33 | 520740 | Transfer Case PTO Switch | 2 | Transfer Case PTO Switch Error | Data erratic, intermittent or incorrect | | | Xfer_Case_PTO_Eng_Switch |
| 33 | 520741 | Transfer Case Range Switch | 2 | Transfer Case Switch Error | Data erratic, intermittent or incorrect | | | Xfer_Case_High_Switch |
| 33 | 520742 | Transfer Case Rear Driveline Solenoid Command | 5 | Air Solenoid A Packs Relay Under Current Or Open Circuit | Current below normal or open circuit | | | SSpd_Xfer_Case_NC_Sol_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|---|--|----------|------|--------------------------------|
| 33 | 520742 | Transfer Case Rear Driveline Solenoid Command | 6 | Air Solenoid A Packs Relay Over Current | Current above normal or grounded circuit | | | SSpd_Xfer_Case_NC_Sol_Cmd |
| 33 | 520743 | Transmission PTO Engagement Actuator Command | 5 | TEM PTO Engagement Relay Under Current Or Open Circuit | Current below normal or open circuit | | | TEM_PTO_Engagement_Relay_Cmd |
| 33 | 520743 | Transmission PTO Engagement Actuator Command | 6 | TEM PTO Engagement Relay Overcurrent | Current above normal or grounded circuit | | | TEM_PTO_Engagement_Relay_Cmd |
| 33 | 520744 | Transmission PTO Retention Actuator Command | 5 | TEM PTO Retaining Solenoid Undercurrent | Current below normal or open circuit | | | TEM_PTO_Retaining_Solenoid_Cmd |
| 33 | 520744 | Transmission PTO Retention Actuator Command | 6 | TEM PTO Retaining Solenoid Overcurrent | Current above normal or grounded circuit | | | TEM_PTO_Retaining_Solenoid_Cmd |
| 33 | 520745 | Transmission PTO Switch | 2 | TEM PTO Engagement Switch Error | Data erratic, intermittent or incorrect | | | TEM_PTO_Engagement_Switch_On |
| 33 | 520746 | Transmission Retarder Enable Switch | 2 | Transmission Retarder On/Off switch Failure | Data erratic, intermittent or incorrect | | | Retarder_Switch |
| 33 | 520747 | Two Speed Axle Actuator | 5 | Two Speed Axle Solenoid Relay Under Current Or Open Circuit | Current below normal or open circuit | | | Two_Spd_Axle_Solenoid_Cmd |
| 33 | 520747 | Two Speed Axle Actuator | 6 | Two Speed Axle Solenoid Relay Short To Ground | Current above normal or grounded circuit | | | Two_Spd_Axle_Solenoid_Cmd |
| 33 | 520748 | Wiper Motor Power | 5 | Wiper Motor Undercurrent | Open in Wiper Motor Circuit | | | Wipers_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------------------|-----|---|---|----------|---------|---------------------------------------|
| 33 | 520748 | Wiper Motor Power | 6 | Wiper Motor Overcurrent | Short To Ground or Overload in Wiper Motor Circuit | | | Wipers_Cmd |
| 33 | 520749 | Mirror Heater | 2 | Mirror Heat Switch Error | Faulty Switch Actuator or Microswitch for Mirror Heat Switch | | | Mirror_Heat_On_Switch |
| 33 | 520750 | Fog Lights Left Command | 5 | Left Fog Light Undercurrent | Open in Left Fog Light Circuit | | | |
| 33 | 520750 | Fog Lights Left Command | 6 | Left Fog Light Overcurrent | Short To Ground or Overload in Left Fog Light Circuit | | | |
| 33 | 520751 | ICON Freedomline Gear Indicator | 5 | ICON Freedomline Gear Indicator Relay Under Current | Open Circuit in ICON Freedomline Gear Indicator Circuit | | 1601-F9 | Freedomline_Gear_Indication_Relay_Cmd |
| 33 | 520751 | ICON Freedomline Gear Indicator | 6 | ICON Freedomline Gear Indicator Relay Over Current | Short To Ground in ICON Freedomline Gear Indicator Circuit | | 1601-F9 | Freedomline_Gear_Indication_Relay_Cmd |
| 33 | 520752 | Electrical Accessory Power Switch | 2 | Electrical Accessory Power Switch Error | Faulty Switch Actuator or Microswitch for Electrical Accessory Power Switch | | | Sw_Acc_Load_On_Switch |
| 33 | 520753 | Transmission Economy Mode Switch | 2 | Transmission Economy Mode Switch Error | Faulty Switch Actuator or Microswitch for Transmission Economy Mode Switch | | | Bus_Econ_Mode_Switch |
| 33 | 520754 | Universal Air Solenoid Relay Driver 2 | 5 | Universal Air Solenoid Relay Driver 2 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_2 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------------------|-----|---|---------------------------------------|----------|------|-------------------------|
| 33 | 520754 | Universal Air Solenoid Relay Driver 2 | 6 | Universal Air Solenoid Relay Driver 2 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_2 |
| 33 | 520755 | Universal Air Solenoid Relay Driver 3 | 5 | Universal Air Solenoid Relay Driver 3 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_3 |
| 33 | 520755 | Universal Air Solenoid Relay Driver 3 | 6 | Universal Air Solenoid Relay Driver 3 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_3 |
| 33 | 520756 | Universal Air Solenoid Relay Driver 4 | 5 | Universal Air Solenoid Relay Driver 4 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_4 |
| 33 | 520756 | Universal Air Solenoid Relay Driver 4 | 6 | Universal Air Solenoid Relay Driver 4 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_4 |
| 33 | 520757 | Universal Air Solenoid Relay Driver 5 | 5 | Universal Air Solenoid Relay Driver 5 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_5 |
| 33 | 520757 | Universal Air Solenoid Relay Driver 5 | 6 | Universal Air Solenoid Relay Driver 5 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_5 |
| 33 | 520758 | Universal Air Solenoid Relay Driver 6 | 5 | Universal Air Solenoid Relay Driver 6 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|---------------------------------------|----------|------|--------------------------|
| 33 | 520758 | Universal Air Solenoid Relay Driver 6 | 6 | Universal Air Solenoid Relay Driver 6 Over Current | Short To Ground or Defective Solenoid | | | |
| 33 | 520759 | Universal Air Solenoid Relay Driver 7 | 5 | Universal Air Solenoid Relay Driver 7 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | |
| 33 | 520759 | Universal Air Solenoid Relay Driver 7 | 6 | Universal Air Solenoid Relay Driver 7 Over Current | Short To Ground or Defective Solenoid | | | |
| 33 | 520760 | Universal Air Solenoid Relay Driver 8 | 5 | Universal Air Solenoid Relay Driver 8 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_8 |
| 33 | 520760 | Universal Air Solenoid Relay Driver 8 | 6 | Universal Air Solenoid Relay Driver 8 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_8 |
| 33 | 520761 | Universal Air Solenoid Relay Driver 9 | 5 | Universal Air Solenoid Relay Driver 9 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_9 |
| 33 | 520761 | Universal Air Solenoid Relay Driver 9 | 6 | Universal Air Solenoid Relay Driver 9 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_9 |
| 33 | 520762 | Universal Air Solenoid Relay Driver 10 | 5 | Universal Air Solenoid Relay Driver 10 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_10 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|---------------------------------------|----------|------|---|
| 33 | 520762 | Universal Air Solenoid Relay Driver 10 | 6 | Universal Air Solenoid Relay Driver 10 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_10 |
| 33 | 520763 | Universal Air Solenoid Relay Driver 11 | 5 | Universal Air Solenoid Relay Driver 11 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_11 |
| 33 | 520763 | Universal Air Solenoid Relay Driver 11 | 6 | Universal Air Solenoid Relay Driver 11 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_11 |
| 33 | 520764 | Universal Air Solenoid Relay Driver 12 | 5 | Universal Air Solenoid Relay Driver 12 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_12 |
| 33 | 520764 | Universal Air Solenoid Relay Driver 12 | 6 | Universal Air Solenoid Relay Driver 12 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_12 |
| 33 | 520765 | Universal Air Solenoid Relay Driver 13 | 5 | Universal Air Solenoid Relay Driver 13 or Spare Relay Driver 4 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | BUS_Spare_Relay_Driver_Four_Cmd, Univ_Air_Relay_Driver_13 |
| 33 | 520765 | Universal Air Solenoid Relay Driver 13 | 6 | Universal Air Solenoid Relay Driver 13 or Spare Relay Driver 4 Over Current | Short To Ground or Defective Solenoid | | | BUS_Spare_Relay_Driver_Four_Cmd, Univ_Air_Relay_Driver_13 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--|-----|--|---------------------------------------|----------|------|--|
| 33 | 520766 | Universal Air Solenoid Relay Driver 14 | 5 | Universal Air Solenoid Relay Driver 14 or Spare Relay Driver 3 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | BUS_Spare_Relay_Driver_Three_Cmd, Univ_Air_Relay_Driver_14 |
| 33 | 520766 | Universal Air Solenoid Relay Driver 14 | 6 | Universal Air Solenoid Relay Driver 14 or Spare Relay Driver 3 Over Current | Short To Ground or Defective Solenoid | | | BUS_Spare_Relay_Driver_Three_Cmd, Univ_Air_Relay_Driver_14 |
| 33 | 520767 | Universal Air Solenoid Relay Driver 15 | 5 | Universal Air Solenoid Relay Driver 15 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_15 |
| 33 | 520767 | Universal Air Solenoid Relay Driver 15 | 6 | Universal Air Solenoid Relay Driver 15 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_15 |
| 33 | 520768 | Universal Air Solenoid Relay Driver 16 | 5 | Universal Air Solenoid Relay Driver 16 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_16 |
| 33 | 520768 | Universal Air Solenoid Relay Driver 16 | 6 | Universal Air Solenoid Relay Driver 16 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_16 |
| 33 | 520769 | BUS Spare Relay Driver One | 5 | Spare Relay Driver One Under Current Or Open Circuit | Open Circuit | | | BUS_Spare_Relay_Driver_One_Cmd |
| 33 | 520769 | BUS Spare Relay Driver One | 6 | Spare Relay Driver One Over Current | Short To Ground | | | BUS_Spare_Relay_Driver_One_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-------------------------------|-----|---|---|--|---------|--------------------------------|
| 33 | 520770 | BUS Spare Relay Driver Two | 5 | Spare Relay Driver Two Under Current Or Open Circuit | Open Circuit | | | BUS_Spare_Relay_Driver_Two_Cmd |
| 33 | 520770 | BUS Spare Relay Driver Two | 6 | Spare Relay Driver Two Over Current | Short To Ground | | | BUS_Spare_Relay_Driver_Two_Cmd |
| 33 | 520771 | PPE3 AC Module Output Current | 6 | AC Module has shutdown due to overload condition. | A Surge may have occurred for a while in the Vehicle AC bus for a long time (The inverter supplies additional current to the load). | An Overload condition has been detected in the AC module and the Vehicle AC bus is shutdown. | | |
| 33 | 520772 | PPE3 Fuse Open | 31 | PPE3 Fuse Open. | Load exceeded rating. | PPE3 module Fuse is Open. | | |
| 33 | 520773 | PPE3 AC Module Temperature | 0 | AC module over temperature condition. | An overcurrent condition in the Vehicle AC Bus might have caused an over temperature. | An Over temperature fault has occurred and the source of the fault is the AC module (inverter high voltage bus). | | |
| 33 | 520774 | PPE3 DC Module Temperature | 0 | DC module over temperature condition. | An overcurrent condition in the Vehicle DC Bus might have caused an over temperature. | An Over Temperature fault has occurred and the source of the fault is the DC regulator (Vehicle Battery Bus). | | |
| 33 | 520775 | Anti Theft Ignition Relay | 5 | Anti Theft Ignition Relay Under Current Or Open Circuit | Open circuit in Anti Theft Ignition Circuit | | 1601-E4 | Anti_Theft_Ignition_Relay |
| 33 | 520775 | Anti Theft Ignition Relay | 6 | Anti Theft Ignition Relay over current | Short to Ground in Anti Theft Ignition Circuit | | 1601-E4 | Anti_Theft_Ignition_Relay |
| 33 | 520776 | Anti Theft Engine Stop Switch | 2 | Anti Theft Engine Stop Switch Error | Faulty Switch Actuator or Microswitch for Anti Theft Engine Stop Switch | | | Anti_Theft_Engine_Stop_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|------------------------|-----|---|---|----------|----------|---------------------------------|
| 33 | 520777 | Anti Theft Switch 0 | 2 | Anti Theft Switch 0 Error | Faulty Switch Actuator or Microswitch for Anti Theft Switch 0 | | | Anti_Theft_Switch_0 |
| 33 | 520778 | Anti Theft Switch 1 | 2 | Anti Theft Switch 1 Error | Faulty Switch Actuator or Microswitch for Anti Theft Switch 1 | | | Anti_Theft_Switch_1 |
| 33 | 520779 | Anti Theft Switch 2 | 2 | Anti Theft Switch 2 Error | Faulty Switch Actuator or Microswitch for Anti Theft Switch 2 | | | Anti_Theft_Switch_2 |
| 33 | 520780 | Anti Theft Switch 3 | 2 | Anti Theft Switch 3 Error | Faulty Switch Actuator or Microswitch for Anti Theft Switch 3 | | | Anti_Theft_Switch_3 |
| 33 | 520781 | Anti Theft Switch 4 | 2 | Anti Theft Switch 4 Error | Faulty Switch Actuator or Microswitch for Anti Theft Switch 4 | | | Anti_Theft_Switch_4 |
| 33 | 520788 | TEG Aux Relay Driver 1 | 5 | TEG Aux Relay Driver Output 1 Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E16 | TEG_Aux_Relay_Driver_1_RD13_Cmd |
| 33 | 520788 | TEG Aux Relay Driver 1 | 6 | TEG Aux Relay Driver Output 1 Overcurrent | Current above normal or grounded circuit | | 1601-E16 | TEG_Aux_Relay_Driver_1_RD13_Cmd |
| 33 | 520799 | TEG Aux Relay Driver 2 | 5 | TEG Aux Relay Driver Output 2 Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E12 | TEG_Aux_Relay_Driver_2_RD14_Cmd |
| 33 | 520799 | TEG Aux Relay Driver 2 | 6 | TEG Aux Relay Driver Output 2 Overcurrent | Current above normal or grounded circuit | | 1601-E12 | TEG_Aux_Relay_Driver_2_RD14_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|----------------------------------|-----|---|--|----------|--------------------------|---------------------------|
| 33 | 520800 | Transmission Economy Mode output | 5 | Transmission Economy Mode Relay Driver Output Under Current Or Open Circuit | Current below normal or open circuit | | 1601-F11 | Econ_Mode_Enable_Cmd |
| 33 | 520800 | Transmission Economy Mode output | 6 | Transmission Economy Mode Relay Driver Output Overcurrent | Current above normal or grounded circuit | | 1601-F11 | Econ_Mode_Enable_Cmd |
| 33 | 520801 | Transmission Auto Neutral Output | 5 | Transmission Auto Neutral Relay Driver Output Under Current Or Open Circuit | Current below normal or open circuit | | 1601-E3 | Auto_Neutral_Relay_Cmd |
| 33 | 520801 | Transmission Auto Neutral Output | 6 | Transmission Auto Neutral Relay Driver Output Overcurrent | Current above normal or grounded circuit | | 1601-E3 | Auto_Neutral_Relay_Cmd |
| 33 | 520802 | Aux Air Susp Solenoid Command | 5 | Aux Air Suspension Solenoid Under Current or Open Circuit | Open Circuit or Defective Solenoid | | 1602-E12 | Aux_Air_Susp_Solenoid_Cmd |
| 33 | 520802 | Aux Air Susp Solenoid Command | 6 | Aux Air Suspension Solenoid output Over Current | Short To Ground or Defective Solenoid | | 1602-E12 | Aux_Air_Susp_Solenoid_Cmd |
| 33 | 520803 | Park Brake Relay Command | 5 | Park Brake Relay Under Current or Open Circuit | Open Circuit or Defective Solenoid | | 1601-E7 1601-F1 (BUS) | Park_Brake_Relay_Cmd |
| 33 | 520803 | Park Brake Relay Command | 6 | Park Brake Relay Over Current | Short To Ground or Defective Solenoid | | 1601-E7 1601-F1 (BUS) | Park_Brake_Relay_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-------------------------------------|-----|--|---|---------------|---------------|----------------------------------|
| 33 | 520804 | RKE Option Door Pod Not Present | 14 | Missing Remote Keyless entry door pod | Expected RKE door pod is not present or in the wrong slot or bad door pod harness | Not available | Not available | RKE_Option_Front_Passenger_Byte6 |
| 33 | 520806 | Fifth Wheel Jaw Unlock Sol2 Command | 5 | Fifth Wheel Jaw Unlock Solenoid2 output Under Current or Open Circuit | Open Circuit or Defective Solenoid | | | Fifth_Wheel_Jaw_Unlock_Sol2_Cmd |
| 33 | 520806 | Fifth Wheel Jaw Unlock Sol2 Command | 6 | Fifth Wheel Jaw Unlock Solenoid2 output Overcurrent | Short To Ground or Defective Solenoid | | | Fifth_Wheel_Jaw_Unlock_Sol2_Cmd |
| 33 | 520807 | Engine RPM Interrupt Output | 5 | Engine RPM Interrupt Relay Driver Output Under Current Or Open Circuit | Current below normal or open circuit | | 1601-F3 | Engine_RPM_Interrupt |
| 33 | 520807 | Engine RPM Interrupt Output | 6 | Engine RPM Interrupt Relay Driver Output Overcurrent | Current above normal or grounded circuit | | 1601-F3 | Engine_RPM_Interrupt |
| 33 | 520813 | Aux_Relay_Driver_3 | 5 | Relay Driver 3 Undercurrent | Open in Relay Driver 3 Circuit | | 1601-E3 | Aux_Relay_Driver_3 |
| 33 | 520813 | Aux_Relay_Driver_3 | 6 | Relay Driver 3 Overcurrent | Short To Ground or Overload in Relay Driver 3 Output Circuit | | 1601-E3 | Aux_Relay_Driver_3 |
| 33 | 520814 | Aux_Relay_Driver_4 | 5 | Relay Driver 4 Undercurrent | Open in Relay Driver 4 Circuit | | 1601-E4 | Aux_Relay_Driver_4 |
| 33 | 520814 | Aux_Relay_Driver_4 | 6 | Relay Driver 4 Overcurrent | Short To Ground or Overload in Relay Driver 4 Output Circuit | | 1601-E4 | Aux_Relay_Driver_4 |
| 33 | 520815 | Sixth Gear Disable Relay | 5 | Sixth Speed Disable Relay is Undercurrent or Open Circuit | Open Circuit on the Sixth Gear Disable Relay | | 1601-E4 | |
| 33 | 520815 | Sixth Gear Disable Relay | 6 | Sixth Speed Disable Relay is Overcurrent | Short to Battery on the Sixth Speed Disable Relay | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------------------|-----|---|--|----------|------|--------------------------------|
| 33 | 520816 | Sixth Gear Disable LED | 5 | Sixth Gear Disable LED Relay Driver Output is Under Current or Open Circuit | Open Circuit on the Sixth Gear Disable LED Relay Driver | | | |
| 33 | 520816 | Sixth Gear Disable LED | 6 | Sixth Gear Disable LED Relay Driver Output is Over Current | Short to Battery on the Sixth Speed Disable LED Relay | | | |
| 33 | 520817 | Sixth Gear Disable Switch | 2 | Sixth Speed Disable Switch status is invalid | Fault Switch Actuator or Micro switch for Sixth Gear Disable Switch | | | |
| 33 | 520818 | HEV ePTO Pressure Feedback | 0 | HEV ePTO Pressure Feedback Sensor reading above normal range | HEV ePTO Pressure Feedback Shorted High or faulty sensor system | | | HEV_ePTO_Pressure_Feedback_Raw |
| 33 | 520818 | HEV ePTO Pressure Feedback | 1 | HEV ePTO Pressure Feedback Sensor reading below normal range | HEV ePTO Pressure Feedback Shorted to Ground or Open Circuit or faulty sensor system | | | HEV_ePTO_Pressure_Feedback_Raw |
| 33 | 520819 | Universal Air Solenoid Relay Driver 1 | 5 | Universal Air Solenoid Relay Driver 1 Under Current Or Open Circuit | Open Circuit or Defective Solenoid | | | Univ_Air_Relay_Driver_1 |
| 33 | 520819 | Universal Air Solenoid Relay Driver 1 | 6 | Universal Air Solenoid Relay Driver 1 Over Current | Short To Ground or Defective Solenoid | | | Univ_Air_Relay_Driver_1 |
| 33 | 520820 | Wig-Wag Switch | 2 | Wig-Wag Switch Error | Faulty Switch Actuator or Microswitch for Wig-Wag Switch | | | Wig_Wag_Enable_Switch |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|---|--|---------------|--------------------------------|
| 33 | 520822 | Remote Condenser Electric Fan Control A | 5 | Electric Fan A output Under Current or Open Circuit | Open Circuit in Electric Fan A output | Not available | Not available | RMC_Fan_Control_A_Cmd |
| 33 | 520822 | Remote Condenser Electric Fan Control A | 6 | Electric Fan A output Short-Circuit | Short circuit detected in Electric Fan A output | Electric Fan A can be configured for two different outputs: Low Side Driver RD4 - Fault is reported when Short to Battery condition is detected High Side Driver RD31 - Fault is reported when Short to Ground condition is Detected | Not available | RMC_Fan_Control_A_Cmd |
| 33 | 520823 | Remote Condenser Electric Fan Control B | 5 | Electric Fan B output Under Current or Open Circuit | Open Circuit in Electric Fan B output | Not available | Not available | RMC_Fan_Control_B_Cmd |
| 33 | 520823 | Remote Condenser Electric Fan Control B | 6 | Electric Fan B output Short-Circuit | Short circuit detected in Electric Fan B output | Electric Fan B can be configured for two different outputs: Low Side Driver RD7 - Fault is reported when Short to Battery condition is detected High Side Driver RD32 - Fault is reported when Short to Ground condition is Detected | Not available | RMC_Fan_Control_B_Cmd |
| 33 | 520839 | Transfer Case Output Shaft Odometer Shutoff Relay | 5 | Transfer Case Output Shaft Odometer Shutoff Relay Undercurrent | Open in Odometer Shutoff Relay Circuit | | | SSpd_Xfer_Case_Odo_Shutoff_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|---|--|---------------|---------------|---------------------------------------|
| 33 | 520839 | Transfer Case Output Shaft Odometer Shutoff Relay | 6 | Transfer Case Output Shaft Odometer Shutoff Relay Overcurrent | Short or Overload in odometer Shutoff Relay Circuit | | 1601-E4 | SSpd_Xfer_Case_Odo_Shutoff_Cmd |
| 33 | 520864 | Rear Axle Load Distribution Switch | 2 | Rear Axle Load Distribution Switch Error | Faulty Switch Actuator or Microswitch for Rear Axle Load Distribution Switch | Not available | Not available | Rear_Axle_Load_Distribution_Switch |
| 33 | 520865 | Rear Axle Load Distribution Solenoid A | 5 | Rear Axle Load Distribution A Relay Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | Axle_Load_Distribution_Solenoid_A_Cmd |
| 33 | 520865 | Rear Axle Load Distribution Solenoid A | 6 | Rear Axle Load Distribution A Relay Short To Ground | Short To Ground or Defective Solenoid | Not available | Not available | Axle_Load_Distribution_Solenoid_A_Cmd |
| 33 | 520866 | Rear Axle Load Distribution Solenoid B | 5 | Rear Axle Load Distribution B Relay Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | Axle_Load_Distribution_Solenoid_B_Cmd |
| 33 | 520866 | Rear Axle Load Distribution Solenoid B | 6 | Rear Axle Load Distribution B Relay Short To Ground | Short To Ground or Defective Solenoid | Not available | Not available | Axle_Load_Distribution_Solenoid_B_Cmd |
| 33 | 520867 | Snow Valve Motor Relays | 6 | Snow Valve Motor Relays Output Over Current | Short to Ground or Defective Relay(s) | Not available | Not available | Snow_Valve_Motor_Cmd |
| 33 | 520868 | HVAC Condenser Pusher Fan Relay | 5 | HVAC Condenser Pusher Fan Output Under Current or Open Circuit | Open Circuit on HVAC Condenser Pusher Fan circuit | Not available | Not available | HVAC_Pusher_Fan_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------------|-----|---|---|---------------|---------------|---------------------|
| 33 | 520868 | HVAC Condenser Pusher Fan Relay | 6 | HVAC Condenser Pusher Fan Output Over Current | Short to Ground in the HVAC Condenser Pusher Fan circuit | Not available | Not available | HVAC_Pusher_Fan_Cmd |
| 33 | 520869 | Trailer BO Stop | 6 | Trailer BO Stop Overcurrent | Current above normal or grounded circuit | Not available | 1601-F9 | TRLR_BO_Stop_Cmd |
| 33 | 520870 | Trailer BO Marker | 6 | Trailer BO Marker Overcurrent | Current above normal or grounded circuit | Not available | 1601-E14 | TRLR_BO_Marker_Cmd |
| 33 | 520871 | BO Ignition_1 | 6 | BO Ignition_1 Overcurrent | Current above normal or grounded circuit | Not available | 1601-E16 | BO_Ignition_1_Cmd |
| 33 | 520872 | BO Ignition_2 | 6 | BO Ignition_2 Overcurrent | Current above normal or grounded circuit | Not available | 1601-F1 | BO_Ignition_2_Cmd |
| 33 | 520873 | BO Ignition_3 | 6 | BO Ignition_3 Overcurrent | Current above normal or grounded circuit | Not available | 1601-E1 | BO_Ignition_3_Cmd |
| 33 | 520874 | BO Ignition_4 | 6 | BO Ignition_4 Overcurrent | Current above normal or grounded circuit | Not available | 1601-E2 | BO_Ignition_4_Cmd |
| 33 | 520875 | Winch IN / OUT Switch | 2 | Winch IN OUT Switch Error | Faulty Switch Actuator or Microswitch for Winch IN OUT Switch | Not available | Not available | Winch_Dir_In_Switch |
| 33 | 520876 | Winch IN Command | 5 | Winch IN relay driver under current or open circuit | Current below normal or open circuit | Not available | Not available | Winch_In_Cmd |
| 33 | 520876 | Winch IN Command | 6 | Winch IN relay driver over current | Current above normal or grounded circuit | Not available | Not available | Winch_In_Cmd |
| 33 | 520877 | Winch OUT Command | 5 | Winch OUT relay driver under current or open circuit | Current below normal or open circuit | Not available | Not available | Winch_Out_Cmd |
| 33 | 520877 | Winch OUT Command | 6 | Winch OUT relay driver over current | Current above normal or grounded circuit | Not available | Not available | Winch_Out_Cmd |
| 33 | 520878 | NEC Park Brake Command | 5 | NEC Park Brake Command is Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | NEC_Park_Brake_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|----------------------------------|-----|---|--|---------------|---------------|-------------------------------------|
| 33 | 520878 | NEC Park Brake Command | 6 | NEC Park Brake Command is overcurrent | Short To Ground or Defective Solenoid | Not available | Not available | NEC_Park_Brake_Cmd |
| 33 | 520879 | NEC Service Door Command | 5 | NEC Service Door Command is Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | NEC_Service_Door_Cmd |
| 33 | 520879 | NEC Service Door Command | 6 | NEC Service Door Command is overcurrent | Short To Ground or Defective Solenoid | Not available | Not available | NEC_Service_Door_Cmd |
| 33 | 520880 | NEC Post Trip Inspection Command | 5 | NEC Post Trip Inspection Command is Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | NEC_PTI_Cmd |
| 33 | 520880 | NEC Post Trip Inspection Command | 6 | NEC Post Trip Inspection Command is overcurrent | Short To Ground or Defective Solenoid | Not available | Not available | NEC_PTI_Cmd |
| 33 | 520881 | TEM Interlocked Switch Relay 1 | 5 | TEM Switch Interlocked Output Circuit 1 undercurrent | Open circuit in TEM Interlocked circuit 1 | Not available | Not available | TEM_Aux1_w_Interlocks_RD_Output_Cmd |
| 33 | 520881 | TEM Interlocked Switch Relay 1 | 6 | TEM Switch Interlocked Output Circuit 1 overcurrent | Short circuit in TEM Interlocked circuit 1 | Not available | Not available | TEM_Aux1_w_Interlocks_RD_Output_Cmd |
| 33 | 520882 | TEM Interlocked Switch Relay 2 | 5 | TEM Switch Interlocked Output Circuit 2 undercurrent | Open circuit in TEM Interlocked circuit 2 | Not available | Not available | TEM_Aux2_w_Interlocks_RD_Output_Cmd |
| 33 | 520882 | TEM Interlocked Switch Relay 2 | 6 | TEM Switch Interlocked Output Circuit 2 overcurrent | Short circuit in TEM Interlocked circuit 2 | Not available | Not available | TEM_Aux2_w_Interlocks_RD_Output_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------------|-----|--|---|---------------|---------------|---------------------------|
| 33 | 520883 | Transfer Case Low Indicator | 5 | Transfer case low indicator high side output exhibits an undercurrent condition or is open | Not available | Not available | 1601-F7 | Xfer_Case_Low_Ind |
| 33 | 520883 | Transfer Case Low Indicator | 6 | Transfer case low indicator high side output exhibits an overcurrent condition or is short to ground | Not available | Not available | 1601-F7 | Xfer_Case_Low_Ind |
| 33 | 520884 | Transfer Case Neutral Indicator | 5 | Transfer case neutral indicator high side output exhibits an undercurrent condition or is open | Not available | Not available | 1601-F6 | Xfer_Case_Neutral_Ind |
| 33 | 520884 | Transfer Case Neutral Indicator | 6 | Transfer case neutral indicator high side output exhibits an overcurrent condition or is short to ground | Not available | Not available | 1601-F6 | Xfer_Case_Neutral_Ind |
| 33 | 520885 | Windshield Heat Left Output | 5 | Windshield Heat Left output Under Current or Open Circuit | Open Circuit in Windshield Heat Left Output | Not available | Not available | Windshield_Heat_Left_Cmd |
| 33 | 520885 | Windshield Heat Left Output | 6 | Windshield Heat Left Output Short-Circuit | Short Circuit detected in Windshield Heat Left Output | Not available | Not available | Windshield_Heat_Left_Cmd |
| 33 | 520886 | Windshield Heat Right Output | 5 | Windshield Heat Right Output Under Current or Open Circuit | Open Circuit detected in Windshield Heat Right Output | Not available | Not available | Windshield_Heat_Right_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------------|-----|--|--|---------------|---------------|---|
| 33 | 520886 | Windshield Heat Right Output | 6 | Windshield Heat Right Output Short-Circuit | Short Circuit detected in Windshield Heat Right Output | Not available | Not available | Windshield_Heat_Right_Cmd |
| 33 | 520887 | Windshield Heat Left Temp Sensor | 0 | Left Windshield Heat Temperature Sensor reading above normal range | Left Windshield Heat Temperature Sensor Shorted High or Open Circuit or faulty sensor system | Not available | Not available | Left_Windshield_Temperature_Raw_Signal |
| 33 | 520887 | Windshield Heat Left Temp Sensor | 1 | Left Windshield Heat Temperature Sensor reading below normal range | Left Windshield Heat Temperature Sensor Short to Ground or faulty sensor system | Not available | Not available | Left_Windshield_Temperature_Raw_Signal |
| 33 | 520888 | Windshield Heat Right Temp Sensor | 0 | Right Windshield Heat Temperature Sensor reading above normal range | Right Windshield Heat Temperature Sensor Shorted High or Open Circuit or faulty sensor system | Not available | Not available | Right_Windshield_Temperature_Raw_Signal |
| 33 | 520888 | Windshield Heat Right Temp Sensor | 1 | Right Windshield Heat Temperature Sensor reading below normal range | Right Windshield Heat Temperature Sensor Short to Ground or faulty sensor system | Not available | Not available | Right_Windshield_Temperature_Raw_Signal |
| 33 | 520889 | Relay Driver 9, Channel 1 | 13 | Connector J4 Pin E11 has a load on this pin that has been configured as unused | Connector J4 Pin E11 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD9 |
| 33 | 520890 | Relay Driver 10, Channel 2 | 13 | Connector J4 Pin E10 has a load on this pin that has been configured as unused | Connector J4 Pin E10 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD10 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-------------------------------|-----|--|---|---------------|---------------|----------------|
| 33 | 520891 | Relay Driver 11, Channel 3 | 13 | Connector J4 Pin E15 has a load on this pin that has been configured as unused | Connector J4 Pin E15 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD11 |
| 33 | 520892 | Relay Driver 12, Channel 4 | 13 | Connector J4 Pin E14 has a load on this pin that has been configured as unused | Connector J4 Pin E14 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD12 |
| 33 | 520893 | Relay Driver 13, Channel 5 | 13 | Connector J4 Pin E16 has a load on this pin that has been configured as unused | Connector J4 Pin E16 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD13 |
| 33 | 520894 | Relay Driver 14, Channel 6 | 13 | Connector J4 Pin E12 has a load on this pin that has been configured as unused | Connector J4 Pin E12 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD14 |
| 33 | 520895 | Relay Driver 15, Channel 7 | 13 | Connector J4 Pin E13 has a load on this pin that has been configured as unused | Connector J4 Pin E13 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD15 |
| 33 | 520896 | Relay Driver 16, Channel 8 | 13 | Connector J4 Pin E9 has a load on this pin that has been configured as unused | Connector J4 Pin E9 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD16 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------|-----|---|--|---------------|---------------|----------------|
| 33 | 520897 | Relay Driver 17, Channel 9 | 13 | Connector J4 Pin F6 has a load on this pin that has been configured as unused | Connector J4 Pin F6 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD17 |
| 33 | 520898 | Relay Driver 18, Channel 10 | 13 | Connector J4 Pin F7 has a load on this pin that has been configured as unused | Connector J4 Pin F7 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD18 |
| 33 | 520899 | Relay Driver 19, Channel 11 | 13 | Connector J4 Pin F2 has a load on this pin that has been configured as unused | Connector J4 Pin F2 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD19 |
| 33 | 520900 | Relay Driver 20, Channel 12 | 13 | Connector J4 Pin F3 has a load on this pin that has been configured as unused | Connector J4 Pin F3 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD20 |
| 33 | 520901 | Relay Driver 21, Channel 13 | 13 | Connector J4 Pin F1 has a load on this pin that has been configured as unused | Connector J4 Pin F1 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD21 |
| 33 | 520902 | Relay Driver 22, Channel 14 | 13 | Connector J4 Pin F5 has a load on this pin that has been configured as unused | Connector J4 Pin F5 has a load on this pin that has been configured as unused | Not available | Not available | P_SSC_RD22 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------|-----|--|--|---------------|---------------|----------------|
| 33 | 520903 | Relay Driver 23, Channel 15 | 13 | Connector J4 Pin F4 has a load on this pin that has been configured as unused | Connector J4 Pin F4 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD23 |
| 33 | 520904 | Relay Driver 24, Channel 16 | 13 | Connector J4 Pin F8 has a load on this pin that has been configured as unused | Connector J4 Pin F8 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD24 |
| 33 | 520905 | Relay Driver 25, Channel 17 | 13 | Connector J4 Pin F10 has a load on this pin that has been configured as unused | Connector J4 Pin F10 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD25 |
| 33 | 520906 | Relay Driver 26, Channel 18 | 13 | Connector J4 Pin F11 has a load on this pin that has been configured as unused | Connector J4 Pin F11 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD26 |
| 33 | 520907 | Relay Driver 27, Channel 19 | 13 | Connector J4 Pin F14 has a load on this pin that has been configured as unused | Connector J4 Pin F14 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD27 |
| 33 | 520908 | Relay Driver 28, Channel 20 | 13 | Connector J4 Pin F15 has a load on this pin that has been configured as unused | Connector J4 Pin F15 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD28 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------|-----|--|---|---------------|---------------|----------------|
| 33 | 520909 | Relay Driver 29, Channel 21 | 13 | Connector J4 Pin F13 has a load on this pin that has been configured as unused | Connector J4 Pin F13 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD29 |
| 33 | 520910 | Relay Driver 30, Channel 22 | 13 | Connector J4 Pin F9 has a load on this pin that has been configured as unused | Connector J4 Pin F9 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD30 |
| 33 | 520911 | Relay Driver 31, Channel 23 | 13 | Connector J4 Pin F16 has a load on this pin that has been configured as unused | Connector J4 Pin F16 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD31 |
| 33 | 520912 | Relay Driver 32, Channel 24 | 13 | Connector J4 Pin F12 has a load on this pin that has been configured as unused | Connector J4 Pin F12 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD32 |
| 33 | 520913 | Relay Driver 1, Channel 25 | 13 | Connector J4 Pin E7 has a load on this pin that has been configured as unused | Connector J4 Pin E7 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD1 |
| 33 | 520914 | Relay Driver 2, Channel 26 | 13 | Connector J4 Pin E6 has a load on this pin that has been configured as unused | Connector J4 Pin E6 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD2 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-------------------------------|-----|---|---|---------------|---------------|----------------|
| 33 | 520915 | Relay Driver 3, Channel 27 | 13 | Connector J4 Pin E3 has a load on this pin that has been configured as unused | Connector J4 Pin E3 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD3 |
| 33 | 520916 | Relay Driver 4, Channel 28 | 13 | Connector J4 Pin E2 has a load on this pin that has been configured as unused | Connector J4 Pin E2 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD4 |
| 33 | 520917 | Relay Driver 5, Channel 29 | 13 | Connector J4 Pin E4 has a load on this pin that has been configured as unused | Connector J4 Pin E4 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD5 |
| 33 | 520918 | Relay Driver 6, Channel 30 | 13 | Connector J4 Pin E8 has a load on this pin that has been configured as unused | Connector J4 Pin E8 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD6 |
| 33 | 520919 | Relay Driver 7, Channel 31 | 13 | Connector J4 Pin E1 has a load on this pin that has been configured as unused | Connector J4 Pin E1 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD7 |
| 33 | 520920 | Relay Driver 8, Channel 32 | 13 | Connector J4 Pin E5 has a load on this pin that has been configured as unused | Connector J4 Pin E5 is drawing current and it is configured as unused check configuration and or wiring harness | Not available | Not available | P_SSC_RD8 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|----------------------------|-----|--|--|---------------|---------------|---------------------------|
| 33 | 520840 | Switch 12-Pack Location 7 | 13 | Unexpected switch in 12-pack (MID 5) bottom row position 1 from left (Switch 7 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_5_254_164_2_1_1 |
| 33 | 520841 | Switch 12-Pack Location 8 | 13 | Unexpected switch in 12-pack (MID 5) bottom row position 2 from left (Switch 8 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_5_254_164_2_1_3 |
| 33 | 520842 | Switch 12-Pack Location 9 | 13 | Unexpected switch in 12-pack (MID 5) bottom row position 3 from left (Switch 9 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_5_254_164_2_1_5 |
| 33 | 520843 | Switch 12-Pack Location 10 | 13 | Unexpected switch in 12-pack (MID 5) bottom row position 4 from left (Switch 10 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_5_254_164_2_1_7 |
| 33 | 520844 | Switch 12-Pack Location 11 | 13 | Unexpected switch in 12-pack (MID 5) bottom row position 5 from left (Switch 11 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_5_254_164_2_2_1 |
| 33 | 520845 | Switch 12-Pack Location 12 | 13 | Unexpected switch in 12-pack (MID 5) bottom row position 6 from left (Switch 12 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_5_254_164_2_2_3 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|-----------------------------|-----|--|--|---------------|---------------|---------------------------|
| 33 | 520846 | Switch 12-Pack Location 1 | 13 | Unexpected switch in 12-pack (MID 6) top row position 1 from left (Switch 1 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_6_254_164_2_1_1 |
| 33 | 520847 | Switch 12-Pack Location 2 | 13 | Unexpected switch in 12-pack (MID 6) top row position 2 from left (Switch 2 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_6_254_164_2_1_3 |
| 33 | 520848 | Switch 12-Pack Location 3 | 13 | Unexpected switch in 12-pack (MID 6) top row position 3 from left (Switch 3 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_6_254_164_2_1_5 |
| 33 | 520849 | Switch 12-Pack Location 4 | 13 | Unexpected switch in 12-pack (MID 6) top row position 4 from left (Switch 4 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_6_254_164_2_1_7 |
| 33 | 520850 | Switch 12-Pack Location 5 | 13 | Unexpected switch in 12-pack (MID 6) top row position 5 from left (Switch 5 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_6_254_164_2_2_1 |
| 33 | 520851 | Switch 12-Pack Location 6 | 13 | Unexpected switch in 12-pack (MID 6) top row position 6 from left (Switch 6 of 12) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_6_254_164_2_2_3 |
| 33 | 520852 | Switch 6-Pack #2 Location 1 | 13 | Unexpected switch in switchpack 2 (MID 7) position 1 from left (Switch 1 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_7_254_164_2_1_1 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------|-----|---|---|---------------|------------------|--------------------------------|
| 33 | 520853 | Switch 6-Pack #2 Location 2 | 13 | Unexpected switch in switchpack 2 (MID 7) position 2 from left (Switch 2 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_7_254_164 _2_1_3 |
| 33 | 520854 | Switch 6-Pack #2 Location 3 | 13 | Unexpected switch in switchpack 2 (MID 7) position 3 from left (Switch 3 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_7_254_164 _2_1_5 |
| 33 | 520855 | Switch 6-Pack #2 Location 4 | 13 | Unexpected switch in switchpack 2 (MID 7) position 4 from left (Switch 4 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_7_254_164 _2_1_7 |
| 33 | 520856 | Switch 6-Pack #2 Location 5 | 13 | Unexpected switch in switchpack 2 (MID 7) position 5 from left (Switch 5 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_7_254_164 _2_2_1 |
| 33 | 520857 | Switch 6-Pack #2 Location 6 | 13 | Unexpected switch in switchpack 2 (MID 7) position 6 from left (Switch 6 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_7_254_164 _2_2_3 |
| 33 | 520858 | Switch 6-Pack #1 Location 1 | 13 | Unexpected switch in switchpack 1 (MID 15) position 1 from left (Switch 1 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_15_254_16 4_2_1_1 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------|-----|---|---|---------------|------------------|--------------------------------|
| 33 | 520859 | Switch 6-Pack #1 Location 2 | 13 | Unexpected switch in switchpack 1 (MID 15) position 2 from left (Switch 2 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_15_254_16 4_2_1_3 |
| 33 | 520860 | Switch 6-Pack #1 Location 3 | 13 | Unexpected switch in switchpack 1 (MID 15) position 3 from left (Switch 3 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_15_254_16 4_2_1_5 |
| 33 | 520861 | Switch 6-Pack #1 Location 4 | 13 | Unexpected switch in switchpack 1 (MID 15) position 4 from left (Switch 4 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_15_254_16 4_2_1_7 |
| 33 | 520862 | Switch 6-Pack #1 Location 5 | 13 | Unexpected switch in switchpack 1 (MID 15) position 5 from left (Switch 5 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_15_254_16 4_2_2_1 |
| 33 | 520863 | Switch 6-Pack #1 Location 6 | 13 | Unexpected switch in switchpack 1 (MID 15) position 6 from left (Switch 6 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_15_254_16 4_2_2_3 |
| 33 | 520922 | Switch 6-Pack #3 Location 1 | 13 | Unexpected switch in switchpack 3 (MID 3) position 1 from left (Switch 1 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_3_254_164 _2_1_1 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---|-----|--|---|---------------|------------------|-------------------------------|
| 33 | 520923 | Switch 6-Pack #3 Location 2 | 13 | Unexpected switch in switchpack 3 (MID 3) position 2 from left (Switch 2 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_3_254_164 _2_1_3 |
| 33 | 520924 | Switch 6-Pack #3 Location 3 | 13 | Unexpected switch in switchpack 3 (MID 3) position 3 from left (Switch 3 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_3_254_164 _2_1_5 |
| 33 | 520925 | Switch 6-Pack #3 Location 4 | 13 | Unexpected switch in switchpack 3 (MID 3) position 4 from left (Switch 4 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_3_254_164 _2_1_7 |
| 33 | 520926 | Switch 6-Pack #3 Location 5 | 13 | Unexpected switch in switchpack 3 (MID 3) position 5 from left (Switch 5 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_3_254_164 _2_2_1 |
| 33 | 520927 | Switch 6-Pack #3 Location 6 | 13 | Unexpected switch in switchpack 3 (MID 3) position 6 from left (Switch 6 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1708IN_3_254_164 _2_2_3 |
| 33 | 520928 | Daytime Running Light Tell Tale Command | 5 | DRL Tell Tale Relay Command is Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | DRL_Tell_Tale_Relay_ Cmd |
| 33 | 520928 | Daytime Running Light Tell Tale Command | 6 | DRL Tell Tale Relay Command is Overcurrent | Short To Ground or Defective Solenoid | Not available | Not available | DRL_Tell_Tale_Relay_ Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|---------------------------|-----|---|--|---------------|---------------|------------------------------|
| 33 | 520929 | AGSP Switch Location 1 | 13 | Unexpected switch in AGSP position 1 from left (Switch 1 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_132_61217_33_D_4_5 |
| 33 | 520930 | AGSP Switch Location 2 | 13 | Unexpected switch in AGSP position 2 from left (Switch 2 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_132_61217_33_D_4_7 |
| 33 | 520931 | AGSP Switch Location 3 | 13 | Unexpected switch in AGSP position 3 from left (Switch 3 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_132_61217_33_D_5_1 |
| 33 | 520932 | AGSP Switch Location 4 | 13 | Unexpected switch in AGSP position 4 from left (Switch 4 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_132_61217_33_D_5_3 |
| 33 | 520933 | AGSP Switch Location 5 | 13 | Unexpected switch in AGSP position 5 from left (Switch 5 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_132_61217_33_D_5_5 |
| 33 | 520934 | AGSP Switch Location 6 | 13 | Unexpected switch in AGSP position 6 from left (Switch 6 of 6) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_132_61217_33_D_5_7 |
| 33 | 520935 | Cluster Switch Location 1 | 13 | Unexpected switch in Cluster position 1 from left (Switch 1 of 2) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_23_61184_33_D_2_2 |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------------|-----|---|--|---------------|---------------|-----------------------------|
| 33 | 520936 | Cluster Switch Location 2 | 13 | Unexpected switch in Cluster position 2 from left (Switch 2 of 2) | Switch actuator installed or bad microswitch in location configured as empty | Not available | Not available | P_J1939IN_23_61184_33_D_2_4 |
| 33 | 520937 | TSS Module Power Control | 5 | TSS Module Power Control Under Current | Open Circuit or Under Current in TSS Module Power Control Circuit | Not available | Not available | TSS_Module_Power_Cmd |
| 33 | 520937 | TSS Module Power Control | 6 | TSS Module Power Control Overcurrent | Short To Ground or Overload in TSS Module Power Control Circuit | Not available | Not available | TSS_Module_Power_Cmd |
| 33 | 520938 | User Activated Data Logger | 2 | User Activated Data Logger switch error | Faulty Switch Actuator or Microswitch for User Activated Data Logger switch | Not available | Not available | Data_Logger_Enable |
| 33 | 520939 | Air Brake Pressure Ind Relay Driver | 5 | Air Brake Pressure Indicator Command is Under Current or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | Air_Brake_Pressure_Ind_Cmd |
| 33 | 520939 | Air Brake Pressure Ind Relay Driver | 6 | Air Brake Pressure Indicator Command is Overcurrent | Short to ground or defective solenoid | Not available | Not available | Air_Brake_Pressure_Ind_Cmd |
| 33 | 520940 | Power Adjustable Pedals Enable Relay | 5 | Power Adjustable Pedals Enable Relay Under Current Or Open Circuit | Open Circuit or Defective Solenoid | Not available | Not available | Adj_Pedal_Enable_Cmd |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|--------------------------------------|-----|--|--|---------------|---------------|-----------------------|
| 33 | 520940 | Power Adjustable Pedals Enable Relay | 6 | Power Adjustable Pedals Enable Relay Short To Ground | Short To Ground or Defective Solenoid | Not available | Not available | Adj_Pedal_Enable_Cm d |
| 33 | 520941 | Hydromax Pump Motor Relay Driver | 5 | Current Below Normal or Open Circuited | Current Below Normal or Open Circuited | Not available | Not available | Hymx_Pump_Relay_C md |
| 33 | 520941 | Hydromax Pump Motor Relay Driver | 6 | Current Above Normal or Short Circuited | Current Above Normal or Short Circuited | Not available | Not available | Hymx_Pump_Relay_C md |
| 58 | 109 | Coolant Pressure | 14 | High Refrigerant Pressure | High refrigerant pressure in system or pressure sensor unplugged or faulty Pressure sensor | | | |
| 58 | 168 | Electrical Potential (Voltage) | 3 | Battery Voltage High | Battery voltage above 16VDC | | | |
| 58 | 168 | Electrical Potential (Voltage) | 4 | Battery Voltage Low | Battery voltage below 12.1VDC | | | |
| 58 | 1547 | A/C Evaporator Temperature | 0 | Duct Inlet Sensor High | Recirc sensor wire shorted to power or Recirc sensor missing or open circuit or faulty Recirc sensor | | | |
| 58 | 1547 | A/C Evaporator Temperature | 1 | Duct Inlet sensor Low | Recirc sensor wire shorted to ground or fault Recirc sensor | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|----|--------|------------------------|-----|---|--|----------|------|----------------|
| 58 | 1548 | HVAC Duct Temperature | 3 | Duct temperature sensor voltage high | Duct temperature sensor wire shorted to power or open circuit or faulty sensor | | | |
| 58 | 1548 | HVAC Duct Temperature | 4 | Duct temperature sensor voltage low | Duct temperature sensor shorted to ground or faulty sensor | | | |
| 58 | 2058 | Source Address 58 | 9 | Rear HVAC Data Link Communication Failure | Faulty Rear HVAC or Body Builder Data Link | | | |
| 58 | 520210 | HVAC Blower Output | 3 | Blower output circuit over voltage | Voltage above normal, or shorted to high source | | | |
| 58 | 520210 | HVAC Blower Output | 4 | Blower output circuit under voltage | Voltage below normal, or shorted to low source | | | |
| 58 | 520210 | HVAC Blower Output | 6 | Blower output short circuit | Current above normal or grounded circuit | | | |
| 58 | 520211 | HVAC actuator position | 7 | Actuator position not responding | Mechanical system not responding or out of adjustment | | | |
| 58 | 520212 | HVAC Dimmer Output | 3 | Dimmer output voltage high | Voltage above normal, or shorted to high source | | | |
| 58 | 520212 | HVAC Dimmer Output | 4 | Dimmer output voltage low | Voltage below normal, or shorted to low source | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|-----|--------|-----------------------------|-----|--|---|--|------|----------------|
| 58 | 520213 | Evaporator Sensor | 3 | Evaporator Sensor High | Voltage above normal, or shorted to high source | Evaporator Sensor High or short to Battery | | |
| 58 | 520213 | Evaporator Sensor | 4 | Evaporator Sensor Low | Evaporator Sensor Low or bad sensor | | | |
| 58 | 520808 | No-Idle Compressor Relay | 14 | No-Idle Compressor Relay open circuit or shorted circuit | | | | |
| 58 | 520809 | No-Idle CHS relay | 14 | No-Idle Coolant Heater System relay has an open circuit or a shorted circuit | | | | |
| 58 | 520810 | No-Idle Condenser Fan Relay | 14 | Condenser fan relay has a short or open circuit | | | | |
| 58 | 520811 | No-Idle valve B relay | 14 | Valve B relay has an open circuit or a short circuit | | | | |
| 58 | 520812 | No-Idle datalink error | 9 | J1939 Body Builder Data link error | Abnormal update rate | | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132), lost communication with ESC. | Loss of drive-train data link. | Loss of communication in excess of 10 seconds. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|-----|------|-----------------|-----|--|-------|---|------|----------------|
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132). Datalink ignition signal does not match the hardwired ignition signal. | | | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 1, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 1, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 1, data missing. | | The data for this gauge is not being transmitted. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 2, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|-----|------|--------------------------|-----|--|----------------------|---|------|----------------|
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 2, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 2, data missing. | | The data for this gauge is not being transmitted. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 3, sensor fault. | | There is a problem with the sensor that provides data for this gauge. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 3, data unavailable. | | The data for this gauge should be, but is not available. | | |
| 132 | 2023 | Gauge Cluster | 14 | Auxiliary Gauge Switch Pack #3 (address 132) gauge location 3, data missing. | | The data for this gauge is not being transmitted. | | |
| 132 | 2033 | Communication Loss | 9 | Loss of data link from ESC | Abnormal update rate | | | |
| 132 | 2132 | Auxiliary Switch Pack #3 | 11 | Message accessory and switched accessory do not match for AGSP 3 | Root cause not known | | | |

| SA | SPN | DTC Description | FMI | Message | Cause | Comments | Pins | Logical Signal |
|-----|------|--------------------------|-----|--|-------------------------------------|----------|------|----------------|
| 132 | 2132 | Auxiliary Switch Pack #3 | 12 | Failure of non-volatile memory or checksum fault in AGSP 3 | Bad intelligent device or component | | | |
| 167 | 2033 | Communication Loss | 9 | Loss of data link from ESC | Abnormal update rate | | | |
| 167 | 2167 | Source Address 167 | 11 | Message ignition and switched ignition do not match for SIC 1. | Root cause not known | | | |
| 167 | 2167 | Source Address 167 | 12 | Failure of non-volatile memory or checksum fault in SIC 1 | Bad intelligent device or component | | | |