


FUEL TANKS

MODELS 4300M7 4x2, 4300M7 LP, 4300, 4400

Fuel Tank Location


Code 15SGJ – Single Left Side, Mounted Under Cab, 50 Gallon “D” Style



ALL MODELS

Fuel Tank Location

Code 15SGK – Single Right Side, Mounted Under Cab, 50 Gallon “D” Style



15_0009

DuraStar® SERIES


– 296 –

INTERNATIONAL®

MODELS 4x2, 6x4

Fuel Tank Location

Codes 15SNY, 15SNZ – Single Right Side, Mounted Under Cab, 50 Gallon “D” Style




15_0014

MODELS 4300 4x2, 4400 4x2, 4400 6x4

Fuel Tank Location

Coded 15SPB, 15SPC – Single Left Side, Mounted Under Cab, 50 Gallon “D” Style




15SPB_15SPC

MODELS 4300M7 4x2, 4300M7 LP, 4300, 4400 4x2, 4400 LP

Fuel Tank Location


Code 15SSE – Single Right Side, Mounted Under Cab, 65 Gallon Rectangular



MODELS 4300M7 4x2, 4300M7 LP, 4300, 4400

Fuel Tank Location

Code 15SGG – Single Left Side, Mounted Under Cab, 70 Gallon “D” Style




15_0012

MODELS 4X2 AND 6X4

Fuel Tank Location

Code 15SMD – Single Left Side, Mounted Under Cab, 70 Gallon




15smd

MODELS 4300M7 4x2, 4300M7 LP, 4300, 4400

Fuel Tank Location

Code 15SGH – Single Right Side, Mounted Under Cab, 70 Gallon “D” Style




15_0013

MODELS 4X2 AND 6X4

Fuel Tank Location


Code 15SRU – Single Right Side, Mounted Under Cab, 70 Gallon “D” Style



MODELS 4X2 AND 6X4

Fuel Tank Location

Code 15SGD – Single Left Side, Mounted Under Cab, 100 Gallon “D” Style




15SGD

MODELS 4X2 AND 6X4

Fuel Tank Location

Code 15SGE – Single Right Side, Mounted Under Cab, 100 Gallon “D” Style




15SGE


ALL MODELS

Fuel Tank Location

Code 15DMW – Dual Left and Right Side, Mounted Under Cab, 50 Gallon “D” Style



15_0017





15_0018

MODELS 4300M7 4x2 and LP, 4300, 4400

Fuel Tank Location


Code 15DMV – Dual Left and Right Side, Mounted Under Cab, 70 Gallon “D” Style




MODELS 4x2 and 6x4

Fuel Tank Location

Codes 15DUJ, 15DUK – Dual Left and Right Side, Mounted Under Cab 70 Gallon "D" Style Left Side, 50 Gallon "D" Style Right Side



15_0021




15_0022

MODELS 4x2 and LP

Under Cab Step Location With Crew Cab


Code 516006 – Left Side Mount With One Step – With Rectangular Fuel Tanks



MODELS 4x2 and LP

Under Cab Step Location With Crew Cab

Right Side Mount With One Step – With Rectangular Fuel Tanks




15_0024

MODELS 4x2 and LP

Under Cab Step Location With Crew Cab

Left Side Mount With One Step – With 50 and 65 Gallon Rectangular Fuel Tanks




* For fuel tank dimensions see fuel tank sections – left shown, right opposite

ALL MODELS

Under Cab Step Location With Crew Cab

Left Side Mount With Two Steps – With “D” Style Fuel Tanks




- A = 13.47 (342) with “D” Style 50 Gallon Fuel Tanks
16.17 (411) with “D” Style 70 Gallon Fuel Tanks
- B = 11.72 (298) with “D” Style 50 Gallon Fuel Tanks
14.42 (366) with “D” Style 70 Gallon Fuel Tanks

15_0026

ALL MODELS

Under Cab Step Location With Crew Cab

Right Side Mount With Two Steps – With “D” Style Fuel Tanks



- A = 13.47 (342) with “D” Style 50 Gallon Fuel Tanks
16.17 (411) with “D” Style 70 Gallon Fuel Tanks
- B = 11.72 (298) with “D” Style 50 Gallon Fuel Tanks
14.42 (366) with “D” Style 70 Gallon Fuel Tanks